Dr 125



ANCR-1271 UC-78 DATE PUBLISHED — APRIL 1976

IDAHO NATIONAL ENGINEERING LABORATORY

TEST REACTOR RISK ASSESSMENT METHODOLOGY

MASTER



PORTIONS OF THIS REPORT ARE ILLEGIBLE. It has been reproduced from the best available copy to permit the broadest possible availability.

PREPARED BY AEROJET NUCLEAR COMPANY FOR

ENERGY RESEARCH AND DEVELOPMENT ADMINISTRATION

IDAHO OPERATIONS OFFICE UNDER CONTRACT E(10-1) -1375

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency Thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

DISCLAIMER

Portions of this document may be illegible in electronic image products. Images are produced from the best available original document.

Printed in the United States of America
Available from
National Technical Information Service
U. S. Department of Commerce
5285 Port Royal Road
Springfield, Virginia 22161
Price: Printed Copy \$6.00; Microfiche \$2.25

NOTICE

This report was prepared as an account of work sponsored by the United States Government. Neither the United States nor the Energy Research and Development Administration, nor any of their employees, nor any of their contractors, subcontractors, or their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness or usefulness of any information, apparatus, product or process disclosed, or represents that its use would not infringe privately owned rights.

Distributed Under Category: UC-78 Light Water Reactor Technology TID-4500, R64

TEST REACTOR RISK ASSESSMENT METHODOLOGY

by

R. H. Jennings

J. K. Rawlins

M. E. Stewart


AEROJET NUCLEAR COMPANY

Date Published - April 1976

This report was prepared as an account of work sponsored by the United States Government. Neither United States, nor the United States, and the United States, and the United States, and the United States, and their employees, nor any of their contractors, subcontractors, or their employees, makes any warranty, express or implied, or assumes any legal stability or responsibility for the accuracy, completeness or usefulness of any information, apparatus, product or process disclosed, or represents that its use would not infringe privately owned rights.

PREPARED FOR THE
ENERGY RESEARCH AND DEVELOPMENT ADMINISTRATION
IDAHO OPERATIONS OFFICE
UNDER CONTRACT NO.E(10-1)-1375

DISTRIBUTION OF THIS DOCUMENT IS CINCIMITED



ACKNOWLEDGMENTS

Individuals other than the authors have made valuable contributions to this study. R. G. Ambrosek, in addition to providing advice regarding the design of the Engineering Test Reactor, was responsible for the core damage calculations. H. K. Petersen and \bar{J} . M. Strong were responsible for making the consequence calculations and secondary event identifications, respectively. D. M. Rasmuson and F. J. Balkovetz quantified the fault models. J. B. Sahr provided advice regarding the operation of the Engineering Test Reactor.

ABSTRACT.

A methodology has been developed for the identification of accident initiating events and the fault modeling of systems, including common mode identification, as these methods are applied in overall test reactor risk assessment. The methods are exemplified by a determination of risks related to a loss of primary coolant flow in the Engineering Test Reactor.

CONTENTS

ACK	NOW	LEDGMENTS
ABS	TRAC	CT
I.	INT	RODUCTION
II.	RISI	K ASSESSMENT
	1.	ACCIDENT INITIATING EVENTS
,	2.	EVENT TREES
	3.	SYSTEM FAILURE AND EVENT TREE SEQUENCE PROBABILITIES
	4.	CONSEQUENCES
Ш.	ACC	IDENT INITIATING EVENT IDENTIFICATION
IV.	SYS	TEM FAULT MODELING
	1.	SYSTEM FAILURE DEFINITION AND UNDESIRED EVENT 15
	2.	FAULT TREE CONSTRUCTION
		2.1 Conventional Fault Tree Construction
	3.	COMPONENT FAULT STATES
	4.	GATE TYPES
	5.	TRANSFERS
	6.	EVENT NAMING
	7.	REQUIRED CONDITIONS
	8.	BOOLEAN SIMPLIFICATION
	9.	COMMON MODE FAILURES

	10.	HUMAN ERRORS	34
	11.	TEST AND MAINTENANCE	34
	12.	ANALYSIS STAGING	35
•	13.	DATA	35
	14.	QUANTITATIVE EVALUATION OF FAULT MODELS	36
v.	DEF	INITIONS	38
VI.	REF	ERENCES	39
APP	ENDI	X A – RISK ASSESSMENT OF ETR LOSS OF FLOW	·
	EVE	NT	41
	1	DISCUSSION OF ETR	43
	2.	OVERVIEW OF DISCUSSION	45
	3.	IDENTIFICATION OF ACCIDENT INITIATING EVENTS	45
		3.1 Undesired Radiological Release 3.2 Release Sources 3.3 Switches for Release Magnitudes 3.4 Switches for Operating States 3.5 Barriers Preventing Release 3.6 Barrier Failure Mechanisms 3.7 Accident Initiating Events	45 45 47 47 47 47
	4.	LOSS OF FLOW ACCIDENT	48
	5.	SYSTEMS ANALYSIS	49
		5.1 Primary Coolant System	49 67 70
	6.	EVENT SEQUENCE PROBABILITIES	88

	7.	CORE DAMAGE	89
		7.1 Model	89 90 90 102 106
	8.	CONSEQUENCES	107
	9.	RISK RESULTS	108
	10.	REFERENCES	117
APP		X B — DIFFERENCES BETWEEN TEST REACTORS AND IMERCIAL NUCLEAR PLANTS	119
		FIGURES	
)	
1.	Risk	assessment tasks	4
2.	Exa	mple event tree diagram	5
3.	Majo	or steps to identify accident initiating events	9
4.	Faul	It tree logic leading to list of accident initiating events	10
5.	Core	e deluge system simplified diagram	14
6.	Top	level fault tree-core deluge system	15
7.	Faul	It tree of Subsystem A output component	16
8.	Faul	It tree development of two single input components in series	17
9.		ical fault tree structure of component with two inputs related utput by AND logic	18
10.		ical fault tree structure of component with two inputs related utput by OR logic	18

11.	Typical fault tree structure of component with complex inputs	19
12.	Abbreviated fault tree structure of two components in series	22
13.	Abbreviated fault tree logic gates	24
14.	Required conditions incorporated as a direct input to AND gate	31
15.	Required conditions incorporated as inverted inputs to AND gate	31
16.	Classifying faults using the house	32
A-1.	Simplified diagram of ETR	44
A-2.	ETR accident initiating events fault tree	46
A-3.	Event tree for loss of flow event	49
A-4.	ETR primary coolant system - simplified flow diagram	51
A-5.	ETR loss of forced flow	53
A-6.	Reactor shutdown system simplified block diagram	69
A- 7.	Reactor protection system for loss of forced flow fault tree	71
A-8.	Emergency flow system fault tree	83
A-9.	ETR core model for risk evaluation	91
A-10	. CFA 250-foot level lapse wind roses, July 1951 through May 1962	.09
A-11	. CFA 250-foot level inversion wind roses, July 1951 through May 1962 1	10
A-12	. Risk summary for ETR loss of flow event	18
	TABLES	
Ī.	Fault Summary	21
II.	System Code	26
III.	Fault Mode Code	26

IV.	Component Type Code	27
V.	Secondary Event Type Code	30
VI.	Common Mode Events on Fault Summary	33
A-I.	Loss of Primary Flow	57
Λ-II.	Reactor Protective System for Loss of Forced Flow	74
A-III.	Loss of Emergency Flow	85
A-IV.	Flow Coastdown Expected with Two Pumps Operating	,92
A-V.	Core Volume Geometry	93
A-VI.	Core Volume Geometry	94
A-VII.	Core Section Geometrics	95
A-VIII.	Junction Data	97
A-IX.	Junction Data	98
A-X. .	Data Values for Three Heat Conductor Geometries	9.9
A-XI.	Core Geometry	100
A-XII.	Core Power Distributions	101
A-XIII.	Reactor Kinetics Parameters	103
A-XIV.	Feedback Parameters	105
A-XV.	Data Input to RSAC-2	111
A-XVI.	Thyroid Inhalation Dose with Lapse Weather Conditions	112
A-XVII.	Input Data to RSAC-2	114
A_ Y VIII	Thyroid Inhalation Dose with Inversion Weather Conditions	115

TEST REACTOR RISK ASSESSMENT METHODOLOGY

I. INTRODUCTION

The methods developed and described herein are intended for use in quantitatively evaluating the risks of test reactors. Risk is generally defined in the dictionary as the chance of injury where injury might be construed to mean bodily injury, loss of wages, loss of property, etc. In terms of accident producing injuries risk can be defined as the product of an accident occurrence probability and the consequence of that accident (that is, risk equals accident probability times accident consequence). In reactor safety it has been customary to talk about the probability of accident occurrence in a qualitative sense. For example, the familiar terms credible, incredible, likely, unlikely, extremely unlikely, and anticipated are usually used to describe the predicted frequency of accidents. The consequence factor, on the other hand, has been subject to the rigor of the scientific approach and, therefore, can be expressed quantitatively. Unless both factors in the risk expression are quantified, risk and, therefore, safety must be generally classified as unknown.

The recent Reactor Safety Study (RSS)^[1] was a comprehensive study to estimate quantitatively the risks associated with two large commercial nuclear plants and to compare those risks with other natural and man-made risks to which the general public is exposed. The methods used to assess risks by the RSS can be used to evaluate any type of reactor plant. However, areas exist in which modification and expansion of the methods used by the RSS is desirable so that the methods can be made more suitable to the evaluation of other plants. The primary objective of the present study is to develop methods which can be applied to ERDA-owned test reactors, the intent being to modify and expand the methodology used in the RSS where needed and to improve the methodology where improvement is clearly possible. A secondary objective of this study is to demonstrate the methods which are developed by applying them, on a skeleton basis, to the evaluation of the Engineering Test Reactor (ETR) at the Idaho National Engineering Laboratory (INEL).

Three major areas exist in which departures have been made herein from the methods used in the RSS: (a) accident initiating event identification, (b) system fault model construction, including the treatment of common mode events, and (c) radiological consequence determination. Accident initiating event identification and system fault modeling have been subject to development by this study. They are discussed in some detail in Sections III and IV, respectively. The discussion on fault modeling duplicates somewhat that contained in Reference 1 because it was believed to be needed in order to facilitate description of the improved method. Radiological consequence determination was not subject to methodology development. Standard methods are in use at the INEL for making these determinations and were used herein to illustrate the risk methods. This alternate methodology for determining radiological consequences is discussed in Section II. Also in Section II is an overview of the tasks required to do a risk evaluation.

A few terms are used herein that required definition. These terms are defined in Section V.

A hypothetical loss of flow accident at the ETR was selected to illustrate the risk assessment techniques. This_sample assessment is described in Appendix A.

II. RISK ASSESSMENT

The major tasks proposed here for assessing test reactor risks are summarized in the following discussion. The overall approach is generally the same as that used in the RSS which is shown in Figure 1. Where departures have been made from that study, they are so mentioned. For more detailed discussion regarding the methodology used in that study, the reader should refer thereto.

1. ACCIDENT INITIATING EVENTS

The first step in a risk assessment is to identify the accident initiating events associated with the plant; that is, to identify those events such as loss of coolant or loss of flow that could result in a radioactivity release [a] if the safety systems provided to cope with those events did not respond. The accident initiating events selected in the RSS were those recognized by the Nuclear Regulatory Commission as important to nuclear safety and events which have evolved over the years from reactor licensing activities and extensive reactor safety research. The test reactor designs have not been subject to that same research. Instead, they are precursors to and specifically designed tools used in that research. Major differences occur in the objectives of the two reactor types and, therefore, their designs; so the accidents, and risks, could appreciably differ [b]. And faults occurring in experiments, which might change from test to test, could change the nature of the risks from experiment to experiment. Appropriately then, a procedure should be developed which could be used to systematically identify accident initiating events. Such a procedure has been developed here; it makes use of the fault tree method to (a) identify all sources of radioactivity within a test reactor facility, (b) identify the barriers which retain that radioactivity, and (c) identify the mechanisms by which those barriers can fail. The failure mechanisms are the accident initiating events. This procedure is discussed fully in Section III.

2. EVENT TREES

The second step in the procedure is to develop an event tree for each of the important accident initiating events identified. The event tree is a logic diagram which depicts all meaningful outcomes, or accident sequences, which result from each applicable engineered safety feature, either responding or not responding to a given accident initiating event. For example, typical possible responses to a large pipe break in a power reactor might be those shown in Figure 2. Each of the systems needed to respond to a pipe break is shown

[[]a] The scope of this study has been arbitrarily limited to those risks pertaining to radioactivity releases.

[[]b] Some of the major differences between test reactors and large commercial reactors that could appreciably affect their risk differences are discussed in Appendix B.




Fig. 1 Risk assessment tasks.

2




Fig. 2 Example event tree diagram.

as a column heading on the event tree, and each of these systems can succeed (denoted by yes in the example) or fail (denoted by no). Whether a system works or does not work results in a different sequence. The column headings are ordered according to time and dependency such that the system to the left must work first, those to the right last; dependent systems are shown first, nondependent systems are shown last. Logic reasoning is applied in the construction of the event tree so that meaningless sequences are eliminated. For example, if the reactor shutdown system does not work, whether or not the emergency coolant, containment isolation, and containment heat removal systems operate is immaterial. Thus, a straight line is drawn across columns subsequent to the reactor shutdown failure.

The event tree, in addition to providing a logic diagram of the meaningful responses to an accident initiating event, serves to identify the systems requiring detailed analyses and it can be used conveniently to summarize the probability and consequence values obtained from the study. These values are discussed further.

3. SYSTEM FAILURE AND EVENT TREE SEQUENCE PROBABILITIES

Each sequence shown on the event tree has a probability of occurring and results in a definable radioactivity release. Radioactivity releases and their attendant consequences are discussed in Section II-4. Sequence probabilities are obtained by combining accident initiating event occurrence probabilities with probability values for each of the engineered safety systems identified in the individual sequences. Dependencies between systems identified in the sequences must be considered in the computations, and can be done automatically for cases in which the complete systems fault models can be combined before the computation is made.

The probability values used in a sequence computation are the probability that the initiating event occurs and the probability that each of the responding systems is in a failed state (does not work as shown in Figure 1) when the initiating event occurs (system unavailability).

System failure probabilities are derived by developing detailed fault models of each of the systems which appear in the accident sequences, applying experience data to those models, and combining those data according to the logic of the models. Tasks 5, 6, and 7 of the RSS shown in Figure 1 embody these activities. The RSS found the fault modeling of systems to be very time consuming and, therefore, costly. So considerable effort was devoted to streamlining the fault tree methodology, and as a result an abbreviated approach has been developed and tried which reduces by about one-half the time required to develop a conventional fault tree model. This modified procedure has other advantages over the conventional fault tree approach in that it provides more visibility of the system fault modes and their logical interrelationships, modifications are made relatively easy, and the model can be checked against the system without much difficulty. The procedure also describes a workable approach for the identification of common mode failures which are readily incorporated into the fault model. This abbreviated fault modeling procedure is described in Section IV.

4. CONSEQUENCES

As indicated in Section II-3, each accident sequence results in a definable radioactivity release and ultimately results in a definable consequence. The RSS, in essence, determined the release for each sequence (Task 3 in Figure 1). Actually, a large number of sequences involved similar physical processes and produced similar consequences; thus, the RSS was able to define a few release categories in which the sequences could be grouped. The result was a histogram representing the probability distribution of the release categories. This histogram was then input to the consequence model. The consequence model, in essence, then combined each of the values in the histogram with each of the values in distributions for other important variables until all possible combinations of the values were considered (Task 8, Figure 1). The result of the calculation was a probability versus magnitude distribution for each of the consequences: deaths, injuries, long-term health effects, and property damage. These results were presented in graphical form with the probability of a consequence equal to or greater than X plotted along the ordinate and consequence X plotted along the abscissa (Task 9 in Figure 1).

A different approach is used here for dealing with the consequence factor in the risk expression. Primarily, the release probabilities are not input to the consequence model. Instead, the consequence of each sequence is determined independently of the sequence probability, and the result is multiplied by the sequence probability to obtain a risk value for that sequence. The probability, consequence, and risk value corresponding to each sequence is then summarized on the event tree. (The event tree, Figure A-12, in Appendix A reflects these values for a loss of flow event at the ETR.)

The radioactivity release terms were obtained by the RSS through use of a computer code called CORRAL developed in that study. Here a computer code, RELAP4^[2], is used to calculate the fraction of core damage and this calculation, in turn, provides input to a computer code, RSAC2^[3], which calculates the consequences.

RELAP4 is a thermal analysis code developed by Aerojet Nuclear Company which describes the behavior of water-cooled reactors subjected to postulated transients such as loss of coolant, pump failure, or excursions in nuclear power. Inputs to the code describe the geometry of the system and initial conditions; the code calculates as a function of time fluid conditions (for example, flow, pressure, and quality), thermal conditions (for example, surface temperatures and temperature profiles), heat fluxes in power generating and dissipating elements, reactor power, decay heat, and reactivity.

RSAC2 calculates radiological consequences resulting from reactor accidents. Input to the computer code generally consists of the reactor core power history, fission product release data, and data which describe the meteorology of the site (for example, release height, inversion height, meteorological diffusion data, wind speed, release rate, and downwind distance). With fission product dispersion calculated, radiological doses for hypothetical receptors at predetermined downwind locations are calculated. These radiological consequences can be expressed in terms of wholebody gamma doses due to immersion in the radioactive plume or in terms of body organ doses by specific nuclides due to inhalation.

III. ACCIDENT INITIATING EVENT IDENTIFICATION

The first step in risk assessment is to select the accident initiating events, that is, those events that can result in accidents if not checked or mitigated. For this study, the events that could lead to release of radioactivity must be found. These events may be operating errors or hardware failures that are not expected to occur but, should they occur, may require operator or safety system action to prevent the release of radioactivity. The potential of these events occurring combined with the potential that the corrective action is not taken is part of the risk calculation. The consideration of all accident initiating events is essential for an accurate assessment of risk.

The steps for identifying accident initiating events are shown in the block diagram in Figure 3. As indicated in the left block, the first step is to state the undesired event, in this case a radiological release from the reactor facility. This is the release for which the probability of occurrence and consequence will be determined.

The second step is to determine all possible sources of radioactive material at the reactor facility that if released could cause the release stated in Step 1.

Step 3 requires consideration of the plant operating states that can affect the release magnitude. For example, the release potential will be different if flow blockage occurs in the reactor cooling system when the reactor is or is not operating.

The barriers that prevent the release of the radioactive material from each potential source are determined in Step 4.

The final step lists the accident initiating events. These events are the mechanisms that can cause the failure of each barrier. Event trees are developed for each of the events identified in this step as part of the overall risk assessment.

The fault tree method illustrated in Figure 4 is used when Steps 1 through 5 are performed in order to logically tie together the steps which lead to the listing of all accident initiating events. The statement of the undesired radiological event becomes the top event for the fault tree. The analyst is then required to determine all possible sources of radioactive material within the facility that if released could cause the top event to occur. Information must be obtained about the flow of radioactive material at the reactor site for the analyst to be able to make this list.

The next level of the tree contains the "house" fault tree symbol that is used here as a switch to "turn on" that part of the tree that should be included and thus allows investigation of radiological releases of different magnitudes. The analysis can be general or explicit as to the amount of release; here the amount is kept general because the amount does not enter into the calculations. This switching ability of the "house" is explained in Section IV-7.




Fig. 3 Major steps to identify accident initiating events.




Fig. 4 Fault tree logic leading to list of accident initiating events.

If different operating states affect the magnitude of the release from a source, the next level of the tree should distinguish these operating states by using "houses" at the next fault tree level to switch on or off operating states to be considered or not considered, respectively, in the analysis.

Before the radioactive material at each source can be released to the environment, the barriers that contain the material must be penetrated. Each barrier becomes an input to an "AND gate" on the fault tree. All the barriers for each source must be penetrated before the release can occur.

The accident initiating events are those events that can cause failure of the barriers. All mechanisms of failure should be considered. The list should be verified by knowledgeable individuals and by a study of the reactor operating history.

IV. SYSTEM FAULT MODELING

A modified and abbreviated version of the fault tree method is used to determine system success and failure probabilities where the system, in turn, is related to the overall risks associated with the plant. Fault tree analysis is a systematic procedure used to identify and record the various combinations of component fault states that can result in a predefined undesired state of a system. Unlike the familiar inductive method of first postulating a component failure mode and then determining its effect on the system. fault tree analysis is an opposite deductive approach whereby the analyst first defines an undesired system effect and then identifies all the component failure modes that can, by themselves or in combination with other component failure modes, produce that predefined undesired system state. A fault tree, as opposed to fault tree analysis, is a result of the fault tree analysis and is a graphic display of all of the fault modes of a system and the combinatorial AND and OR logic that relates those fault modes to the predefined undesired event associated with the system. It is a fault model of the system which, when expressed in its nonredundant Boolean form, can be used as a probabilistic model to determine an overall probability of system failure based on known, or easily computed, probability values for individual events shown on the fault tree.

1. SYSTEM FAILURE DEFINITION AND UNDESIRED EVENT

Fault tree analysis begins with a statement of the undesired event. Embodied in that statement must be the conditions which constitute failure of the system. For example, the undesired event, "insufficient coolant flow through the reactor core when the reactor is generating heat" is considered. This event statement is a complete logic statement specifying the requirements for reactor coolant. If a fault tree were to be developed about the undesired event, the analyst would examine all systems, normal operating and emergency systems, which deliver coolant to the reactor vessel. The analyst may define a more restrictive undesired event, for example, "insufficient emergency coolant flow when normal flow is lost", for which a fault tree is developed for the auxiliary coolant systems only.

The undesired event examples previously presented are stated rather generally which in most cases is perfectly acceptable. For example, the word "insufficient" implies that below some flow value, the system will have failed. Where redundancy has been provided, however, the generalized statement must be translated into a statement more specific in order to account for the redundant capabilities of the system. For example, the statement "insufficient coolant flow . . ." might be translated into the more specific statement "less than two pump coolant flow . . ." where more than two pumps have been provided.

The fault tree will be developed about the selected undesired event, and only events which relate logically to the occurrence of that undesired event will be identified.

Component failures that produce other undesired events (for example, inadvertent operation of the system) when loss of flow is of concern will not be identified unless the particular component failures relate to the occurrence of both undesired events.

The undesired event and all subsequent events shown on the fault tree are binary. That is, if the event as stated occurs, the system (or component in more detailed parts of the tree) has failed; if the event does not occur, the system has not failed. Ambiguous or "maybe" statements are not allowed on the tree. The statement is either true if the condition exists or false if the condition does not exist.

2. FAULT TREE CONSTRUCTION

Once an undesired event has been defined, a fault tree can be constructed about that undesired event. To illustrate the procedure, the ETR core deluge system will be used as an example. First, the top tiers of the fault tree will be constructed using the conventional method^[4,5]; then the tree will be restructured using an abbreviated approach developed and demonstrated herein.

Figure 5 is a simplified schematic of the core deluge system. The system is comprised of two redundant subsystems, each containing an air-operated block valve which must open when the system is needed to allow emergency coolant to flow from a source of coolant to the reactor vessel. The block valve is opened automatically by associated instrumentation and controls when the water in the reactor vessel drops below a predetermined safe level.

2.1 Conventional Fault Tree Construction

4.

The top event selected for the core deluge system is "insufficient coolant flow from the core deluge system when the reactor is producing heat and the water level in the vessel is low". This event, as shown in Figure 6, is the top event on the fault tree. Since the "when" statement specifies the conditions under which the fault events to be defined by the fault tree produce system failure (Section IV-7), the top undesired event is translated into two statements: (a) "reactor producing heat and vessel water level low", which is shown within a house, and (b) "insufficient coolant flow from the core deluge system", a fault, shown within a rectangle, which will be developed further. Since there are two subsystems, either one of which will provide sufficient emergency coolant, the "insufficient coolant flow from the core deluge system" statement can be translated into two statements, "insufficient coolant from core deluge Subsystem A" and "insufficient coolant from core deluge Subsystem B". Both subsystems must coexist in a failed state in order to produce failure of the system; so an AND gate is used to relate the two subsystem events to the system event (gate types are discussed in Section IV-4). Thus a system event, a set, has been transformed into subsystem events, or subsets.




Fig. 5 Core deluge system simplified diagram.

. .

₽,




Fig. 6 Top level fault tree core deluge system.

Next, the subsystem events are translated into events pertaining to components within the subsystem. At this level of resolution, each component fault in a subsystem is enumerated in the subset, but no new levels are established. To enumerate component faults in an orderly fashion is desirable, and is most easily accomplished by starting with the subsystem output components and then stepwise examining each upstream component. That is, to work toward sources of energy is desirable because each succeeding tier of events on the fault tree results in the preceding or higher tier of events. So the subsystem event "insufficient coolant from Subsystem A" is translated into an event related to the output component of the subsystem, a pipe, which is "insufficient coolant flow from Pipe 1A". The Subsystem B event is similarly restated.

Examination of the fault tree in Figure 7 for output Pipe 1A shows that "insufficient flow from Pipe 1A" can be caused by rupture of Pipe 1A, plugging of Pipe 1A, a higher pressure in the reactor vessel than in the core deluge system, or insufficient coolant from the upstream—component Check Valve DV-1A. These are all the immediate events sufficient and necessary to prevent coolant flow through Pipe 1A.

Development of the fault tree one more step involves examination of the next upstream component of the subsystem to determine what can cause "insufficient coolant flow from Check Valve 1A". This additional development is shown in Figure 8. "Higher pressure in the vessel than in the system" would also be a cause for "insufficient coolant flow from Check Valve 1A"; however, this event has already been identified in the preceding component fault tree development; therefore, it is not restated (further discussion is provided in Section IV-8 on Boolean reduction for justification). Most component arrangements in typical systems are of the series type as indicated thus far — each component output is an input to a succeeding component. Some components have multiple inputs, and the inputs may relate to the output through AND logic as shown in Figure 9, OR logic as shown in Figure 10, or a more complex logic arrangement. Figure 11 is one example of complex inputs. A large number of possible complex logic arrangements occur, depending on the system and component complexity.




Fig. 7 Fault tree of Subsystem A output component.




Fig. 8 Fault tree development of two single input components in series.

The fault tree is developed in the preceding manner until all components of the system are identified in their basic fault states. The result is a binary model of the system which can be reduced to its simplest Boolean form. Failure rates, human error rates, and appropriate time intervals can be assigned to determine probability values for the components, subsystems, and the system. The quantification process involves the naming of events (Event Naming, Section IV-6) and the transferring of all the information contained on the fault tree to event tables and coding sheets for ease in the assignment of data to events and for computer processing.




Fig. 9 Typical fault tree structure of component with two inputs related to output by AND logic.




Fig. 10 Typical fault tree structure of component with two inputs related to output by OR logic.




Fig. 11 Typical fault tree structure of component with complex inputs.

2.2 Abbreviated Fault Tree Construction

Since all basic fault event statements on the conventional fault tree are subsequently transferred to tables, one way to reduce the fault tree analysis effort is to not put those statements on the fault tree in the first place. The first step in the abbreviated method, then, is to enter all basic fault statements directly onto fault summary tables (a portion of a fault summary table is shown in Table I). Only the event code name, described in Section IV-6, is shown on the fault tree.

The second step in the procedure is to define a new logic gate, the tabulation OR gate (described in Section IV-4), to facilitate the listing of event names on the tree rather than to show named individual event statements within event type symbols as is conventionally done. Typically, systems which are evaluated contain a large number of events that are logically in series when reduced. For example, the fault tree development for the two core deluge components connected in series (shown in Figure 8) is considered. This development can be restructured as shown in Figure 12, where the code names for basic input events are listed under a tabulation OR gate, and only the input to the two components is identified for further development. The same treatment can be applied to any number of components logically in series. A completed fault tree for a system would be typically depicted by a top undesired event, basic fault events listed by code name under one or more tabulation OR gates, a few input events identified within rectangles which are inputs to chains of components and inputs to the system, a few house events, and the logic AND and OR gates used to relate the events. All the other information is contained in the fault summary table.

The abbreviated fault tree procedure has several distinct advantages over the conventional approach, all of which ultimately reduce the time and effort required to evaluate a system. Some of the more important of those advantages can be summarized as follows:

- Fault trees are readily restructured for each new accident situation. (1)For example, the loss of flow accident associated with the ETR might result from any number of pipe ruptures or from failure of any number of faults in the power circuits to the primary coolant pumps. A loss of flow accident resulting from a pipe rupture may require that the core deluge system respond; whereas, a loss of flow accident caused by loss of power to the pumps requires that one of the emergency pumps continues to operate. A fault tree for each of the situations can be derived from a fault tree constructed for the general case of "loss of flow" by merely excluding on the fault tree all coded events related to loss of power to the primary pumps in the first case and excluding all pipe ruptures, also coded events, in the second case. The fault statements entered in the fault summary are not changed. During the course of this study the requirement for operation of primary coolant pumps changed from two of four pumps to three of four pumps. The change would have resulted in a major change to a conventional fault tree; only a few minutes were needed to change the abbreviated tree.
- (2) Component fault modes and their logical relationship to system failure are more visible on the abbreviated fault tree. A typical system fault tree developed according to the conventional procedure usually requires 20 to 30 large sheets of paper in order to show all the component fault

TABLE I
FAULT SUMMARY

			PRIMARY FAILURE				SECONDARY EVENT (10 ^{-x} .)*											
EVENT NAME	EVENT COMPONENT	FAILURE MODE	FAILURE RAȚE	FAULT DURATION	ERROF. FACTOR	FIRE	FLOOD	EARTHQUAKE	SIEAM	нідн темревативе	PRESSURE	номіріту	FREEZING	MISSILE	- ЫРЕ WHIР			
BPPOO1AR	Pipe 1A	Rupture																
BPPOO1AP	Pipe 1A	Plugged			٠										\square			
P000001M	Higher Pressure in Vessel Than System											,						
BCVOO1AD	Check Valve 1A	Does Not Open						1										
BCVOO1AP	. Check Valve 1A	Plugged								·								
BCVOO1AR	Check Valve 1A	Rupture																
	,																	
															\Box			
			<u> </u>	<u> </u>	L													

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)




Fig. 12 Abbreviated fault tree structure of two components in series.

statements. These same component faults usually can be shown on two or three $8-1/2 \times 11$ inch sheets when presented in the abbreviated form. Because of their reduced size and because of the improved fault mode visibility of the system, the fault trees are much easier to check.

- (3) A system evaluation is easier to stage using the abbreviated method. Analysis staging is discussed more fully in Section IV-12.
- (4) The abbreviated procedure is more amenable to the treatment of common mode. This procedure is discussed in Section IV-9.

(5) Where formalized reports are required, most diagrams are superseded by tables which require less publication effort.

3. COMPONENT FAULT STATES

A component can transfer to a fault state due to any one of three categories of causes: primary failure, secondary failure, and command transition. A primary failure is the so-called "random" failure found in the reliability literature and refers to failure from no known external causes. A secondary fault results when a component is exposed to an operational or environmental condition which exceeds the design rating of that component. A command transition does not involve actual component failure. It simply means that the component is in the wrong state at the time of interest because it was commanded to that faulted state by another faulted component, a human error, or in some cases by an environmental condition.


Most of the data available on nuclear components embody both primary and secondary causes for failure; therefore, the distinction between the two types of failure is not made on the fault tree except for the case in which a secondary cause results in multiple component failures, and the distinction is made in code only. The procedure for screening secondary failures for common mode failures is discussed in Section IV-9.

4. GATE TYPES


The basic logic gates used in fault tree work are the AND and OR gates. A number of variations of these basic gate types have been introduced in the literature from time to time which are used to handle special situations. Shown in Figure 13 are the standard AND and OR gates and the tabulation OR gate which is introduced here to enumerate a set of fault events which are associated with a series arrangement of components. Safety systems are typically comprised of redundant subsystems each having numerous components connected in series. A fault tree constructed for one of these systems will have, then, a large number of OR gates each with several inputs. The advantage of the tabulation OR gate is that it permits all the fault events within a series arrangement of components to be tabulated rather than being spread out, sometimes over several pages, within individual fault symbols connected together by OR gates.

5. TRANSFERS

Most system fault trees, even the abbreviated form discussed herein, may extend to more than one sheet of paper. To facilitate the extension of a fault tree branch from one sheet to another, transfers are used as follows:




The transfers are arbitrarily lettered or numbered to facilitate cross reference.



AND GATE


The output event A occurs when input events X_1 and X_2 and X_n coexist.



OR GATE

The output event A occurs when any one or more input events X_1 , X_2 X_n exist.

$$A = X_1 + X_2 + \dots X_n$$
 (All input events independent)



TABULATION OR GATE


The output event A occurs when any one or more input events $X_1, X_2 \dots X_n$ exist.

$$A = X_1 + X_2 + ... X_n$$
 (A11 input events independent)


Fig. 13 Abbreviated fault tree logic gates.

6. EVENT NAMING

In order to facilitate the computer handling of events, each basic input event (events which are not expanded into their respective causes) is given a code name. The identification codes are presented in Tables II through V. Required conditions, or "house" events, are identified on the model by a four-character naming scheme as follows:




Fault Events are given an eight-character name described as follows:



The component identifier in the code is identifiable (where practicable) with the name given the component in the facility identification.

Secondary events which are expected to have significant effect on component failure and are suspect of affecting multiple components (common mode) are given a different eight-character name than that described previously. This secondary event code is characterized by the type of secondary event and location:



The potential secondary event location is best identified by building, room number within the facility, and cabinet number if applicable. If all rooms within the facility are uniquely numbered, the building number is not needed.

All events which are unique in the system must be given a unique name. An event may appear in more than one place on the model or on multiple models, but if it is the same event in the system it must be given the same name.

7. REQUIRED CONDITIONS

A system can assume a variety of possible off, standby, or normal operational states depending on plant conditions and operational requirements. For example, a water pump may be off if the water level in a tank is high but on if the water level is low, a diesel generator may be required to start if the offsite power fails, or a valve may be required to close if a fault has occurred in a downstream component. In fault modeling, inclusion: by the analyst of the conditions upon which a system or component is required in the analysis is important. A systemfault is not considered a tault unless the system is required. For example, failure of a diesel to start at any time other than when the diesel is needed is not a fault insofar as the analysis is concerned.

Required conditions in a fault tree analysis can be in the form of explicit assumptions and the fault tree constructed accordingly, or the required conditions can be incorporated directly into the fault model. The latter is preferred because it provides versatility in the use of the model. When incorporated

TABLE II

SYSTEM CODE

Code	System
A	Surge tank
В	Core deluge
С	Demineralizer
Ď	Primary coolant
E	Auxiliary flow
F	Secondary coolant
G	Reactor
I	Reactor protection
J	Degassing
K ·	Demineralizer
M	Experiment

TABLE III
FAULT MODE CODE

Code	Fault Mode
Α	Does not start
В.	Open circuit
С .	Close valve
D.	Does not open
E	Engaged
F	Loss of function
G	Disengaged
K	Does not close
L	Leakage
М	Exceeds limit
N	No input
0	Open valve
P	Plugged
Q	Short to power
R	Rupture
S	Short to power

into the model, required conditions are shown within the "house" symbol. The "house" serves as a switch to turn on those events which are faults when the required conditions exist and off when the required conditions do not exist. The "house" is input into one input of an AND-gate, and the subtree of faults is input into other inputs of the AND gate as shown in Figure 14.

In some situations, to turn on or off subtrees by connecting the "house" to the input of an OR gate is desirable before going into an AND gate as shown in Figure 15. In this case the required condition is inverted (stated negatively) such that when the "house" statement is true the AND gate is enabled; when the "house" statement is false only the existence of faults described by the associated subtree enable the gate. Typically this inverted logic arrangement is used in fault modeling standby redundancy.

The house is also used to describe mutually exclusive faults, in which case two "houses", as shown in Figure 15, are used — one or the other house can be on but not both at the same time.

The house is also frequently used to classify faults for which each fault classification results in a different consequence. For example, in the evaluation of a reactor containment classification of breach areas (faults) according to size may be desirable as shown in Figure 16. In the computer evaluation of the preceding fault tree either or both houses may be turned on depending on whether the analyst is interested in faults <2 in.², >2 in.², or all faults, respectively, where the faults in each

TABLE III (contd.)

FAULT MODE CODE

Code	Fault Mode
T	Test and maintenance outage
· W	Does not actuate
X	Operational or maintenance fault

TABLE IV

COMPONENT TYPE CODE

Mechanical Components	*
Code	Component
AC	Accumulator
AV	Valve, air operated
BL	Blower
CD	Control rod drive unit
CP	Pipe cap
CV	Check valve
DL	Diesel
FE	Flow element
FL	Filter or strainer
GB	Gas bottle
GK	Seal or gasket
HE	Heat exchanger
HV	Valve, hydraulic operated
KV	Valve, solenoid operated
MV	Valve, motor operated
, NZ	Nozzle
OR	Orifice
PM	Pump
PP	Pipe
PV	Pressure vessel
sv	Safety valve


TABLE IV (contd.)

category are listed under the tabulation OR gate (described in Section IV-4).

8. BOOLEAN SIMPLIFICATION

The final process in developing a fault model of a system to which probabilistic values can be assigned involves removing redundancies from the Boolean expression of the model, usually by using the PREP or MOCUS computer codes [6,7]. The analyst can, however, often save considerable time by the application of the same process in developing the fault model in the beginning. However, the analyst should not necessarily try to reduce the model to its simplest Boolean form as it is being constructed, but knowledge of how the model is simplified will sometimes allow the analyst to construct the model more efficiently.

The process of reducing a fault model to its nonredundant Boolean form requires first that the fault model be transformed into an algebraic expression as illustrated by the following example:



 $= x_1 x_1 x_2 + x_1 x_1 + x_1 x_2 x_3 + x_1 x_3$

COMPONENT TYPE CODE

Mechanical Components	
Code	Component
ТВ	Turbine
ፐር	Tubing
TK	Tank
TZ	Transmitter
VT	Vent
vv	Valve, relief
xv	Valve, manual
00	Event not involving component

Electrical Components

Code	Component
AM	Amplifier
AN	Annunciator
AS	Buffer
ВС	Battery charger
BS	Bus
вч	Battery
RE	Relay
CI.	Actuator controller
ČA	Cable
СВ	Circuit breaker
CC	Capacitor
CM	Comparator
CN	Converter
CT	Current transformer
DC	dc power supply
DE	Diode or rectifier
FU .	Fuse
GE	Generator
GS	Ground switch
	• •

(1)

The preceding algebraic expression contains "AND" and "OR" redundancies which can be removed by using the following idempotent relations:

Α	Α	=	A.	($(\bar{2})$)

$$A + A = A - (3)$$

$$A + AB = A (4)$$

By application of these relations to algebraic Expression (1), the model reduces to $A = X_1$. In this example, the analyst would not expand X_2 and X_3 into their respective causes of failure because the models represented by those variables would disappear in the end result.

9. COMMON MODE FAILURES

Single events that fail components in two or more redundant systems or subsystems are common mode failures. They are events which violate any assumptions of independence of redundant systems. Common mode failures can take the form of design or manufacturing defects which emerge as component failures in a common time frame; systematic human errors in the maintenance, testing, or operation of systems; or unexpected environmental or operational transients which result in multiple component failures.

TABLE IV (contd.)

COMPONENT TYPE CODE

Electrical Components	·
Code	Component
HG	Heating element
HT	Heat tracing
IV	Inverter
KS	Lockout switch
LA	Lightning arrester
LS	Limit switch
LT	Light
ME	Meter
MO '	Motor
MS	Motor starter
ND	Neutron detector
OL	Overload, thermal
OT	Transformer
PS ,	Pressure switch
PT	Potentiometer
QS	Torque switch
SW	Hand switch
TC	Temperature controller
· TF	Transmitter
TI	Timer
TM	Terminal board
WE	Wire
00	Event not involving component '

Before any attempt is made to search for common mode failures, the system fault tree, as constructed in Section IV-2, should be free of any single hardware or human events that result in system (or multisystem) failure because these failures tend to dominate over common mode event contributions. In other words, common mode events do not need to be identified if single component or human events clearly dominate the system probability of failure.

Common mode failures due to operational and environmental variables are usually identified in fault tree analysis by expanding component failure events into secondary causes for failure. That is, component failure events are expanded to show the potential failure mechanisms which exceed the design ratings of the components. For example, the event "Pipe 1A plugged" in Figure 8 might be expanded into possible causes for failure such as "Pipe 1A plugged due to freezing" or due to any number of possible causes depending on the imagination of the analyst. If, in this example, freezing can plug Pipe 1A and components in the redundant subsystem, freezing would be a potential common mode failure event. To expand the fault tree indiscriminately without some real basis for doing so, however, into secondary events can be extremely time consuming and costly.

The method proposed herein for treating single environmental causes for multiple component failures requires, first, that the analyst determine the location of each component identified by the fault tree analysis. The location is recorded in the column provided in the fault summary of Table VI. Next he

TABLE V
SECONDARY EVENT TYPE CODE

Code	Event
C	Freezing
D	Dust
E	Earthquake
F	Fire
Ğ	Wind
H	Humidity
K	Corrosion
M	Missile
P	High pressure
R	Radiation
S	Steam
T	High temperature
W	F1ood
X	Pipe whip or hammer
Z ^[a]	Proximity

[a] Z is a code used to indicate that redundant components, because of their close proximity, are subject to a large number of unknown secondary events not readily classified.

examines each component in its operating location to determine: first, whether any of the secondary events listed as column headings can occur in the component location; and, second, whether, if a secondary event can occur in that location, will the secondary event cause failure of the component. An estimate of the secondary event occurrence likelihood is shown in the upper half of the space provided in the fault summary and an estimate of the likelihood of the secondary event producing component failure is shown in the lower half of the space provided. These need only be order of magnitude probability estimates and are usually written -1, -2, -3, . . ., corresponding to probability values of 10^{-1} , 10^{-2} , 10^{-3} , . . ., respectively. The list of secondary events shown in the fault summary column headings is certainly not complete and should be expanded where appropriate.

Finally, if there are secondary events that have a relatively high likelihood of occurring and causing component failure, they should be named and treated as additional component failure events on the fault tree and on the fault summary. The product of these




Fig. 14 Required conditions incorporated as a direct input to AND gate.




Fig. 15 Required conditions incorporated as inverted inputs to AND gate.




Fig. 16 Classifying faults using the house.

two probabilities, likelihood of occurrence and likelihood of causing failure, should be large compared with other secondary events treated in the same manner. Typically, these events do not take on much significance unless the product is of the order of 10^{-6} and greater. The procedure for treating common modes can be illustrated by examining Table VI^[a]. Pipe IA might rupture due to an earthquake (probability of 10^{-3}), high pressure (10^{-2}), freezing (10^{-1}), missiles (10^{-2}), or pipe whip (10^{-1}). The likelihoods of these events occurring in the pipe tunnel are 10^{-8} , 10^{-8} , 10^{-9} , 10^{-8} , and 10^{-7} , respectively. The products of these probabilities are relatively low (10^{-11} , 10^{-10} , 10^{-10} , 10^{-10} , and 10^{-8}); therefore, they are relatively insignificant contributors. Relay 26A is subject to failure by fire (10^{-2}), dust (10^{-2}), or corrosion (10^{-3}). The likelihoods of fire, dust, and corrosion in Room 211 are 10^{-6} , 10^{-3} , and 10^{-5} , respectively. Dust, which has a combined likelihood of occurrence and causing failure of 10^{-5} , is potentially an important contribution to relay failure; therefore, a new event, "dust" with a code name D0000211, is entered in the fault summary. The code

[a] The values shown are for illustration purposes only and are not intended to be characteristic of ETR.

TABLE VI

COMMON MODE EVENTS ON FAULT SUMMARY

			PR	IMARY FAIL	URE	Γ					SEC	ON	DAR	Y EV	/ENT	(10	-×) *		_					
· EVENT NAME	EVENT COMPONENT	FAILURE MODE	FAILURE RATE	FAULT DURATION	ERROR FACTOR	FIRE	FLOOD	EARTHOUAKE	STEAM	ні темР	PRESSURE	HUMIDITIY	FREEZING	MISSILE	PIPE WHIP	WIND	DUST	RADIATION	CORPOSION	MEDUCED VOLI	SOLVENIT	COLUMN	LOCATION	REMARKS .
BPPOO1AR	Pipe 1A	Rupture	10-9	270	10	F	F	-8 -3			-8 -2	\Box	-9 -1	-8 -2		7		7	7	+	Ŧ	F	Pipe Tunnel	
BREO26A	Relay 26A	Doesn't Close	10-5	270	10	-6 -2	E				Е		\exists		\exists	1	-3 2	<u> </u>	5 3		\pm	+	Rm 211	
DOOOC2111	Dust		,	(New Ev	ent)						\exists					4	\exists	\pm	1	\pm	1	\pm	Rm 211	
			<u> </u>	<u> </u>				<u> </u>			H			\exists	=	\downarrow	\pm	\pm	1	\pm	+	\pm		
						-	E					ㅂ	\exists	_	\dashv	#	\downarrow	\pm	#	\pm	\pm	士		<u>.</u>
						L		\vdash			H		\exists		\rightrightarrows	1	\pm	\pm	\pm	\pm	#	\pm	1	
							E							\exists	\dashv	_	#	\pm	#	\pm	\pm	$^{\pm}$		
						L		上			H	H		=	⇉	\Rightarrow	\downarrow	\pm	#	士	‡	丰	_	
						E					H		\exists	⇉	⇉	\pm	\pm	\pm	\pm	\pm	\pm	\pm		
											H			\exists	\dashv	\pm	\pm	\pm	#	\pm	+	\pm		
		ļ				E							=	⇉	⇉	#	\downarrow	\pm	士	#	#	士	<u> </u>	
						E					Н			\exists	#	+	\pm	\pm	\pm	\pm	#	上		
	·					\vdash		\vdash			Н	ᆸ		╛	士	\pm	\pm	\pm	\pm	\pm	\pm	+		· · · · · · · · · · · · · · · · · · ·
		,				L	E				Н	\exists		╛	╛	\pm	\pm	\pm	\pm	\pm	\pm	\pm		
	<u> </u>					\vdash		E			Н	\exists	\exists	_	Ⅎ	\pm	\pm	\pm	\pm	\pm	\pm	\pm		1
					٠٠						H	\exists		\exists	╛	\pm	1	\pm	\pm	+	\pm	£	<u> </u>	
				,			E	_				\exists	\exists	\exists	1	\pm	-	\pm	\pm	\pm	\pm	\pm		
						Ŀ	_		\exists		Н	\exists	\exists	-	\pm	\pm	\pm	\pm	\pm	\pm	\pm	£		
				,									\exists	\exists	\exists	\pm	\pm	\pm	\pm	\pm	Ι			
								-			\square		\dashv	\exists	\exists	7	\pm	\pm	\pm	\pm	\pm	E	1	
						E		F			\Box		\exists	\exists	\exists	$\overline{\mathbf{J}}$	\pm	\mp	\pm	Ŧ	Ŧ	F		
]			F	F	F	\Box	\Box	Н	\dashv	\dashv	7	\dashv	7	Ŧ	Ŧ	Ŧ	Ŧ	Ŧ	F		

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

name is also listed on the fault tree under the tabulation OR gate where the failure modes of Relay 26A are shown. D0000211 is a unique identifier for "dust in Room 211". If in the process of applying this procedure to other components, and the event name D0000211 appears in other trees or subtrees representing redundant systems or subsystems, respectively, the event is a common mode event. That is, the event D0000211 would appropriately affect the nonredundant form of the Boolean expression resulting from one or more trees containing the event.

10. HUMAN ERRORS

Human errors are relatively high probability events; therefore, human intervention or human inputs to components are important contributions to the probability of system failure. Switches, valves, adjustment pots, and test plugs are only a few of the many components which are subject to normal human input. All potential human errors should be identified on the fault tree at the component where the human intervention takes place. For example, if the only place a valve can be operated is from a switch in the control room, the human error event would be associated with the switch in the control room and not the valve. If the valve can be operated remotely and locally, then the human error fault events should appear both places.

Human errors are generally classified as errors of commission and errors of omission^[1]. Errors of commission are those for which an operator or maintenance man will act inadvertently with a component of the system (for example, an operator throws the wrong switch or a maintenance man misadjusts a limit switch). Errors of omission are those for which the operator forgets to perform a required act (for example, fails to start pump). The type of human error should be clear in the fault statement. For example, the fault statement in the fault summary might read, "operator forgets to start Pump 1B" for an act of ommission, or "valve inadvertently closed" for an act of commission.

11. TEST AND MAINTENANCE

System outages due to tests and maintenance and the human errors which can accompany test and maintenance activities can be important contributors to the risks of nuclear plants. Most systems associated with test reactors are tested and maintenance is performed when the reactor is shut down; therefore, test and maintenance outage, as such, is not an important risk factor. However, where on-line testing and maintenance has been provided in the design, a system which is redundant can change to a nonredundant system during the time tests and maintenance are performed unless override features have also been provided in the design.

Outage due to test or maintenance is treated on the abbreviated fault model by showing an additional component fault event on the fault tree and on the fault summary for any subsystem or portion thereof which is unavailable during test and maintenance. Although not a fault in the strict sense of the word, outage is treated as a component fault

with a mode designation "test" or "maintenance" and a fault mode code designation "T". Unless each component is tested or maintained separately and at different times, only the component requiring the longest outage time is shown as a fault time. If each component is tested or maintained separately and at different times, each component should be treated as a test and maintenance fault.

If a valve or other component can be left in the wrong state as a result of a test or maintenance error, the fault is also shown on the fault tree and is treated as a human error as discussed in Section IV-10.

12. ANALYSIS STAGING

The abbreviated fault tree analysis described in the preceding section helps the analyst to stage the analysis effort. That is, he can determine the overall logic structure of complex systems and multiple systems first before performing a detailed examination of components within the system. Thus, staging allows the analyst to identify the more important, or critical, paths of the system without wasting time on details which may, in the end result, be unimportant. To stage the analysis, the analyst constructs the abbreviated fault tree without identifying the individual events normally listed under the tabulation OR gate. Instead, each tabulation OR is treated as a single component until the fault tree is reduced to its nonredundant Boolean form. Then, only those tabulation OR gates which appear as critical cut sets in the nonredundant Boolean form are expanded to include individual component events.

Caution should be exercised regarding the analysis staging just discussed: First, the tabulation OR gates must be independent of other tabulation OR gates (they should not contain common elements if expanded), and, second, reliance on the importance of tabulation OR gates resulting from staging can ignore potential significant common mode events among those individual component fault modes not included, particularly if the staging effort does not produce single component events that can result in system or multiple system failure. (In most cases single hardware and single human error events will dominate over the contribution by any common mode events.)

13. <u>DATA</u>

Once all basic fault events have been identified for a system, probability values are assigned to, or information is provided in order to calculate probability values for, individual event entries listed in the fault summary. Component failure probabilities are calculated from failure rates and appropriate time intervals (or cycles if the failure rate is cyclic). Component failure rates which are time dependent are usually expressed in failures per 10⁶ hours; component failure rates which are related to the number of times the component is operated are expressed in failures per 10⁶ cycles. For most standby systems a cyclic

component is usually called upon to operate once; therefore, the failure probability on demand is also the failure rate (1" is entered in the fault summary time column).

The time intervals used to calculate failure probabilities for components in nonoperating standby systems, typical of most safety systems, are the fault duration times. Usually this duration is the average time during which a fault can exist without being detected plus the time to repair the component when the system is required to stand by. If a component failure can only be detected by periodic tests, then the average fault duration time is one-half the test interval plus any time needed to repair the component. One hour is usually used as an arbitrary minimum in the calculation if the component status is continuously monitored. The repair time is the lesser of the times required to actually repair the component or to return the reactor to a state in which the system is no longer required.

Probability values for individual events shown on the fault summary pertaining to test or maintenance outage are determined by taking the accumulated total test or maintenance outage time and dividing by the time the system is required.

14. QUANTITATIVE EVALUATION OF FAULT MODELS

The evaluation of a fault model basically involves two steps: (a) qualitative analysis and (b) quantitative analysis.

Qualitative evaluation of fault models is the conversion of the failure logic to its nonredundant Boolean form. For any individual TOP event of concern, all sets of necessary and sufficient individual events that cause this TOP failure must be identified. Any set of necessary and sufficient events is called a minimal cut set. All failure modes of a TOP event of a system are completely described by the collection of all minimal cut sets. The computer codes now available, and which are receiving the greatest use for this type of qualitative evaluation, are PREP^[6] and MOCUS^[7].

The PREP computer code for determining minimal cut sets allows one of two different options, deterministic testing and Monte Carlo simulation. The deterministic testing in theory essentially checks all possible combinations of individual events to determine whether their failure will result in the TOP event. The Monte Carlo approach weights the individual events, thus accelerating the process of determining the minimal cut sets. However, with the Monte Carlo approach, the analyst can not be sure that all the minimal cut sets are identified.

The algorithm used in MOCUS to find the minimal cut sets starts with the TOP event failure and proceeds to the individual failures in order to determine the minimal cut sets. Basically, the MOCUS algorithm builds a matrix along the following lines: the fault model gates are randomly labeled with a value a_i and the individual events are randomly labeled with a value b_i ; the first element in the matrix is set to the value of a_i representing the gate immediately under the TOP failure. From this point on, the object is to eliminate all the

gate a values from the matrix such that only the b values for the individual events remain. Each row of the matrix is now a cut set. The rows are then searched to determine the minimal cut sets.

The inputs to both the PREP and MOCUS computer codes are compatible. For large component minimal cut sets, the MOCUS code requires much less computer execution time. Usually the smaller component cut sets consisting of possibly only one, two, or three individual events describe the majority of the failure modes quantitatively; therefore, either PREP or MOCUS may be used.

The qualitative analysis of the fault model thus provides the framework for the probabilistic or quantitative evaluation. With the modes of failure obtained from the qualitative analysis in the form of minimal cut sets and the reliability characteristics of individual events, the TOP event or system reliability characteristics can be calculated. The time-dependent failure rate or hazard rate and the fault duration time for each individual event completely describes the reliability characteristics necessary for the quantitative evaluation of the system. From these minimal cut sets, hazard rates, and fault duration times, the reliability characteristics associated with system failure or operation can be calculated. The computer codes now in greatest use to calculate these are KITT^[8] and SAMPLE^[1].

The KITT computer code is an application of Kinetic Tree Theory^[8] and calculates the complete spectrum of reliability characteristics. The SAMPLE computer code evaluates the unavailability for the fault model specified by the minimal cut sets and also calculates confidence limits for the unavailability.

The input-output for the PREP, MOCUS, and KITT computer codes are totally compatible. The previously mentioned computer codes are written in FORTRAN IV for the IBM 360/75 computer. The assumptions and limitations for each code are given in their documentation.

V. DEFINITIONS

- 1. Accident Initiating Event A parameter which enters a region where protective action is required in order to prevent an accident.
- 2. Fault An event which can, either by itself or in combination with other events, result in a system malfunction.
- 3. Failure A component or system fault which is nonreversible; that is, repair is required.
- 4. Common Mode Event An event originating within or external to a system that causes multiple component or system malfunctions.
- 5. Direct Input An event which, if it occurs, has a probability of unity of producing a failure.
- 6. Coupled Input An event which, if it occurs, has a probability less than unity of producing component failure.
- 7. Secondary Event An event which exceeds the design rating of a component.

VI. REFERENCES

- 1. Reactor Safety Study, An Assessment of Accident Risks in U.S. Commerical Nuclear Power Plants, WASH-1400 (August 1974).
- 2. K. V. Moore and W. H. Rettig, RELAP4, A Computer Program for Transient Thermal-Hydraulic Analysis, ANCR-1127 (December 1973).
- 3. M. L. Winton, Preliminary User's Manual for Revised Radiological Safety Analysis Computer Program (RSAC-2), ACI39 (June 1973).
- 4. W. L. Headington et al, Fault Tree Analysis of the PBF Transient Rod Drive System, IDO-17274 (November 1968).
- 5. D. F. Haasl, "Advanced Concepts in Fault Tree Analysis", Systems Safety Symposium, Seattle, Washington, June 8-9, 1965.
- 6. W. E. Vesely and R. E. Narum, PREP and KITT: Computer Codes for the Automatic Evaluation of a Fault Tree, IN-1349 (August 1970).
- 7. J. B. Fussell et al, MOCUS A Computer Program to Obtain Minimal Cut Sets from Fault Trees, ANCR-1156 (August 1974).
- 8. W. E. Vesely, "A Time-Dependent Methodology for Fault Tree Evaluation", *Nuc. Engr. and Design*, 13, 2 (August 1970).

THIS PAGE WAS INTENTIONALLY LEFT BLANK

APPENDÎX A

RISK ASSESSMENT OF ETR LOSS OF FLOW EVENT

THIS PAGE WAS INTENTIONALLY LEFT BLANK

APPENDIX A

RISK ASSESSMENT OF ETR LOSS OF FLOW EVENT

This appendix illustrates the risk assessment methodology by applying it to the Engineering Test Reactor (ETR) located at the Idaho National Engineering Laboratory. This assessment is done by progressing through the various steps of a risk assessment using a loss of forced flow as an example accident initiating event.

1. DISCUSSION OF ETR

The ETR was completed in 1957 to fulfill a demand for more and larger facilities to provide higher neutron fluxes and more spaces for larger samples than existed in previous test reactors. Its purpose is to expose samples of reactor fuels, coolants, and structural materials to intense neutron fluxes produced in or near the reactor core. The samples are then studied to determine possible changes in their material properties. Items that are irradiated in the reactor typically include comparatively large reactor components proposed for use in other military, commercial, or research reactors. When tested, these components are inserted directly in spaces provided in the core region or in dynamic loops, that is, closed systems in which a coolant circulates around the experiment at flows, temperatures, and pressures that are independent of coolant in the reactor.

The design power level of the ETR is 175 thermal megawatts. The reactor is capable of producing a maximum thermal neutron flux of $8 \times 10^{14} \frac{n}{\text{cm}^2\text{-sec}}$ and a maximum above-thermal neutron flux of $2.5 \times 10^{15} \frac{n}{\text{cm}^2\text{-sec}}$. Figure A-1 is a simplified diagram of the ETR.

Recently the ETR has undergone major modifications to accept the Sodium Loop Safety Facility (SLSF). One of the purposes of this experiment is to study the characteristics of fuel element failure propagation in a fuel bundle cooled by liquid sodium as the primary coolant and helium gas as the secondary coolant.

In preparation for ETR operation with the sodium loop, the instrumentation associated with reactor control and the plant protection system has been improved. In general, the improvement consists of the replacement of much of the older vacuum tube circuitry and mechanical relays with integrated circuitry and other more reliable devices. The SLSF installation has its own plant protection system whose function is to shut the reactor down in the event experimental variables exceed predefined limits.




Fig. A-1 Simplified diagram of ETR.

2. OVERVIEW OF DISCUSSION

The first task considered in the sample risk assessment was to identify all accident initiating events that might occur which could, in the absence of mitigating action, lead to uncontrolled release of fission products. This accident initiating event identification analysis is illustrated in Section 3. The loss of flow accident is discussed in Section 4. Event tree sequence probabilities were obtained by the evaluation of individual systems which appear in the sequences. These individual systems evaluations are covered in Section 5 and are combined for sequences in Section 6. Sections 7 and 8 discuss the analysis needed to determine the core damage and consequences resulting from each loss of flow sequence. Finally, the results of the risk assessment are discussed in Section 9.

3. IDENTIFICATION OF ACCIDENT INITIATING EVENTS

The procedure described in the report has been used to identify the accident initiating events for the ETR. The study is not complete but has been developed as far as necessary to illustrate the procedure described in the report. The example considers only the events that would lead to radioactivity releases to the atmosphere. Other energy releases (for example, steam) were not considered. The top level fault tree showing the logic for the accident initiating events is shown in-Figure A-2.

3.1 Undesired Radiological Release

A broad statement for the top event of the fault tree was selected so that the undesired radiological release would include all levels of release. The top event, then, contains a statement about all possible releases of radioactivity from the ETR.

3.2 Release Sources

All sources of radioactive material at the ETR are shown at the next level of the fault tree. A release from any one of these sources would result in the undesired radiological release stated in the top event of the fault tree. Because the ETR is one of several reactors in the Test Reactor Facility, some storage locations are shared with other reactors. The fault tree includes all sources associated with the ETR even though shared with other reactors.

The identification of all sources was helped by a review of a nuclear material accountability list in an unpublished monthly report. This report identifies the type, amount, and location of radioactive material for most of the sources listed on the fault tree. Other sources were found by a review of the operating system of ETR.




Fig. A-2 ETR accident initiating events fault tree.

3.3 Switches for Release Magnitudes

Because the top event does not specify a specific release magnitude, all levels of release are included on the tree. The potential magnitude of release from each source has been assigned as high, medium, or low. If a study of a specific release magnitude were to be desired, the tree below the desired magnitude statements would be included. For this example study, the tree for a release from the reactor core is the only one developed. Each fault in the diamond symbols would be further developed for a complete study. The switch function of the house symbol was explained in the methodology section in the body of this report (Section IV-7).

3.4 Switches for Operating States

When the operating state of the reactor will affect the radiological release, switches are provided so that the state under consideration can be analyzed. For this example, only the state when the reactor is operating has been developed.

3.5 Barriers Preventing Release

All sources of radioactive material are prevented from release by one or more physical barriers. The barriers that have to be penetrated before radioactivity is released from the fuel in the core are the fuel cladding and the primary cooling system. Both barriers have to be penetrated. The radioactive material in the core is not released if contained by either one.

3.6 Barrier Failure Mechanisms

The next level of the fault tree lists all mechanisms that can cause failure of the barriers. The failure of the primary cooling system has not been developed in this example but would include all ruptures of primary system pipe, valves, pumps, . . ., or the reactor vessel.

All conceivable mechanisms that can cause failure of the fuel cladding are listed at this level. Of these, only the failure caused by high fuel temperature is developed for this example. High fuel temperature can be brought about by two general categories of failure: (a) heat generation in the fuel that exceeds the maximum cooling capacity of the cooling system, and (b) reduced primary cooling system capacity.

3.7 Accident Initiating Events

The events that can bring about the two general categories of failure previously identified are considered to be accident initiating events. Should any of these events occur, reactor protection systems are required to respond to prevent the release of radioactive material from one or both of the physical barriers. Further study of the events will lead to an investigation of all hardware in the reactor systems that can, alone or in combination with other events, fail and cause a release. This investigation will be done by a systems analysis as described in Section 5 of the report. For completeness, the list has been

reviewed by individuals knowledgeable of the ETR systems and their operation. The loss of coolant flow accident will be developed as an example.

4. LOSS OF FLOW ACCIDENT

An event which causes loss of coolant flow through the reactor is considered important because it jeopardizes the integrity of the fuel cladding. That is, fuel cladding temperatures can occur which result in melting of the cladding and, ultimately, to release of radioactivity to the atmosphere. The reactor, when operating at power, is a source of considerable heat which must be constantly dissipated by the flow of large volumes of water through the flow passages in the core. Under normal operation, this flow is controlled at about 43,000 gallons per minute, with a reactor vessel inlet temperature of about 120°F. The outlet water temperature is maintained at about 135°F. Upon loss of flow and no soram, the system temperatures will increase to a point at which coolant voiding occurs at the cladding surfaces. The cladding temperatures then commence to rise rapidly to a point (about 1,200°F) at which fuel cladding melting occurs.

Upon loss of flow, the plant protective system and the emergency flow system respond to shut the reactor down and to provide for minimum circulation of coolant, respectively. The plant protective system responds upon (a) low or high differential pressure across the reactor, (b) reactor low inlet-to-outlet pressure, or (c) low flow to cause rapid insertion of all poison control rods into the core. The emergency flow system responds (one of the two pumps is always running when the reactor is operating) to cause a minimum of coolant circulation through the core.

The event tree for the loss of forced flow accident in the ETR is shown in Figure A-3. The event tree is explained as follows:

(1) The ETR event tree starts with the assumption of complete loss of forced primary coolant flow through the reactor with a probability of occurrence of P₁. The first event node, second column, has two branches that represent whether or not the automatic reactor shutdown system is available to scram the reactor. A probability of P₂ that the system is not available (lower branch) to shut down the reactor and a probability of (1-P₂) that it is available to shut down the reactor (upper branch) are assigned.

If the PPS fails to respond, and the reactor continues to operate at power with no flow of coolant, melting will occur. (The reactor will produce fission heat until sufficient coolant voiding occurs to terminate the fission process.) The probability of this series of events, S_3 , is $P_1 \times P_2$ (provided P_1 and P_2 are independent).




Fig. A-3 Event tree for loss of flow event.

- for loss of flow avent
- (2) The second event node, third column, is the availability of the emergency flow pumps for operation. Either of the two pumps will supply sufficient coolant for a short period of time to prevent voiding after a loss of flow, where one pump is capable of providing 2,000 gpm coolant flow. The probability of emergency flow unavailability is designated P₃; the availability is (1-P₃). The sequence probability cannot be determined by a direct calculation of the individual probabilities because the probability values are not independent.
- (3) Each sequence shown on the event tree produces a consequence which when multiplied by the preceding sequence probabilities produces risk values for the loss of flow event.

5. SYSTEMS ANALYSIS

The analysis of the loss of coolant flow accident, selected as the accident initiating event for this study, requires an evaluation of the primary coolant system, to determine how it functions, and to identify those malfunctions of the system that could initiate a loss-of-flow accident.

5.1 Primary Coolant System

The primary coolant system removes heat from the reactor core and rejects it to a secondary coolant system which, in turn, dumps it to the atmosphere through cooling towers. A number of accident initiating events can stem from the primary coolant system,

for example, loss of coolant, loss of coolant flow, loss of primary system pressure, insufficient heat rejection to the secondary system, . . ., none of which is independent. In this example risk evaluation, determining the probability and potential consequences of the loss of flow event is the only concern, and particularly in this section to determine the probability that a loss of flow will occur at the ETR of sufficient duration to demand a response by the plant protection and auxiliary flow systems.

5.1.1 System Description. The primary coolant system is comprised of the reactor vessel, pumps, valves, heat exchangers, and piping arranged as shown in the simplified diagram, Figure A-4. Coolant flow through the reactor core is maintained at the desired level by series Control Valve P-8 for coarse control, and bypass Control Valve PCV-4-4 for fine control. Flow is controlled on differential pressure across the reactor and outlet coolant temperature. Control Valve P-8 is equipped with mechanical stops which prevent closure beyond 45 degrees. Control Valve PCV-4-4, if completely open, will not permit sufficient bypass flow to prevent removal of decay heat with an emergency flow pump (2,000 gpm) operating. Three of four primary coolant pumps will be used for the SLSF tests.

The temperature of the coolant (about 135°F exit temperature at ≤177 psig during operation) is sufficiently low at all pressures above atmospheric that a break in one of the primary coolant pipes will not uncover the core. Also, the elevation of the piping which enters the vessel is sufficiently high to prevent draining, and sufficient bypass exists internal to the vessel to prevent any siphoning of water from the vessel in the event of a primary coolant pipe break.

Primary system pressure is maintained at 177 psig by a degassing system which constantly removes coolant from the primary coolant system and, after removing any gas, returns it to the primary system at a constant 177 psig. A surge tank is provided to absorb any transients which may occur in the system. A fraction of the primary system flow is circulated through a demineralizer for removing impurities and maintaining a desired pH. Relief valves are located on the input manifold of each of the four heat exchanger banks.

- 5.1.2 System Analysis. The primary coolant system was evaluated to identify all events related to the system and dependent systems that could result in loss of forced flow. Any loss of flow was considered whether affecting a part of the core or the entire core. That portion of the electrical power distribution system which supplies power to the primary coolant system was also included in the analysis.
 - (1) <u>Assumptions</u>. For the purposes of the analysis the following assumptions were made and ground rules were established:
 - (a) The loss of flow accident occurs when the reactor is operating, and any three of four primary coolant pumps are sufficient and necessary for core cooling.




Fig. A-4, ETR primary coolant system - simplified flow diagram.

- (b) The nature of the faults produces loss of flow but does not necessarily result in other initiating events; that is, it does not depressurize the system or does not uncover the core (The fault tree developed for the system, however, identifies numerous events that can result in more than just loss of flow.).
- (c) Once loss of flow occurs, flow is not restored; that is, the sequences on the event tree are carried to completion. For example, a valve failure could not be repaired in time to prevent the course of an accident initiating event as described by the event tree.
- (d) The only responses to the accident initiating event are those described by the event tree.
- (e) An operating time for the reactor is 720 hours.
- Fault Tree and Fault Summary. The fault tree and fault (2) summary developed for the loss of flow event at the ETR are shown in Figure A-5 and Table A-I, respectively. Since the primary system is a normally operating system (as opposed to an engineered safety system), numerous single events can occur that would result in loss of flow. The fault tree identifies a number of component ruptures that could result in loss of flow. These ruptures, should they occur, would require a response by the core deluge system rather than the emergency flow system as shown on the event tree. That is, a separate event tree would be required to reflect the possible sequences resulting from a loss of flow caused by component ruptures. The rupture events, if included, however, would not alter the quantitative results because the rupture probabilities are small compared with loss of pumping power and human error events identified in the analysis.

Data shown in the fault summary, as is the case with other systems analyzed in this sample risk assessment, were extracted from the Reactor Safety Study [A-1].

- (3) <u>Drawings</u>. Engineering drawings were used in the analysis of the primary coolant system. The simplified sketch shown in Figure A-4 was taken from the drawings.
- (4) Data. Failure data used in the evaluation were those contained in WASH-1400^[A-1].




Fig. A-5 ETR loss of forced flow.




Fig. A-5 ETR loss of forced flow (contd.):




Fig. A-5 ETR loss of forced flow (contd.).




Fig. A-5 ETR loss of forced flow (contd.).

TABLE A-I

LOSS OF PRIMARY FLOW

ĺ			,	RIMARY FAILU	RE	Ι .						SEC	ONDA	RY F	VENT	116	- 2 , 4								<u> </u>
EVENT BWAN,	EVENT COMPONENT	FAILURE MODE	FAILURE RATE	FAULT DURATION	ERROR Factor	FIRE	2000	EARTHQUAKE	STEAM	HI-TEMP.	PRESSURE	HUMIDITY	FREEZING	BISSILE	WHIP	Q. I	1500		CURRUSIUR	INDUCED VOLT	VIBBATION	SOLVENT		LOCATION	REMARKS
DPP0001R	PIPE P-1	RUPTURE	10-10	720	30 /	H	1	4	4	4	_			\exists	4	7	1	7	7	\exists	_		\Box	PIPE TUNNEL	
DPFOOOLP	PIPE P-1	PLUGGED	10-8	720	300	\blacksquare			7	-				\dashv	\dashv	\dashv	-	\exists	\exists					PIPE TUNNEL	
DPF0003R	PIPE P-3	RUPTURE	10-10	720	30	Н		\exists	-							\exists			\exists					PIPE TUNNEL	
DXVOOP3R	MANUAL VALVE P-3	RUPTURE	10-8	720	10			\dashv	\dashv		\exists			╛	1			\exists	╛				П	PIPE TUNNEL	
DXVGOP4R	MANUAL VALVE P-4	RUPTURE	10-8	720	10				\dashv				=	=	#	\perp			\exists					PIPE TUNNEL	
DAVPCV4R	PNEUMATIC CONTROL VALVE PCV4	RUPTURE	10-8	720	10 -	Н	\dashv	#	\dashv	=	#			#	=	#	+	_		〓				PIPE TUNNEL PIPE	
DPPOCC2R	PIPE P-2	RUPTURE	10-10	720	30		#	-	_		#		4	4	_	#	\dashv	\dashv	#					TUNNEL PIPE	
DPPO002F	PIPE P-2	PLUGGED	10-10	720	300		4	7	7	7	#	\exists		7	#	7	7		7	\dashv		\equiv		TUNNEL PIPE	
DXVOOP5R	MANUAL VALVE P-5	RUPTURE	10-8	720	10			4	4	\dashv	4	\dashv	\dashv	\dashv	-	7	7	7	7	\dashv	_			TUNNEL PIPE	
DXV00P6R	MANUAL VALVE P-6 BUTTERFLY CONTROL	RUPTURE	10 ⁻⁸	720	10	\Box	\dashv	7	\exists	\exists	\exists	\exists	\dashv	\dashv	-	7	7	\dashv	7	\dashv				TUNNEL PIPE	
DMVCOPER	VALVE P-8 BUTTERFLY CONTROL	RUPTURE	10-8	720	10			-	\exists	-	\exists			\exists	\exists				\exists					TUNNEL PIPE	<u>-</u> -
DMVGCP8P	VALVE P-8 BUTTERFLY CONTROL	PLUGGED FAILS	10 ⁻⁸	720	300		\exists	\exists	\exists						\exists									TUNNEL PIPE	<u> </u>
DMV00P8C	VALVE P-8	CLOSED	10 ⁻⁸	720	300		\exists	=	#						\dashv	\exists			\exists		_			TUNNEL EXCHANGE BLDG.	
DPP0008P	PIPE P-8 PIPE P-8	RUPTURE PLUGGED	10 -10	720	10	_	\exists	\dashv	=		\dashv				\dashv	4	1	1						BLDG. HEAT EXCHANGE ELDG.	
DMVOP11R	MOTOR OPERATED VALVE P11	RUPTURE	10-8	720 720	300	<u>-6</u>	4	_	_		_				1	_					_			COMPRESSOR BLDG.	
DAVOP11C	MOTOR OPERATED VALVE P11	CLOSES	10-4	720	30	-6		\dashv	7		\dashv				\dashv	\exists	4	7	\dashv					COMPRESSOR BLDG.	
DPP0009R	PIPE P-9	RUPTURE	10 10	720	30	Ħ	H		\dashv	\dashv					- <u>5</u>	\dashv		7		\dashv				PUMP CUBICLE	
DPPCO1OR	PIPE P-10	RUPTURE	10-10	720	30	Н	H	\exists	\exists			_			5	-	-	_					_	PUMP CUBICLE	
DCVOP16R	CHECK VALVE P16	RUPTURE	10-8	720	100	\vdash			\exists						5	\exists	\exists	\exists	•					COBICLE PUMP	
DMVOP11P	MOTOR OPERATED VALVE P-11	PLUGGED	10-7	1	300	Е			\exists															PIPE TUNNEL	
DPP0009P	PIPE P-9	PLUGGED	10-7	_1	300	E		_	\exists	\exists		٢			5	\exists	_[PUMP CUBICLE	

*PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

TABLE A-I (contd.)

LOSS OF PRIMARY FLOW

	····		Pi	RIMARY FAILU	RE	<u> </u>					SC	CONCA	RY E	ENT (10-1	,*							•
EVENT NAME	EVENT COMPONENT	. FAILURE MDDE	FAILURE RATE	FAULT DURATION	ERROR Factor	FIRE	FARTHOUALF	SIFAE	HI-TEMP	PRESSURE	WINNIBITY	FREEZING	Ì	PIPE WHIP		11 ON	CORROSION	INDUCED VOLT.	VIBRATION	SOLVENT		LOCATION	REMARAS
DPPOOLOP	PIPE P-10	PŁUGGEE	10 ⁻⁷	1	300		+	Ŧ		H				5	+	Ŧ	F			П	\dashv	PUMP CUBICLE	<u> </u>
DCVOP16P	CHECK VALVE P16	RUPTURE	10-8	720	100	H	+	+	F			П	F	5 2	\mp	F	F	F		П	\exists	PUMP CUBICLE	
DPMOOBF	PUMP B	NO TUTTUC	10-5	720	10	H	Ŧ	+	 			П		5	F	F				Н	\dashv	PUMP CUBICLE	
DPMOOBR	PUMP B	RUPTURE	10 ⁻⁸	720	100		1	╄		H		H	-r	5 2	Ŧ	Ŧ	F			П	\dashv	PUMP CUPICLE	
DPMOOOBP	PUMP B	PLUGGED	10-6	1	100	H	+	-	<u>†</u>			H	T	5	╪	Ŧ		H		\square	\dashv	PUMP	
DPP0011R	PIPE 11	R:JPTURE	10-10	720	30	H	F	-	:		_	H	7	-	Ŧ	Ŧ	F	F		П	\dashv	EXCHAZGE	
DCVOP29R	CHECK VALVE P29	RUPTURE	10-8	720	10	H	#	+	+			П	\dashv	7	Ŧ	+	H	F		\Box	\exists	PIPE TURNEL	
DCVOP29C	CHECK VALVE P29	CLOSES	10-7	720	30	H	Ŧ	\mp	F		_	H		#	+	-	-	_		Н	\dashv	PIPE TURNEL	
DPF0011P	PIPE P11	PLUGGED	10-10	1	300	H	Ŧ	+	1			П	7	+	Ŧ	Ŧ	L			Н	4	EXCHANGE	
DPPCOllR	PIPE P12	RUPTURE	10-10	720	10	H	#	#	Ë			\square	\dashv		-	-	-	<u> </u>		П	\exists	EXCHANGE EXCHANGE EXCHANGE	
DCVOP30R	CHECK VALVE P36	RJPTURE	10-8	720	10	H	7	+	-			П	7	╬	╀	F	-	H		П		EXCHANGE BLDG.	
DCVOP30C	CHÉCK VALVE P30	CLOSES	10-7	720	30	H	Ŧ	+	-		_		_	+	#	F	F	F	F	П	=	P_PE TUNNEL	
DCVOP17C	CHECK VALVE P17	CLOSES	10 ⁻⁷	720	30	H	+	╪					7	5	Ŧ	F	F	F		П	\Box	PUMP CUBICLE	
DPMOOOBF	PUMP B	INS JEFT CLEAT	10 ⁻⁵	720	1p	H	+	Ŧ	F	F		П		5 2	\mp	+	H				4	PUMP CUBICLE	***
DPMOOOBR	PUMP B	RJPTURE	10-8	720	100	H	+	-	F		F	Н	\dashv	5 2	-	F	H	H		П	\exists	PUMP CUBICLE	
ДРМОООВР	PUMP B	P'_UGGED	10-6	1	100	H	+	÷	F		F	П		5	+	F	\vdash			П	\dashv	CUBICLE	
DHEDO12P	HEAT EXCHANGED 12	PLUGGED	10-8	1	300	H	Ŧ	Ŧ	F	H	 			_	\mp	-	-	_		П	\exists	EXCHANGE BLCC.	
DHEOO12R	HEAT EXCHANGED 12	RJPTURE	10-6	720	100	H	Ŧ	Ŧ	-	\Box	-	H	H	\mp	\mp	Ŧ	F		_	П		ELDG. HEAT EXCHANGE EXCHANGE EXCHANGE EXCHANGE EXCHANGE EXCHANGE EXCHANGE	
DHEOO13P	HEAT EXCHANGED 13	P_UGGED	10-6	1	300	H	\mp	\mp	\vdash	П	F	H	7	+	+	+	-	-	-	H	\dashv	EXCHANGE BLOC.	
DHEOO13R	HEAT EXCHANGED 13	RUPTURE	10-6	720	100	H	+	Ŧ	F	F	\vdash	H	7	-	\top	\mp	-	-		\sqcap	4	EXCHANGE BLDG.	
DHEO014P	HEAT EXCHANGED 14	PLUGGED	10-8	1	300	H	Ŧ	+	+-			H	H	\pm	Ŧ	F	F	-	_	П	4	EXCHANGE	
DHEO014R	HEAT EXCHANGER 14	RIPTURE	10 6	720	100	H	\top	\mp				П	\Box	\mp	+	\perp	\vdash	F		П	\dashv	EXCHANCE	

^{*}PROBABILITY OF SECONDARY EVENT OCCUPRING (UPPER NUMBER)

PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

TABLE A-I (contd.)

LOSS OF PRIMARY FLOW

	EVENT -COMPONENT	FAILURE MODE	PRIMARY FAILURE				SECONDARY EVENT (10 - 4)*															· · · · · · · · · · · · · · · · · · ·		
EVENT NAME			FAILURE RATE	FAULT DURATION	ERROR Factor	FIRE	f L000	EARTHQUAKE	STEAM	HI-TEMP.	PRESSURE	HUMIDITY	١	16	# KID		ļ		2010000	INDUCED FOLD	VIBRATION	SOLVENT	LOCAT JÖN	REMARKS
DPP0013P	PIPE 13	PLUGGED	10-7	1	300		_				\Box				5	+	7	7	+	7	7	+	PUMP	
DCVOP15P	CHECK VALVE 15	PLUGGED ·	10-7	. 1	300					_		-		[-	5 2	+	\pm	\pm	Ŧ	+		\perp	PUMP	
DPM000CF	PUMP. C	NO OUTPUT	10-5	720	10	L	E						\Box		5	1	\pm	1	+	\pm		1	PUMP	·
DPM000CR	PUMP C	RUPTURE	10-8	720	100	-						_		7-	5	+	\pm	1	\pm	\pm			PUMP CUBICLE	
DPMOOOCP	PUMP C	PLUGGED	10-6	1	100	_					H	_		_	5	\pm	\pm	÷	\pm	+		\pm	PUMP CUBTCLE	
DPP0014R	PIPE 14	RUPTURE	10-10	720	30	\vdash	E						H	1	5	\pm	1	+	1	#	1	1	PUMP	
DCVCP15C	CHECK VALVE 15	CLOSES	10-7	1	300				$\overline{}$						5	1	\pm	1	\pm	+		\pm	PUMP CUBICLE	
DHEOOC6P	HEAT EXCHANGER	PLUGGED	10-8	1	300	L								_	\pm	\pm	\pm	1	\pm	\pm		+	HEAT EXCHANGE	
DHEOGO6R	HEAT EXCHANGER	RUPTURE	10-6	720	100	L									\pm	1	\pm	\pm	\pm	+		\pm	EXCHANGE BLDG.	· · · · · · · · · · · · · · · · · · ·
DH20007P	HEAT EXCHANGER	PLUGGED	10-8	1	300	L								\pm	\pm	\pm	\pm	\pm	\pm	1	_	\pm	EXCENTRE	
DHE0007R	HEAT EXCHANGER	RUPTURE	10-6	720	100	E	E							\pm	\pm	\pm	+	1	1	+	_	1	HEAT EXCHANGE HEAT	,
DHEOOC8P	HEAT EXCHANGER	PLUGGED	10-8	1	300	L	1							\dashv	\pm	\pm	+	\pm	\pm	1		\pm	EXCHANGE HEAT EXCHANGE BLDG.	
DHEOCO8R	HEAT EXCHANGER	RUPTURE	10-6	720	100	L			_					_	\pm	#	1	-	#	#		1	EXCHANGE	
DMVOP12R	MOTOR OPERATED VALVE P12	RUPTURE	-10-8	720	100	L	<u> </u>							_	\pm	#	†		1	#		#	PIPE TUNNEL	
DMVCP11R	MOTOR OPERATED VALVE P11	RUPTURE	10-8	720	100	F	t			_				۵,		#	†		1	#		\perp	PIPE TUNNEL	
DCVOP16C	CHECK VALVE P16	· CLOSES	10-7	1	300		‡							\Rightarrow	2	1	#		#	#		#	PUMP CUBICLE	
DHEOOO9F	HEAT EXCHANGER 9	PLUGGED	10-8	1	300		‡_				Ħ			#	\pm	#	#		\pm	#		_	EXCHANGE BLDG. EXCHANGE BLDG.	
DHECCO9R	HEAT EXCHANGER 9	RUPTURE	10-6	720	_100	E	1	二						\rightrightarrows	#	#	‡	_	#	\Rightarrow		1	EXCHANGE BLDG.	
DHECOLOP	HEAT FYCHANGER 10	PLUGGED	10-8	_11	300	F	1				H			#	#	$^{+}$	\downarrow		\pm	1		\Rightarrow	EXCILATGE HEAT	
DHECO1OR	HEAT EXCHANGER 10	RUPTURE	10-6	1720	100	Ļ	+	二					H	\Rightarrow	\pm	#	†		#	#		#	HEAT EXCHANGE BLCG.	
DHEO011P	HEAT EXCHANGER 11	PLUGGED	10-8	1	300	F	上			Ŀ	\Box		H	\dashv	\pm	\pm	#		\pm	7	╛	\pm	EXCHANGE HEAT	
DHE0011R	HEAT EXCHANGER 11	RUPTURE	10-6	720	100	\vdash	上						Ц	士	士	_	\pm	1	+	\pm		\pm	EXCHANGE BLEG.	1

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)

PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

TABLE A-I (contd.)

LOSS OF PRIMARY FLOW

	\	<u> </u>	PI	RIMARY FAILU	RE							56	CONE	V3 YFA	ENT (1	0	*							-
EVENT NAME	EVENT COMPONENT	FAILJRE Mo: E	FAILURE RATE	FAULT OURATION	ERAOR Factor	FIRE	FLOOD	EARTHQUAKE	STEAN	HI-TEMP	PRESSURE	KUMIDITY		ָ ֖֖֭֭֓֞֝֞֝֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓	WIND WILL	0081	RADIATION	CORROSION	HOUCED VOLF.	VIBRATION	SOLVENT		LOCATION	REWARKS
DMVOP12R'	MOTOR OPERATED VALVE 12	RUPTURE	10-8	720	100	F			4	_					_	F	F	_			4		COMPRESSOR BLDG.	
DMVOPIOR	MOTOR OPERATED VALVE P10	RUPTURE	10-8	720	100	F	Н		\dashv			F		1	+		ļ.	F	-		\dashv		COMPRESSOR BLDG.	
DMVOP10C	MOTOR OPERATED VALVE P10	CLCSED	10-4	720	30	\vdash			\exists							H			I				COMPRESSOR BLDG.	
DPP0012R	PIPE 12	RUPTURE	10-10	720	10	\vdash						L		j-;	2		L						PUMP CUBICLE	
DPPOOL3R	PIPE 13	RUPTURE	10-10	720	10	L			1						2					\exists			PUMP CUBICLE REAT	•
DCVOP15R	PIPE 15	RUPTEJRE	10-10	720	10							_			\pm					\exists			EXCHANGE BLDC	_
DMVGP10P	MOTOR OPERATED VALVE P10	PLUGGED	10-7		300	┢		\dashv	#					H	\pm				H	\exists		\exists	COMPRESSOR BLDG.	
DPP0012P	PIPE 12	PLUGGED	10-7	_ i	300							_		<u></u>	+							\exists	PUMP CUBICLE PUMP	
DFPOO09R	PIPE P-9	RUPTURE	10-10	720	30			\exists	4						2		<u> </u>			\exists		=	CUPICLE	
DPP0009P	PIPE P-9 MOTOR OPERATED	PLUGGED	10-8	720	300			\rightrightarrows	#				E			È	<u> </u>	=					PUMP CUBICLE:	
DMVOP12R	VALVE P-12 MOTOR OPERATED	RUPTURED	10-8	720	100				_						+	Ħ							COMPRESSOR BLDG. COMPRESSOR	
DMVOP12C	VALVE P-12	CLCSES	10-4	720	30	F		\equiv	7		_	_	=	Ħ	#	F	L		Ħ				BLDG. EXCLANGE	
DPP0006R	PIPE P-6	RUPTURE	10-10	720	30		H	\exists	4				-		_	-	F	F			7	_	EXCHANGE BLDG. HEAT EXCHANGE	
DPP0007R	PIPE P-7	RUPTURE	10-10	720	30		Н	\dashv		-			F	-	5	F			H	4			BLDG. PUMP	
DCVCP17R	CHECK VALVE P-1* MOTOR OPERATED	RUPTURE	10-8	720	100	F	\Box	\dashv	\dashv	-			F		2	Ι	F	F	H	\dashv	\dashv	\exists	CUBICLE COMPRESSOR	
DMVCP12P	VALVE P-12 MOTOR OPERATED	PLUGGED	10 ⁻⁷	1	300	E	\square	\exists	\dashv	_			F	H	+	F	H	-					BLDG. COMPRESSOR	
DMVOP12R	VALVE P-12	RUPTURE	10 ⁻⁸	.720	100	E								<u> </u>	5	L	L				\exists	Ξ	BLDG. PUMP	-
DPPCCO6P	FIFE P-6	PLUGGED	10 ⁻⁷	720	300	E									2	E	E	E					CUBICLE EXCENSES	
DPP0007P	PIPE P-7	PLUGGED	10 ⁻⁷	720	300			oxed	_							E		E	Н	\exists		_	PUMP	
DCVOP17P	CHECK VALVE P-17	PLUGGED INSUFFICIEN	10 ⁻⁷	1	300	\perp	\exists	\boxminus								E	E						CUBICL ?	-
DPMOODAR	PUMP A	OUTPUT	10 ⁻⁵	720	10	L	H																PUMP	
DPM000AR	PUMP A	RUPTURE	10 ⁻⁸	720	100	بَـــــــــــــــــــــــــــــــــــــ	\Box	L_I	$_{\perp}$						2				Ш				CUBICLE	

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

			Pi	INARY FAILU	RE	L.,				_		SEC	ONDAF	RY EVE	NT (1	0.1)	*	_	_				
THEVE	EVENT COMPONENT .	FAILURE MODE	FAILURE RATE	FAULT DURATION	ERROR Factor	FIRE	FL000	EARTHOUASE	STEAM	HI-TEMP	PRESSURE	NUMIDITY	FREEZING	PIPE WHIP		1500	RADIATION	CORROSION	IMDUCED VOLT	VIBRATION	SOLVENT	LOCATION	BE NAR KS
	MOTOR OPERATED	T	-8										1	上							\Box	PIPE	
DMVOPO9R	VALVE P9	RUPTURE	10-8	720	100	\vdash				4	-	4	4		┿	┞	╙		\Box	_	_	TUNNEL	
DMVOP28P	MOTOR OPERATED VALVE P28	RUPTURE	10-8	.720	100	H							\pm	土	E	\vdash						TUNNEL	
DMVOP27R	MOTOR OPERATED VALVE P27	RUPTURE	10-8	720	100	H	\dashv	\dashv	\dashv	\dashv	+	\dashv	+	+	\vdash					\exists	\dashv	PIPE TUNNEL	
DMVOP25R	MOTOR OPERATED VALVE P25	RUPTURE	10 ⁻⁸	720	100	\Box	4		_	\exists	4	4	_	\mp	F	F					=	PIPE TUNNEL	
DMVOPO9R	MOTOR OPERATED VALVE P-9	RUPTURE	10 ⁻⁸	720	100	П	1		_				\dashv	#	1						_	PIPE TUNNEL	
-	OPERATOR ERROR	INADVERTENT	10-3			Ħ				_	1	7	#	_	#	L						COMPRESSOE	
DM/JOP10X	MOV P-10 MOTOR OPERATED	CLOSURE		1	100	Н	\exists			\exists	\exists		-	+								BLDG. PIPE	
DMVOP26C	VALVE P26 OPERATOR ERROR	CLOSES INADVERTENT	10 ⁻⁴	720	30	П	\dashv	\dashv		\dashv	_	4	-	Ŧ	\vdash	F	F	F				TUNNEL	
DMVOP26X	VALVE P26	CLOSURE	10-3	1	100	H	\exists		\exists		\dashv		\Rightarrow		+	L					\Box	BLDG.	
DPP0015R	PIPE 15	RUPTURE	10-10	720	30	Н			_		╛				+							PIPE TUNNEL	
DPP0016K	PIPE 16	RUPTURE	₁₀ -10	720	30	Н	\dashv	\dashv	\dashv	\dashv	\dashv	\dashv	\dashv	- 5		-	-	\vdash	\vdash		\dashv	CUBICLE	
DCVOP14R	CHECK VALVE P14	RUPTURE	10-8	720	100	H	\dashv	_	4	4	4		7	-5		\vdash		<u> </u>			\Box	PUMP . CUBICLE	
DMVOPO9P	MOTOR OPERATED VALVE P9	PLUGGED	10 ⁻⁷	1	300	H	_		_	_	4	4	#	#	1	Ħ		I				PIPE	• • • • • • • • • • • • • • • • • • • •
			10 ⁻⁷						\exists				1	\perp	#							PIPE	
DPP0015P	PIPE 15	PLUGGED		720	100	\Box	_			-	\dashv	\dashv	\pm	-5	\pm							TUNNEL PUMP	
DPP0016P	PIPE 16	PLUGGED	10-7	720	100	\Box	_		_	-	_	\dashv	\dashv	-2 -5		\vdash	H	H	H	H		CUPICLE	
DCVOP14P	CHECK VALVE P14	PLUGGED	10 ⁻⁷	1	300	\Box						_		-2 -5	1	#						CUBICLE	
DPMOOODF	PUMP D	NO FLOW	10 ⁻⁵	720	_10_	日			_					. 12	_l		L	L				CUBICLE	
DPMOCODP	PUMP D	RUPTURE	10 ·3	720	100	\vdash	\dashv		\dashv			-	\dashv	- 5	+	╀	├		-	<u> -</u> -	$\left - \right $	PUMP CUBICLE	
DPMOOODP	PUMP D	PLUGGED	10 ⁻⁶	1	100	\Box	-		\dashv	_	=		7	5	\perp	F		-	F	_	Н	PUMP	
DPPOO17R	PIPE 17	RUPTURE	10-10	720	30	H				\exists				#	#	F	厂		F		П	EXCHANGE	
			10-7			\Box						〓	1	5		‡						PUMF	
OCVOP14C	CHECK VALVE P14	CLOSES		720	30				-			\exists	\pm	2	\perp	\perp		L				CUBICLE	·
DHEOO3P	HEAT EXCHANGER	PLUGGED	10-8	1	300	\square	-		\dashv	\dashv				T	F	F	F	1	F		H	EXCHANGE	
HEOO3R	HEAT EXCHANGER	RUPTURE	10-6	720	-100	Ħ	_		\dashv	\dashv	\vdash	\dashv	\dashv	\dashv	+-	\top	1	1		!	 	EXCHANGE	

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)

PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

			- Р	RIMARY *AILU	RE						SE	CONDA	ITY E	/EN1 (10.4	,*	_						
EVENT NAME	EYEMI COWPONENT	FAILURI . MODE	IFAILURE RATE	FAU_T OURATION	ERROR Factor	FIRE	EARTHQUAKE	STEAM	HI-TEMP.	PRÉSSURE			=	PIPE WHIP		NO 1 1	CORROSION	INDUCED VOLT	VIORATION	SOLVENT		S KOLIKOOJ	REMARKS
DHEO004P	HEAT EXCHANGER	PLUGGED	10-8	1	300		L	E							E		-		E		\exists	HEAT EXCHANGE , BLDC HEAT	
DHEO004R	HEAT EXCHANGER	RUPTURED	10 ⁻⁶	720	100_		Ł	-	Ŀ	Н		\sqcup	\pm	\perp	\pm	╁	<u> </u>			-	Ⅎ	EXCHANGE	
DHEOOO5P	HEAT EXCHANGER	PLUGGED	10-8	1	300	\pm	-	L		oxdot				\pm	\pm						\exists	EXCHANGE REAT	
DHEOOOSR	HEAT EXCHANGER	RUPTURE	10-6	720-	100		H				E			1		L	E				\exists	EXCHANGE	
DMVOP12R	MOTOR OPERATED VALVE P12 MOTOR OPERATED	P.UPTURE	10-8	72C	100		+	t	_	\Box			+	#	+		<u> </u>				1	PIPE TUNNEL PIPE	
DMVOP11R	VALVE P11 MOTOR CPERATED	F.UPTURE	10-8	`72C	100		F	Ė	-	Ħ		H	1	#	+	F	=		F	H	\exists	TUNNEL PIPE	
DMVOP10R	VALVE P10 MOTOR CPERATED	RUPTURE.	10-8	720	100		Ħ	‡	=	Ħ			\dashv	#	#					H	7	TUNNEL PIPE	
DMVOP28R	VALVE P28 MOTOR OPERATED	RUPTURE	10-8	720	100		F	1	‡=	П		Ħ		#	#		ļΞ				7	TUNNEL	
DMVOP27R	VALVE P27 MCTOR OPERATED	RUPTURE	10-8	720	100		1	+	‡=					#	‡	1	‡=				#	PIPE TUNNEL PIPE	
DMVOP26R	VALVE P26 OPERATOR ERROR	RUPTURE	10-8	720_	100		t	1	1	Ħ		H	\Rightarrow	#	‡		F			H	ゴ	TUNNEL	
DMVOPO9X	. MOV-9	INADVERTENT CLOSURE	10-3	_1	100	茸	1	L	Ι_	\Box				#	‡		=			口	⇉	BLDG. PIPE	
DMVOP25C	MOTOR OPERATED VALVE P25 OPERATOR ERROR	CLOSES	10-4	720	30	\pm	+	#	‡=				\Rightarrow	#	‡	=	‡=				⇉	TUNNEL	
DMVCP25X	MOV-25 OPERATOR ERROR	INADVERTENT CLOSURE INADVERTENT	10-3	_1_	100	上	t							#	+		‡=				1	BLDG.	
DMVOP12X	MOV P-12 MOTOR OPERATED	CLOSURE	10-3	11	100_		‡	+						#	#	\vdash	‡=				⇉	COMPRESSO BLDG	
DMVOP28C	VALVE P-28	CLOSES	10-4	720	30	\Rightarrow		+	‡=				#	丰	1	Ė	‡=				コ	PIPE TUNNEL	
DMVOP28X	- OPERATOR ERROR MOV P-28 OPERATOR ERROR	INADVERTENT CLOSURE	10-3	1	100		t	‡	E	H			\exists	1	L	t	上				\Box 1	BLDG.	· · · · · · · · · · · · · · · · · · ·
DMVOP11X	MOV P-11	INADVERTENT CLOSURE	10-3	_1	100		t	上				H	#	+	Ė		上				Ⅎ	BLDG.	·
DMVOP27C	MOTOR OPERATED VALVE P27	CLOSES	10 ⁻⁴	720	_30		上	╘	<u> </u>					#	‡		Ë				_	PIPE TUNMEL	
DMVOP27X	OPERATOR ERROR MOV P27	INADVERTENT CLOSURS	10-3	1	100		\downarrow	士	\pm					1	\pm	\pm	\vdash			廿	Ⅎ	COMPRESSOL	
DCA0001S	PUMP A CABLE 1	SHORT	10-7	720	_10		\downarrow	\perp	\vdash		E			\pm	\pm	\vdash	L				- 1	ELEC BLDG 1	
DCA0001B	PUMP A CABLE 1	OPEN	10-6	720	3		\pm	\pm	\vdash	\vdash			\exists	\pm	\pm	L	\vdash		_		- 1	COMPRESSOR ELEC. BLDG.	
DCA0G02S	PIMP B CABLE 2	SHORT	10-7	720	10	<u>H</u>	Ł	\pm	\perp				\exists	\pm	\pm	\pm	<u>L</u>		E		\exists	COMPRESSOE TO PLPC BLDC	

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING [UPPEP NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

				RINARY FAILU		Γ					SEC	CONDA	RY E	ENT (10 - 2		•					$\overline{}$	
EVENT NAME	EVENT COMPONENT	FAILURE MODE	FAIRURE RATE	FAULT DURATION	ERROR Factor	FIRE	FL000	STEAM	H - TEMP.	PRESSURE	HUMIDITY		, 11	PIPE WHIP		NO 1 1	CORROSION	INDUCED VOLT.	VIBRATION	SOLVENT	LOCAT	10N .	REMJRKS
DCAGCO2B	PUMP B CABLE 2	OPEN	10-6	720	3	-5 1	\pm	-	- <u>5</u>		_				F						COMPRI TO ELEC	- 1	
DCA0003S	PUMP C CABLE 3	SHORT	10 ⁻⁷	720	10	5	\pm	\perp	-5 -1			\dashv	+		_					\Box	FLEC	מתוזא	
DCA0003B	PUMP C CABLE 3	OPEN	10 ⁻⁶	720	3	5	+	+	_5 1			\exists	+	+	-	\vdash				Н	COMPRISON TO	BLDG.	
DCA00C4S	PUMP D CABLE 4	SHORT	10 ⁻⁷	720	10	5	\pm	_	5			\exists	\dashv	-	-					H	TO ELECT	BLDG.	
DCA0004B	PUMP D CABLE 4	OPEN	10 ⁻⁶	720	3	-5 1	_	-	-5 -1			\vdash	-	Ξ-							ELEC	BLDG.	
DCEOCOAB	PUMP A CIRCUIT BREAKER	OPEN	10 ⁻⁶	720	30	-5 -1	\pm	$oxed{\bot}$	_5 _1 _5			\exists	\exists	$oxed{T}$	1 5						ELE BLD	С.	
DCBCGOAX	OPERATIONAL ERROR CIRCUIT BREAKER	INADVERTENT OPEN	10 ⁻³	1	100	-5		-	Ξī			-	+	+	<u>1</u> -5					\blacksquare	ELE BLD		
XCEADJ1X	OPERATIONAL ERROR CK + BKR ADJUST	INADVERTENT OPEN	10-3	1	100	-5 -1	+	+	-5 1			-	4	-	_1 -5					\vdash	ELE		
DCBOOOBB	PUMP B CIRCUIT BREAKER	OPEN	10 ⁻⁶	720	30	-5 -1			_5 _1			\exists		=	1 5					$oxed{H}$	ELE BLD		
DCBOOOBX	OPERATIONAL ERROR CIRCUIT BREAKER	INADVERTENT OPEN	10-3	1	100	-5 -1	\perp	\perp	-5 -1			\exists	\exists	\pm	_1 -5	\Box		_		Н	ELE		
DCBOOOCB	PUMP C CIRCUIT BREAKER	OPEN	10 ⁻⁶	720	30	-5 -1	_	\pm	_5 _1	Ι			\dashv		1 5					Н	ELE BLD		
DCEGGOCX	OPERATIONAL ERROR CIRCUIT BREAKER	INADVERTNET OPEN	10-3	1	100	5	t	\pm	5						- <u>1</u>	I					ELE BLD		
DCEOCODB	PUMP D CIRCUIT BREAKER	OPEN	10-6	720	30	5	t	\pm	-5 -1					\pm	- <u>1</u> -5		-		_	Н	ELE BLD	G	
DCBOOODX	OPERATIONAL ERROR CIRCUIT BREAKER D	INADVERTENT OPEN	10-3	1	100	-5		士	-5 -1 5				\pm	_	_1 5	•					BLD	G.	
LRE00818	13.8KV FREQUENCY TRIP RELAY BUS C INPUT	OPEN	10 ⁻⁵	720	100	5	_	+	_1	<u>L</u>			#		1 					Ħ	BLD:	Ġ.	
LCB013CB	CIRCUIT BREAKER	OPEN	10-6	720	30	5	+	1	1				_	#	_1 5						BLD.	g	
LCB013CX	OPERATIONAL ERROR BUC "C" INCOMING CB	OPEN	10-3	1	100	_5 _1	‡.	+	1				#	\pm	_1 5	İ.,					BLD	G	
LCA013CB	INCOMING CABLES TO BUS "C"	OPEN	10-6	720	3	5	_	+	_5 _1				_	#	- <u>-1</u>						ELE:	G	<u> </u>
LCA013CS	INCOMING CABLES TO BUS "C"	SHORT	10 ⁻⁷	720	10	_5 1	\pm	\pm	_5 _1				_	士	_1 5					\Box	BLD:	G	
LCCLDOCM	OVERLOAD ON BUS C	EXCEED LIMIT	10 ⁻⁶	720	100	5	\pm	L	5 1				\dashv	\pm	- <u>1</u>	_				H	BLD:	S.	<u> </u>
LOTCOTIB	TRANSFORMER T-1	OPEN	10 ⁻⁶	720		5	\pm	\pm	5 1 5			15	\exists		13			Ė		H	YAR		
LOTOOTIS	TRANSFORMER T-1	SHORT	10-6	720	3	5	\pm	\pm	ئ 1	H	E	<u>-5</u>	\exists		1 5		-			Н	ELE		

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)

<u></u>			Р	RIMARY FAILU	RE						SI	ECOAD	ARY E	VENT I	10.4	, *					\Box		
EVENT NAME	EVENT COMPONENT	FA.LUFE WODE	FAILURE RATE	FAULT OURATION	ERROR Factor	FIRE	F 1,000	EARTHQUAKE	STEAM	PRESSURE	KUMBOLIY	PREELING	WESSILE	PIPE WHIP	0us1	RADIATION	CORROSION	INVULED TOLI	VISRATION	SOLVENT		LOCATISM	REMARKS
LCBC03AB	BUS A CIRCUIT BREAKER 3	OPEN	10-6	720	30	-5 -1	7	1	- 5 - 1		F			\pm	1-5						\exists	ELEC. BLDG.	
LCE003AX	OPERATIONAL ERROR BUS A CB 3	OPEN	10-3	1	100	- <u>5</u> -1		\pm		\equiv		-	Н	\pm	1 5						\exists	ELEC. BLDG.	
LBS000AB	BUS A	OPEN_	10-6	720	30	5	-	\pm		U											\exists	ELEC. BLDG.	
LBS000AS	BUS A	SHCRT	10 ⁻⁷	720	30	-5	\pm	\pm	5 1 2	\pm	\vdash	\perp	Н	\pm	يا						\exists	ELEC. BLDG	
LOOLDOAM	OVERLOAD ON BUS A	EXCEEDS	10 ⁻⁶	_ 720	_100		:	+		J	L	E		\pm	1 5		E			\exists	Ⅎ	ELEC. RLDG	
LSWYARDF	TEST REACTOR SWITCHYARD FAULTS CAUSE POWER LOSS	LOSS OF FUNCTION	10 ⁻⁷	720	100	5	\pm	\pm		\perp	L	3	Н		-						ᆸ	SWITCHYARD	
LCEO23DB	CIRCUIT BREAKER 23	TRIP OPEN	10-6	720	30	5	\perp	\pm	<u>-</u> د ــــــــــــــــــــــــــــــــــــ	\top	L	\vdash		士	-1-5						\exists	ELEC.	
LCBG23DX	OPERATIONAL ERROR CIRCUIT BREAKER 23	OPEN	10-3	1	100	_5 1	\pm	\pm		\perp	╁╴	\perp	Н	\pm	1 5						\exists	ELEC. BLDG	
LCAO23DB	CABLE 23	OPEN	10-6	720	. 3	<u>5</u>	\pm	\pm		工	L		Н	\pm	_1 -5		Ŀ				\exists	ELEC.	
LCA023DS	CABLE 23	SHORT	10-7	720	10	5	÷	\pm	- 5		L			\pm	-1-5				П		님	ELEC. BLDG.	
LOOLDODM	LOAD CIRCUITS ON BUS D	EXCEED LIMIT	10 ⁻⁶	720	100	5	\pm	1	5 1	I	╁	L	Н	土	1 5					\exists	Ⅎ	ELEC. BLDG.	
LOTOOT2B	TRANSFORMER T-2	OPEN	10-6	720	3	5	\pm	\pm	5	\Box		\pm	Н		15		_				\exists	TRANSFORME YARD	
LCB003BB	CIRCUIT BREAKER 9	TRIP OPEN	10-6	720	30	5	\pm		<u></u>		\vdash	H			1 5	\Box				i	크	ELEC. BLDG.	
LBSOOOBB	BUS B	OPEN	10-6	720	30	5	\pm	1	<u>5</u> 1		L			_	1 5						크	ELEC. BLDG.	
LBSOOOBS	BUS_B	SHORT	10 ⁻⁷	720	30	1	士	#	5	\perp				+	-1		Ė	Н		\exists	ᆿ	ELEC. BLDG.	
LOOLDOBM	LOAD CIRCUITS ON BUS B	EXCEED LIMIT	10-6	720	100	5	+	\downarrow	5 1	\perp	L			\pm	5						ᆿ	ELEC. BLDG.	i
LCB009BX	OPERATIONAL ERROR CIRCUIT BREAKER 9	OPEN	10-3	1	100	5 1	\pm	\pm	<u>ا</u> 1	Л.	L			_	1 5						ᆿ	ELEC. BLDG.	
LCONETS	LOSS OF INEL POWER GRID		10-5	1	30	5	#	#	5 1		+	<u>1</u>			5						ᆿ	INEL	
DXVOP34C	MANUAL VALVE P34	CLOSED	10-4	1	3	H	\pm	\pm	\pm	上	+			#	$^{+}$	\vdash					ᆿ	PIPE TUNNEL	
DXVOP34X	OPERATIONAL ERROR MANUAL VALVE P34	INADVERTENT CLOSED	10-3	1	100	H	\pm	\pm	\pm	上	E	\pm		\pm	+	\pm	L				二	PIPE TUNNEL	
DXVOP34R	-MANUAL VALVE P34	FUPTURE	10 ⁻⁸	_1	10	H	\pm	\downarrow	\pm	\pm	Ł	\pm	Ц	\pm	士	Ė	E	H			ᆿ	PIPE TUNNEL	
DXVOP34P	MANUAL VALVE P34	ELUGGED	10-8	360	300	Н	\pm	\pm	\pm	\pm	-	\perp	Н	\pm	上	上		Н			ᅥ	PIPE. TUNNEL	

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

·					nr.	Ι					_		ONDAR	v 5		0.1	*		•			_	· I	
EVENT	EVENT COMPONENT	FAILURE Mode	FAILURE RATE	FAULT OURATION	ERROR Factor	FIRE	F1000	EARTHOUARE	STEAN	HI-TEMP	PRESSURE	HUMIO I IY				TSOO	RADIATION	CORROSION	INDUCED VOLT	VIBRATION	SOLVENT		LOCATION	REMARKS
DPPCO2OP	PIPE 20	PLUGGED	10 ⁻⁸	360	300		\exists	1	7			\exists		-								ŕ	PIPE TUNNEL	
DPOC2OR	PIPE 20	RUPTURE	10-10	360	30	H	\pm	1	1		4	\exists	\exists	\pm		L							PIPE TUNNEL PIPE	<u> </u>
DORFE14P	ORIFICE FE-4-14	PLUGGED	10 ⁻⁸	1	300		_	\pm	\exists					\pm	\pm	_					\exists	Ⅎ	TUNNEL *	
DXVCP40R	MANUAL VALVE P40	RUPTURE	10-8	1	10	Н		\perp						Ī	2	L						_	EYERG. CUBICLE EVERG.	
DXVOP41R	MANUAL VALVE P41	RUPTURE	10 ⁻⁸	1	10		\pm	\pm		\exists			\exists	Ŀ	2	L	L						CURICLE *	
DXVOP36R	MANUAL VALVE P36	RUPTURE	10-8	1	10		\pm	\pm		\exists				Ē	2							_	CURICLE	
DXVOP37R	MANUAL VALVE P37	RUPTURE	10-8	1	10		+	\pm	\pm	Ⅎ	\exists				2	L	L	L			\exists		CURYCLE	•
DPP0021R	PIPE 21	RUPTURE	10-10	1	30		-	\dashv	\exists	_	_	_	<u></u>	+	\pm	\vdash	┢	L					PIPE TUNNEL	
DPP0021P	PIPE 21 .	PLUGGED	10-8	1	300	\vdash	\dashv	\dashv	\dashv	\dashv	\dashv		\perp	\pm	1	Ł				Н			PIPE TUNNEL	_
DXV0035P	MANUAL VALVE P35	PLUGGED	10-8	1	300	H	\exists	\exists	\exists					\perp		E	-		_				PIPE TUNNEL	
DXV0035R	MANUAL VALVE P35	RUPTURE	10-8	1	ío		+	\perp			_				_	-							PIPE TUNNEL	
DXVOP31C	MANUAL VALVE P31	CLOSED	10-4	1	3	\vdash		+	_		_			\pm	-	\perp	ł						PIPE TUNNEL	
DXVDP31X	OPERATIONAL ERROR MANUAL VALVE P31	CLOSED	10-3	1	100	H	\dashv	\exists	\exists							\perp	\vdash						PIPE TUNNEL	
DXVOP31R	MANUAL VALVE P31	RUPTURE	10-8	ı	10	Н	1	1	\pm				Н	\perp	\pm	\perp	\vdash	\vdash	L				PIPE TUNNEL	
DXVCP31P	MANUAL VALVE P31	PLUGGED	10-8	360	300		\pm	1	\pm						\pm		L						PIPE TUNNEL	
DPPCO2OP	PIPE 20	PLUGGED	10-8	360	300		+	\dashv		\exists				\pm		L	L	\vdash	<u> </u>				PIPE TUNNEL	
DPP0020R	PIPE 20	AUPTURE	10-10	360	30	Н	\pm	\pm		\exists	\exists			1	\pm	Ł	_						PIPE TUNNEL	
DØRFE14P	ORIFICE FE-4-14	PLUGGED	10-8	1	300	-	\pm	\perp			\exists			\pm	+	╘		1	Ė				PIPE TUNNEL	
DXVOP40R	MANUAL VALVE P40	RUPTURE	10-8	1	10	H	\exists	\pm				_			5 2	\pm	\perp					-	CUBICIE CUBICI CUBI	
DXVOP41R	MANUAL VALVE P41	RUPTURE	10-8	1	10	H	\pm	_	\exists							+	\vdash						CULTULE CULTULE CULTULE	
DXVOP36R	MANUAL VALVE P36	RUPTURE	10-8	1	10	Н	1							Ī	2	\pm	\pm	\vdash	L	E			CUPTCLE	· · · · · · · · · · · · · · · · · · ·
DXVOP37R	MANUAL VALVE P37	RUPTURE	10-8	1	10	Н	士	╛					Н	\pm	2	L	Ł	i					EMERG. PUMP CUBICLE	

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

LOSS OF PRIMARY FLOW

			P	RIMARY FAILU	RE							SE	CONDA	IAA E	VER 1	10.1	,*				-			_		
EVENT NAME	EVENT COMPONENT	FAILURE MODE	F11BURE RAJE	FAULT OURATION	ERROR Factor	FIRE	61000	EARTHOUARE	STEAM	H1-TEMP	PRESSURE	HUMIDITY	FREEZING	31	ding 3did		11.0M	CORROSION	INDUCED VOLT	VIBRATION	SOLVENT	LOCATIO	in .		REWARKS)
DPP0021R	PIPE 21	RUPTURE	10-10	_ l	30		\exists													E	Н	PIPE TUNNEL				
DPP0021P	PIPE 21	PLUGGED	10-8		300	\exists	#	\dashv	\exists	\exists	1			_	:	t	+	\vdash				PIPE		<u> </u>		
DXV0035C	MANUAL VALVE P35	CLOSEL	10 ⁻⁴	1		\pm	\pm	_	_	=				⇉		+						PIPE	\perp			
GST0001Z	STRUCTURAL FAILURE OF THE FLOW DISTRIBUTOR	STRUCT FAILURE	10-10	1	300		†	\dashv		\dashv				_		\pm	t	\vdash				REACTOR VESSEI				
ESTC002Z	STRUCTURAL FAILURE OF EXPERIMENTAL PIPING STRUCTURAL FAILURE OF	STRUCT FAILURE	10 ⁻¹⁰	1	300	1	#	1	#	4	#			\dashv		t	Þ	\vdash	E	Ļ		REACTOR VESSEI	-			
GST0003Z	EXPERIMENTAL PIPING SINUCTURAL FAILURE OF THE UPPER CONTROL POD SUPPORT FRAME	STRUCT. FAILURE	· 10 ⁻¹⁰	1	300	-	1		_					⇉		t	Ļ	L	Ħ	L		REACTOR VESSEI				
GSTC004P	CORE BLOCKAGE CAUSED BY FUEL PLATE WARPAGE	STRUCT. FAILURE	18-10	1	300	\dashv	#	#	\exists		1			_	‡	\pm		L				REACTOR VESSEI	\dashv			
GST0005Z	FUEL PLATE WARPAGE THE CONTROL BOD GUIDE CORE BLOCKAGE CAUSED REAFORE PLOCKAGE CAUSED REAFORE PROSERVE STATEM	STRUCT. FAILURE	10-10	1	300		\pm	\rightrightarrows	4	\exists				1	1	#		╘		上		REACTOF VESSEI				
COCOCOLP	REACTOR COOLING SYSTEM	BLOCKAGE	10-5	1	100	\Rightarrow	#	_		\dashv				Ⅎ	#	\pm						HX. ELE	G.			
D000001X	CORE BLOCKAGE CAUSED BY DEBRIS LEFT IN	BLOCKAGE	10-5	1	100	\Rightarrow		1	⇉	╛		\exists	\exists		5	t	L	L	E	┢	H	COMP. BI		<u> </u>		
	SYSTEM BY OPERATIONS PERSONNEL						\pm	\pm	\exists	╛	\exists			\exists			上									
						\pm	\downarrow	╁	_	\dashv	\exists				\pm	\pm				L			_			
						\exists	\pm	1			\exists			_	\pm	t	t	\vdash								
							#	⇉	\exists	\exists				\exists	\pm	╆	╆	t		E						
						\exists	_		\exists	_	_			\exists	_	†	+	L	L	L		┪				
						\exists	1	_	\exists					\exists		t	L			┢		┧				
							_		\exists	_	1				\Rightarrow	\pm	上	t								
						\pm	\pm	\dashv	\exists	_	╛		Н	\exists	\pm	\pm	$oxed{\pm}$	\vdash		\vdash	\Box					
:						\exists	\pm	\exists	\exists		\exists	\exists				\pm	Ŀ									
							\pm		Ⅎ							L	Ł	Ė				-				
						\pm	\pm	\exists	_	\exists	\exists				+	\pm			L							
						\exists	\pm	\exists	\exists	\exists	\exists	_	\exists	\exists	\pm	$oxed{\mathbb{F}}$	E									

5.1.3 Results. The probability of a loss of flow event occurring in the primary cooling system was determined through use of the SAMPLE computer code. For this analysis, the events on the fault summary dealing with rupture of the primary system were not included. Therefore, the probability given is for an accident involving failure of the coolant to flow, but the coolant will not be lost from the system.

The fault tree for the primary system was reduced to include only the "significant" fault events. The "significant" events are those used in the probability calculation. An event or combination of events having a probability of occurrence of 1×10^{-10} is insignificant when compared with a probability of 1×10^{-3} . Thus, the fault tree was greatly simplified and the computer analysis time reduced.

The SAMPLE code uses Monte Carlo techniques to determine the system unavailability at a given point in time. The time chosen was 720 hours, which is the assumed length of operating time at the ETR. System unavailability at this time is higher than any other time during the operating period. Unavailability increases as time increases, and unavailability is the probability that the stated event exists at the specified time.

The median probability value of a loss of primary flow accident (loss of flow but not loss of coolant) occurring in the ETR, calculated by the SAMPLE computer code, is 2 x 10^{-2} /operating cycle. The 90% range is 7 x 10^{-3} to 1 x 10^{-1} /operating cycle. The median probability value indicates that about twice in 100 operating cycles, the automatic reactor shutdown system and emergency flow system are expected to be called upon because of a loss of flow event at the ETR.

Four faults resulting from human error are the main contributors to the probability. Their code names on the fault summary, Table A-I, are LCB009BX, LCB023DX, LCB003AX, and LCB013CX. These faults result when electrical circuit breakers are inadvertently opened manually. Two breakers affect power to the A and C primary pumps and two affect power to the B and D pumps. Because three primary pumps are required, loss of two pumps is considered failure of the system. However, at least one primary pump will continue running following any one of these four faults. The flow from this one primary pump exceeds the flow from the emergency flow system. This conservative factor has not been taken into account in this study.

5.2 Plant Protection System

The ETR Plant Protection System (PPS) provides for the automatic shutdown of the reactor in the event one or more of the plant or experimental variables exceeds predefined safe limits. In this analysis failure of the PPS to respond to a loss of flow event is the area of concern. The equipment in the protection system includes the devices that sense or measure the process variables; the instruments that modify, amplify, and operate on the signals from these sensors to provide trip signals to logic elements; the logic elements that receive these trip signals from the instrument channels and provide other trip signals to initiate protective action when the instrument channel trip signal is generated; and finally, the actuators that act directly on the reactor control rod and its release mechanism to provide protective action.

5.2.1 System Description. The PPS is a one-out-of-two logic system; that is, it is comprised, as shown in Figure A-6, of two logic trains either of which produces scram action.

Each automatic shutdown logic train accepts up to 20 scram signals monitored by nuclear and process subsystems or channels. Each channel has its own input buffer, an amplitude and frequency noise rejection circuit, and a latch or seal circuit. The latched scram signal is connected to the 20-input logic train which performs an "OR" function so that the existence of any one or more scram signals at either logic train input produces scram action. At its output, the output scram signal from the logic train is transmitted to all tenactuator controllers, one for each actuator. On receipt of a scram signal from the logic train of either or both automatic shutdown channels, the actuator controllers switch off current to rod-holding magnets, thereby releasing the safety rods. The safety rods are released within 23 milliseconds of receipt of a scram signal at any automatic shutdown channel input.

Manual shutdown Channels 1 and 2 can be activated by the reactor operator by push button switches located on the control console. A manual shutdown is accomplished by interrupting the ac power to the actuator controllers. Either manual shutdown channel will cut off the current to the magnets. The safety rods are released within 250 milliseconds after activation occurs.

- 5.2.2 System Analysis. The plant protective system was evaluated to identify all events related to the PPS system and its associated subsystems that could prevent reactor shutdown in the event of loss of forced flow through the reactor during operation at power. The loss of flow considered was of a magnitude such that partial or complete core melting would eventually result should the PPS fail.
 - (1) <u>Assumptions.</u> For purposes of this analysis the following assumptions were made and ground rules established:
 - (a) Onc of the ten control rods being inserted into the core is sufficient to scram the reactor; thus, failure to scram is defined as failure of all ten safety rods to enter the core upon a loss of flow signal.
 - (b) Only three of the twenty input signal variables are most responsive to a loss of flow event: reactor differential pressure, reactor inlet/outlet pressure, and emergency flow. Other protective subsystems response, that is, surge tank level, neutron level, fission break monitor, . . . , lag the selected protective subsystems by several seconds




Fig. A-6 Reactor shutdown system simplified block diagram.

- (c) Credit can not be given in the analysis for manual operation of the PPS because the operator would not respond quickly enough.
- PPS response to the loss of flow event and the associated fault summary which lists each fault event are shown in Figure A-7 and Table A-II, respectively. The fault tree on Sheet 1 of Figure A-7 was developed to identify event combinations in Logic Trains A and B which could tail to provide scram signals to the safety rod actuator controllers. No single failures were identified in this analysis; only combinations of two component failures were identified (15 potential fault events in each train which must combine with 15 potential fault events in the other train). These are listed in the fault summary, Table A-II. For the most part, these event combinations are of relatively low probability because no common mode failures exist between events identified in the logic trains.

Sheet 2 of Figure Λ -7 depicts the fault events within the three required protective channels or subsystems: the differential pressure, the inlet/outlet pressure, and the emergency flow subsystems. The combinations of events identified in the channels needed to fail the PPS are higher order cut sets (higher than the two member cut sets found in the logic train) and, therefore, were not important contributors to system failure.

- (3) Data. Data used to quantify the fault model for the PPS were obtained from WASH-1400^[A-1] and MIL-HDBK-217B^[A-2].
- 5.2.3 Results. The calculated median value of the unavailability of the PPS as it applies to a loss of flow event is 6×10^{-6} . The upper and lower 90% confidence bounds on this median value are 2×10^{-5} and 2×10^{-6} , respectively.

The principal contributors to this unavailability are transistor faults which could occur in the logic trains. Faults in the individual scram channels which monitor the various scram parameters were insignificant contributors because of their logical arrangement on the fault tree and because of their independence from one another.

5.3 Emergency Flow System

The emergency pumps provide coolant flow through the reactor core in the event of primary coolant pump loss and for circulation of coolant during normal shutdown. In this analysis interest is centered about determining the likelihood that the emergency pumping system will not respond following a loss of forced flow event, that is; interest is centered about the unavailability of the emergency flow system.




Fig. A-7 Reactor protection system for loss of forced flow fault tree.




Fig. A-7 Reactor protection system for loss of forced flow fault tree (ccntd.).




Fig. A-7 Reactor protection system for loss of forced flow fault tree (contd.).

TABLE A-II

REACTOR PROTECTIVE SYSTEM FOR LOSS OF FORCED FLCW

1			PF	IMARY FAILU	RE							SEC	ONDA	R" EV	DIT:	{10°	')*						<u> </u>	
MAME	EVENT COMPONENT [LOGIC TRAIN] CHANNEL A AID/OR B	FA:LUPE NGOE	FACLURE RATE	FAUL8 OURAT:OON	ERROR Factor	186	FL000	EARTHQUAKE	STEAM	31.1887,	FAESSURE	HUNIDITY		=		T INO		COSDOSION	Tion Called	200000	Molevania	SOLVENI	LOCATION	REMARKS
	LOGIC A	SHORT	-7				1			\Box	╛		\Box	ユ	I	I	I	I	I		I	ፗ	CABINET	
TTRAOQ3J	TRANSISTOR Q3	E-C	1×10-1	72C	10	\vdash	+	-		-1	-4		\rightarrow	-	4	- -	+	+	╁	+	+	+	R-17	
	LOGIC A RESISTOR R26	SHORT	1 x: 10 ⁻⁷	72C	10	⊢	┽	\dashv	-		-	\dashv	-+	+	+-	+	╁	┿	┿	┿	┿	+	CABITET R-17	
IRSAR26J	LOGIC A	OPEN	-1 A. 10	120	10	Н	\pm	-	_	┪	┪	-	\dashv	\dashv	┰	+	╁	+	+	╈	┿	+	CABINET	
ITRACQ2B	TRANSISTOR 02	E-C	1 x 10 ⁻⁷	72C	10	\vdash	_	┪	寸	_	\neg	_		十	+	\top	+	┪.	╅	\top	╅	十	R-17	
	LOGIC A	SHORT					\Box						\Box			1	I	T		I	\top	T	CABILET	
ITRACOZI	TRANSISTOR Q2	B-E	1 x 10-7	72C	10		\Box	\Box	\Box	\Box		\Box			\perp	\perp	\perp	I	\perp	I	I		R-17	
	LOGIC A IC1	SHORT				$\perp \downarrow$	4	_	_	_	-4	_	\perp		4	+	\bot	4	4	4	4	4	CABINET	
IICAICI5	INTEGRATED CIRCUIT	TC GROUND	1 × 10 1	720	10	$\vdash \vdash$	+	-	-+		\dashv			+	+	+	+	+-	+	+	+	+	R-17 CABINET	
IICAICLB	LOGIC A IC1 INTEGRATED CIRCUIT	OPEN	1 x 10-7	72C	10	┝╼┼	+	\dashv	-+	\dashv	-+		+	+	+	+	╁	+-	╁	+	╁	+-	R-17	
TICATOR	LOGIC A IC2	SHORT	- A-A-U			1		-	_		1	┪	_	\dashv	+	+	+	╅	╅╌	+-	┿	+-	CABINET	
IICAIC25	INTEGRATED CIRCUIT	TO GROUND	1 x 10-7	72C	10	\vdash	╅	_	一	_		\dashv	_		+	\top	+	╈	t	+	╈		R-17	
	LOGIC A IC2						\Box		\neg		.	_			_		T	7	Т		\top		CABILET	
IICAIC2B	INTEGRATED CIRCUIT	OPEN	1 x 10 (72C	10		\Box	$\overline{}$	=	\Box	\Box	\Box			\perp	\perp	Ι	\perp	\perp	\perp	\perp	\perp	R-17	
	LOGIC A IC3	SHORE				1	4	_	_	_	4	_	\rightarrow	4	4	4	1	4	4	4	4	4	CABINET	
IICAIC35	INTEGRATED CIRCUIT	TO GROUND	1 x 10-7	72C ·	10		\dashv	-			-	-		+		+	+	-	+	+	4	+	R-17 CABINET	
IICAIC3B	LOGIC A: IC3 INTEGRATED CIRCUIT	OPEN	1 x 10-7	720	10	⊦-⊦	+	-		-+	 +	\dashv	-+	+	+	+	┿	+-	+	+-	+	-	R-17	
TICKICSB	TATEGRATED CIRCUIT	CUTPUT	- X 10	150		┨	\dashv	-	-	╗┪	-+	\dashv	\dashv	-+	+	\pm	+-	+-	+-	╁	┿		CABITET	
IICAFLIW	F & L MODULE (AP)	DCES NOT	3 x 10-7	72C	10	1	十	_	_	∹†		┪	-	\neg	╅	+	$^{+}$	+	+-	+	+	+-	R-17	
	/INLET	OPEN CUTTOT DOES NOT TPAUSFER LCW DOES NOT TRAUSFER LCW DOLLS NOT TRAUSFER LCW TRAUSFER LCW	~~~				o	\neg	7	-31		┪		_	\neg	\top	$^{+}$	+	+	+	+	\neg	CABINET	
IICAFL2W	F & L MODULE PRESS.	TRĂTISFER LCW	1 x_10 ⁻⁷	720	10		コ			0		二			工			I	I	1	I	\Box	R-17	
	EMER.	DEES HOT	7				4	_		<u> </u>	_	_		_	4	_	4	4	4	┸	4		CABINET	
IICAFL3W	F & L MODULE (FLOW	PRADSFER LCU	י ט	720	10	₩	+		;	-3		-	-		-	+	4-	+	+	+	+	_	R-17	
		1 200233200	13-7	700	10	\vdash	+	-		윙	-+			\dashv	+	+	+	+-	+	+	╀	+	CABINET	
_IPTAØ00M	AMSS PHOTOTRANSISTOR	CURRENT EXCESSIVE		720	10	╁┼	-+		→.	-31		\dashv	-	-	-+-	+	┿	+-	+	╅	┿	+	R-17 CABINET	
ТРСАФООМ	AMSS PHOTOCOUPLER	CURRENT	າວ ⁻⁷	720	10		ヿ	ヿ		-51	寸		\dashv		_	十	+	+	+	╅	╈	_	R-17	
												Ī	\Box		Τ.		I	Ι.	Ι	I				
							\perp	\Box			\Box	\Box			\sqsupset	\perp	T	Ţ		T	I	\perp	1	
1	FAULTS IN LOW AP					$\vdash \vdash$	\dashv	_		\dashv	_		 		4	+	+	4-	+	\perp	4	+	4	
	NETWORK CHAINEL #A					⊢┼	\dashv	-			\dashv	-		+	+	+	+	+-	+-	╁	+	-	NOBUE	
IPPLALOR	PRESS. IMPULSE LINES	RUPTURE	19-7	720	20	┝╌┼	+	\dashv	\dashv		-+	\dashv	-	\dashv	+	╅	┿	+-	╁	╁	┿		NOPTE TUNIEL	
TELIMINA	TREES. IMPUISE LINES	NUPLURE		150	30	╁┼	\dashv	\dashv	-	\dashv	\dashv	\dashv		\dashv	┰	+	+	╅	┰	+	+	+-	I NOBILE -	
IPPLALOP	PRESS. IMPULSE LINES	PLUGGED	10-7	1	30	ľΤ	-	_	\dashv	\neg	\neg	\dashv	-	_	+	\top	+	十	+	╅	\top	1	NOBIH PLPE TUMEL	
	The second secon	INADVERTENT					ゴ							二	\perp	I	I	I	I	I	I		110 Kiri	
IRVLALIC	BLOCK VALVE	CLOSURE	19-6		700		\Box	\Box					\Box		I	\Box	1.	I	I	I	I	\perp	TVINEL	
	·	INADVERTENT				\sqcup	4	I	_[_]	\Box	_]	\sqcup	— [Д.	4	4-	4	1	┸	1	\perp	1 1,550	
IBVLAL2C	BLOCK VALVE	CLOSURE	10-6	1	100		4	-	-4		4		-	-	4	+	+	4-	+	4	+	+	TUDNEL	
IBVIAL3C	BLOCK VALVE	INADVERTENT CLOSURE	10-6	١, ١	100	⊦⊣	\dashv	-	-			1	\vdash	-+	+	+	+	+	+	+	┰	+	TUNEL	

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NÚMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

TABLE A-II (contd.)

REACTOR PROTECTIVE SYSTEM FOR LOSS OF FORCED FLOW

<u> </u>		· · · · · · · · · · · · · · · · · · ·	0	RIMARY FAILUI	nt .	_								RY EV		10.1	*	-	-			.	
EVENT NAME	EVENT COMPONENT	FAILURE MODE	FAILURE RATE	FAULT DURATION	ERROR FACTOR	FIRE	1,000	EARTHQUAKE	STEAM	HI-TEMP	PRESSURE	HUMIOITY		ונע נע	NI NI		11 OH	CORRUSION	INDUCED VOLT	VIBRATION	SOLVENT	LOCATION	PEMARAS
IBYLALAC	BLOCK VALVE	INADVERTENT CLOSURE	10-6	1	100				\exists	\dashv	_	\exists	4	4	1	1	1	-				NORTH PIPE TURNEL	
IBFLALOX	BY-PASS VALVE	LEFT OPEN	10-4	1	100						\exists		\exists				E					TUDEL	
IPTLALOF	DPT4 - 3A PRESSURE TRANSMITTER	FAILS TO FUNCTION	10-5	720	30								_	\pm	t		-				=	PIPE TUILEL	
İDCLALOF	POWER SUPPLY	LOSS OF FUNCTION	10-6	720	30						_		1	\pm	\pm	╁	L	L				TUITIEL RSS CAB RSS CAB.	
ICMLALOF	SC4 - 3A SIGNAL COMPARATOR	FAILS TO SCRAM FAILS	10 ⁻⁵	720	30						\dashv		_	#	#	#	F	L			$ \downarrow $	RSS CAB.	
IRSLALOØ	RESISTOR, 200Ω IA4 - 3A	OPEN FAILS TO	_10-7	720	30				\equiv			\exists	1	\mp	1	Ŧ	F				Ħ	PSS CAB. 10. COUSOLE RSS CAB.	
IAMIALOF	ISOLATION AMPLIFIER	BUFFER	10-5	720	30		H	_		Н	1		4	+	F	1	F	F		F	Ħ	NO. COUSOLE	
ICALALOS	INTERCONNECTING CABLES PSSC4-3A	SHORT CIRCUIT		720	30							\exists	\exists	\exists	+	Ŧ	F				\exists	CABINET	
IDCLALOF	S. C. POWER SUPPLY FLUX RUN PERMIT	FUNCTION RELAY FAILS	10-6	720	30																	ON	•
ISSIALOC	SELECTOR SWITCH	CLOSED	1.0	/DEMAND	50									1	$^{+}$	\downarrow	È	L	L			CONSOLE	
	FAULTS IN HIGH ΔP HETWORK CHANDEL #A	· ·				Ė										-	-	E					
IPPLAHOR -	PRESS. IMPULSE LINES	RUPTURE	0.1	720	30	_						_		+	+	+	_	-		-		TUNEL TUNEL	
IPPIAHOP	PRESS TAPLITUSE LINES BV4 - 3A - 1H	PLUGGED	0.1	_1	30									#	+	+	F	F	F			I minner I	
IBVIANIC	BLOCK VALVE BV4 - 3A - 2H	CLOSED	1.0	.1	100	E								1	1	+		L				NORTH TUNNEL NORTH	· · · · · ·
IBVLAH2C IBVLAH3C	BLOCK VALVE BV4 - 3A - 3H BLOCK VALVE	CLOSED	1.0	1	100	_	_		_					#	_	\pm			<u> </u>	-		NORTH	
IBVLAH4C	BV4 - 3A - 4H BLOCK VALVE	CLOSED	1.0	1	100	F	-						\dashv	\dashv	+	+	Ħ	F	F			TUNNEL NORTH TUNNEL	V 19
ІВРІАНФХ	BPV4 - 3A BY-PASS VALVE (N.C.)	LEFT	10.0	· 1	100	E	E									E	E	E	E			NORTH TURNEL NORTH PIPE	
IPTLAHOF	DPT4 - 3A PRESSURE TRANSMITTER	FAILS TO TRANSMIT HIAP SIGNAL	10.0	720	30									\pm	\pm	\pm	\perp					TUNNEL	· · · · · · · · · · · · · · · · · · ·
IDCLAHTF	PST4 - 3A POWER SUPPLY SC4 - 3A	LOSS OF FUNCTION	1.0	720	30		_	E		-				\Rightarrow	+	+	+	t		F		TUNNEL INSTRUMENT CABINET CONSTRUMENT	_ ,
ICMLAHOF	SIGNAL COMPARATOR	FAILS TO SCRAM	10.0	720	30					H				士	土	上	土	Ĺ		╘	廿	NORTH CONS.	

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)

PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

REACTOR PROTECTIVE SYSTEM FOR LOSS OF FORCED FLOW

TABLE A-II (contd.)

		Ï	Р	RIMARY FAILU	RE	Γ			_	-	- ;	SECON	DARY	EVEN	1 (10	, , ,	*					T		
EVENT	EVENT COMPONENT	FAILURE MODE	IFM&LURE BATE	FAULT DURATION	ERROR FACTOR	FIRE	FLOOD	CAKI KUDANE	STEAM	11-15H7.		KUMIDITY FRFF7146	MISSILE	PIPE WILL	WIND	DUST	RADIATION	CORROS I ON	INDUCED VOLT	WIBRATION	SOLVENT		CATION	REWARKS
IRSLAHOF	RESISTOR, 200Ω	FAILS OPEN	0.1	720	30		\pm	1	1	Ŧ	1		l	E		\exists			1	1	\pm	⊢ NO	TRUMENT ABINET RTH CON IRUMENT	; 5.
IAMLAHOF	IA4 - 3A ISOLATION AMPLIFIER	FAILS TO BUFFEE	10.0	720	30	H	+-	+	+	╁	╁	+	+	\vdash	Н	\dashv	\dashv	\dashv	+	+	+	ار"2 8″ ⊢	ABINET.	<u>[</u>
						H	\mp	Ŧ	#	4	1	1	\perp	\Box	\Box	\exists	4	4	7	\downarrow	_	٦.,	R-29	
ICALAHO5	INTERCONNECTING CABLES PSSC 4 - 3A	SHORT CIRC.	0.1	720	30			_		1	Ϊ		\pm	\vdash				╛	\perp	\pm	\pm	T CA	ABINET RTB COS RSS BINET RSS RSS BINET	
IDCLAHOF	S. C. POWER SUPPLY FLUX RUN PERMIT	FUNCTION RELAY	1.0	720	30		+	+	╁	╁	╁	+	╁	╁	\vdash	-	-	+	\dashv	+	+		BINET	
isslaho¢	SELECTOR SWITCH	PALLY PALLY OPEN	1.0	/demand	50_	Ħ	\perp	1	1	#	1	1	T		\Box	\dashv		4	_	#	\mp		NSOLE	
							\perp	\pm	\pm	\perp	\pm	土	土			コ	⇉	⇉	1	士	\pm	1_		
	[LOW INLET PRESSURE] CHANNEL A					H	+-	+	╁	+	+	+	+	╁┤	Н	\dashv	\dashv	\dashv	+	+	+	┥		
IPPMALOR	PRESS. IMPULSE LINES	RUPTULE	0.1	720	30		\pm	1	\pm	\pm	I	\pm	\pm	$oxed{\mathbb{H}}$			\exists		\exists	\pm	\pm	Ţ	IPE UNNEL	
IPPMALOP	PRESS. IMPULSE LINES	PLUGGED	0.1	720	30	\vdash	+	+	\pm		\pm	1	1	-		\exists	\dashv	-	1	+	士		IPE UNNEL	
IBVMALOX	BLOCK VALVE	INACVERTENT CLOSED	100.0	2	100		+		\pm	\pm	\pm	\perp					\exists	\exists			\pm	φ	UNNEL OBJE E LOOK E NEOLE LOOK E NEOLE LOOK E NEOLE E	·
IDVMALOX	DRAIN VALVE	INAL-VERTENT OF EN	100.0	2	100	H	+	+	╁	+	+	+	╁	+-	Н	\dashv	\dashv	\dashv	+	+	+	c∳	NSOLE LOOR	
ITZMALOF	PT4 - 1A PRESS. TRANSMITTER	FAILS TO FUNCTION	10.0	720	30	П	-	7	7	\mp	Ŧ	\top	-		П	\dashv	\dashv	\dashv	7	7	7	PNO	RTH LUNNEL	
IDCMALOS	PTV4 - 1A POWER SUPPLY	SHORT TO	1,0	720	30	H	#	+	+	\mp	‡	+	Ŧ	\vdash		\dashv	\dashv	7	7	#	丰	S	RSS RINET	
	PQ4 - 1A	POWER IMPROPER CALL SETTING		<u>.</u>		Ħ	Ŧ	†	#	1	#	\perp	╪	\vdash	П	\dashv	_	_	7	7	7	3	RSS	
IPOMALOX	SIGNAL CONDITIONER PAS4 - 1A	FAILS TO	100.0	· · · · · ·	100	\Box	1	$^{\pm}$	\pm	士	\pm	\pm				ᆿ	⇉	コ	#	\Rightarrow	丰	1 c8	RSSH	
ICMMALOF	SIGNAL COMPARATOR BZ - P4 - 1A	FAILS TO	10.0	720	30	\vdash	+	+	+	+	+	+	+	\vdash	Н	\dashv	┥	-	+	+	+		BINET DUTH RSS	
IBZMALOF	BUFFER AMPLIFIER	FUNCTION RELAYS	10.0	720	30	Ħ	#	\mp	Ŧ	-,	,	\perp	1	F	П	\dashv	7	7	7	7	7	CA	BINET ON	
ISSMALOC	F. R. PERMIT SWITCH	CLOSES	100.0	/DEMAND	30		\pm	$^{+}$	#	Ę		丰	#	\pm		\exists	_	\dashv	#	#	\pm		NSOLE STRUM	
ICAMALOS	INTERCONNECTING CABLES	SHORT CIRCUIT	1.0	720	30	H		\pm	\pm	\pm	\pm	\pm	\pm	\perp				1	\pm	\pm	\pm	. CA	RINET	
IOTMALOV	IY - P4 - 1A ISO. TRANSFORMER	DC VOLTAGE SHIFT	1.0	720	30	H	_	\pm	\pm	\pm	\pm	\pm	\pm		Н		\exists	\exists	\pm	\pm	\pm	1 88	ISOLE LOOR	
						\vdash	+	+	+	+	+	+	+	+	Н	\dashv	\dashv	\dashv	\dashv	+	+	\dashv]
	[HIGH INLET PRESSURE] CHANNEL A					H	\perp	+	F	Ŧ	Ŧ	\mp	+	F	H			-	1	\perp	\mp	\pm		
IPPMAHOR	PRESS. IMPULSE LINES	RUPTURE	0.1	720	30	H	\pm	\pm	\pm	1	Ŧ	\pm	Ε			\exists	\exists	\exists	\exists	\exists	\pm		Pipe Unnel	

REACTOR PROTECTIVE SYSTEM FOR LOSS OF FORCED FLOW

T				RIWARY FAILUI	of	Γ.					۲,	COND	ADY 6	VENT	,,,,·,	.,*					\neg	Τ	
EYENT NAME	EVENT COMPONENT	FAILURE Mode	FAILURE RATE	FAULT OURATION	ERROR Factor	FIRE	61000	37700475	HI-1EMP	PRESSURE			MISSILE	WHIP	Tall	1	CORROSION	INDUCED VOLT	VIBRATION	SOLVENT		LOCATION	MEWARKS
					_				上			\Box					1			コ	コ	PIPE	
LPPMAHOP	PRESS, IMPULSE LINES	PLUGGED	0.1	720	30	\vdash	-	-	4	╄	┾-	-	\vdash		-	4	+	-	L			TUNNEL	
IBVMAHCX	BLOCK VALVE	INADVERTENT CLOSED	100.0	,	100	Н	+	┽		╁	⊢	╁	⊢	-+	+-	┿	+-	├	┝╌	\rightarrow	\dashv	NORTH CONSOLE NORTH CONSOLE FLOOR	• •
	BLOCK VALVE	INADVERTENT	100.0			1-1	-	- -	+	+	1-	1-	\vdash		+	†	+	1		7		- RUKYR	
IDVMAHÓX	DRAIN VALVE	OPEN	100.0	2	100				1								1			1		CALSON .	
	PT - 4 - 1A	FAILS TO							\perp					\Box I							\Box		
ITZMAHOF	PRESS. TRANSMITTER	FUNCTION	100.0	720	30			1	\perp	\Box	匚		\Box		T	\perp		L			_]	CONSOLE RSS CAB. CONSOLE RSS CAB.	
	PTV - 4 - 1A	ABNORMAL		,,,	20	⊢⊦		- -	+	+	-	-		+	+	+-	4-	⊢		-		CONSOLE	
IDCMAHTS	POWER SUPPLY	VOLTAGE IMPROPER	1.0	720	30	H			+-	╁	⊢			\dashv	+	╁	+	\vdash	⊢	-	\dashv	KSS CAB. 1	
IPOMAHOX	PQ4 - 1A SIGNAL CONDITIONER	SETTING	100.0	720	100	\vdash	-	+	+	+	+	1-	1-1	\dashv	+	+	+	1	┢	-+	\dashv	CONSOLE RSS CAB	
THUMBUA .	PAS - 4 - 1A	FAILS				1-1	\neg	十	+-	1	+	一	1	$\neg +$	\top	+-	1		┢	_		CONSOLE CONSOLE CONSOLE CONSOLE	
ICMMARSE	SIGNAL COMPARATOR	TO SCRAM	10.0	720	30	П	\neg	丁	_	-	\top				_	7						RSSSCAB.	
	BZ - P4 - 1A	FAILS							1								\Box		Ĺ			CHREAL	
IBZMAHOF	BUFFER AMPLIFIER	- ISOLĂTE RELAYS	_10.0_	720	30			\perp				\perp			\Box	\perp					\Box	RSS CAB.	
	FLUX RUN PERMIT	CLOSED		{		\Box		_	77		↓_	\perp	Ш			\bot	1	ــــ			_	ON	
ISSMAHOC	SELECTOR SWITCH		100.0	/ DEMAND	50	\sqcup	-		- 6	+	₩	 		$-\!\!\!+$	-		+-	₩	<u> </u>		_	CONSOLE	
	INTERCONNECTING CABLES	SHORT	1.0	720	30	⊢Ⅎ	-+-	+	┿	╁	┼	₩	\vdash	-+			+	┼-	-	\dashv		INSTRUMENT CABINETS	
ICAMAHOS	IY - P4 - 1A	DC VOLTAGE		120	30	┨	\dashv	+	6	╁	╁	+-	╌┤	-+	+	╁╌	+	╁	-	-	-	CONSOLE	
I TMAHOV	ISO. TRANSFORMER	SHIFT	1.0	720	30	H		-	+5		+	1-	Н	-†	\top	+-	T	 	┢	-	╛	FLOOR	
	PSV4 - 1A	SHORT TO		 		1	\neg	_	+	\top	†	t	\vdash			十	+		Г	\Box		NORTH CABINET NORTH RSS	
IDCMAHCS	COMP, POWER SUPPLY	GROUND	1.0	720	30			\perp							工							CABINET	
	BZV2 - 1	SHORT TO				<u></u>		_	Т.	_	1_	!	Ш	_1		┸	┷	 	Ļ	\perp	_	RSS	
IDCMAHAS	D. C. POWER SUPPLY	GROUND	1.0	720	30	₩		-	┵	4-	+-	<u>Ļ</u> .	1	1	_		4	<u> </u>	<u> </u>	\dashv		CABINET	
		ľ		1		Н			┰	1	↓	╀	\vdash	-+	-	+	+	╄	⊢-	\rightarrow	_	1	
	[LOW EMERGENCY FLOW]					\vdash			+	+	+-	+	Н	-+		+	+	+	⊢	\vdash			
Į.	CHANNEL A	,		i !		П		.	┰	+	+-	1	Н		\dashv	1	+-		\vdash		\neg		
	Olar Miles					П	$\neg \top$	7	┰	1	1	1	П	_		1	\top	1		\Box		PIPE	
IPPNALOR	IMPULSE LINES	RUPTURE,	0.1	720	30			\perp														TUNNEL	
						\Box		\perp				ـــــ	\Box					↓_	L.	\perp		PIPE	
IPPNALOP	IMPULSE LINES	PLUGGED	0.1	720	30		+	+		<u> </u>	+		$\vdash \vdash$	-+	-	+	+	⊢	⊢-	\vdash	_	_TINNEL.	
. '	FE - 4 - 14			,,,		$\vdash \vdash$		+	+	╄	+	┰	\vdash		-	+	+	⊢	⊢-		-	PIPE TUNNEL	
LORNALOP	FLOW ORIFICE	PLUGGED	0.1	720_	30	\vdash		+	+	+	╁	+	┝╼╂	-+	+	+	+	+	-		-	PIPE	
IXVNALOX	VALVE MANIFOLD	INADVERTENT CLOSURE	100	YDEMAND	100	Н	\dashv	+		+	+	+	╁╌┤	+	+	+	+	\vdash	┢	\vdash		TUNNEL	
- LAVINGIAIA	FT - 4 - 14A	FAILS		, DECOMP		П	\neg	_	\top	\top	T	1	П	\vdash †		\top	1	1	T		-	PIPE	
ITZNALOF	FLOW TRANSMITTER	TO FUNCTION	10	720	30					\top						I		Ŀ	\Box			TUNNEL	
	FS - 4 - 14A	ERRONEOUS							1			\Box			\Box							TUNNEL RSS (R-29) CABINET	
IPSNALFX	LOW FLOW SWITCH	SETTINGS	100	YDEMAND	50	\Box		\perp	I				\Box	\Box	\perp	I			Ľ	\Box I	_]	CABINET	
	FAS - 4 - 14A LOW	FAILS TO	10	770	30	ш		+	4	1	_	╂	Ш	-4		+	+		┞-	├ ─┼	_	RSS (NE 29)	
IAVNALOF	FLOW ALARM MODULE	FUNCTION	10	720	30	┖			Щ.	_l	ــــــــــــــــــــــــــــــــــــــ	<u>i </u>	لـــا			_i_	ـــــــــــــــــــــــــــــــــــــ	ــــــــــــــــــــــــــــــــــــــ	Ц.	ш		CABINEI	

			P	RIMARY FAILU	AE							SE	CONDA	RY E	VENT	(10-1	,*							
EVENT NAME	EVENT COMPONENT	FAILBRÉ Mobe	FAILURE RATE	FAULT OVERTION	ERROR Factor	FIRE	F1000	EARTHQUAKE	STEAM	HI-TEEP	PRESSURE	KUBIDITT	FREEZING	MISSILE	PIPE WHIP	TINO Dist	RADIATION	CORROSION	INDUCED VOLF	VIBRATION	SOLVENT		LOCATIO»	REMARKS
IDCNALFS	FSU - 4 - 14 A POWER SUPPLY	SHORT TO POWER	1.0	720	_30				7					-	7	+	\vdash				\exists	\dashv	NORTH RSS (R-29) CABINE	
IPSNALPC	LOW INSTRUMENT WATER PASS - 24 - 15A KOXKA RESBUCE	FAILS CLOSED	10	720	30				\exists				\exists	-	\pm							\exists	RSABINE 291 RSABINE 291 RSABINE 291	
IAUNALPF	PAS - 4 - 5 1 5 A ALARM MOBULE	FAILS TO FUNCTION	1.0	720	30	Н	\exists		_				\exists	\pm	\pm		L					\exists	RSS (R-19)	
IPSNALPS	PSU - 4 - 15A POWER SUPPLY	SHORT TO POWER	1.0	720	30		\equiv		\Rightarrow					1	\pm	\pm	\perp						RSS (RE2)	<u> </u>
IOTNAL4V	FIY - 4 - 14A ISOLATION TRANSFORMER FIY - 4 - 15A	VOLTAGE SHIFT VOLTAGE	1.0	720	30				1	1				\Rightarrow	\Rightarrow	\pm					\exists		RSSABINET	
IØTNAL5V	ISOLATION TRANSFORMER	SHIFT RELAYS	1.0	720	30				+	\exists			\dashv	#	#	#	F				\dashv	\dashv	RSS (R-19) CABINE	
ISSNALFC	FLUX RUN SWITCH INTERCONNECTING	FAIL CLOSED SHORT	10	//DEMAND	30	Ħ	\exists		7	=			#	#	#	#	+					\dashv	ROOM AMPLIFIER	
IWRNALOS	WIRING	CIRCUIT	1.0	720	30			#	_	_				#	#	+	+	E				\dashv	ROOM AMPLIFIER	<u></u>
ISDNALI\$	skotr ⁶ eeteer	OPEN	10	720	30	П		\dashv	\dashv	\dashv	-		\exists	7	#	+	F	H			_	\exists	ROOM	
	LOW EMERGENCY FLOW							\exists	1					4	\exists	\pm	E	E				\exists		
IPPNBLOR	CHANNEL B IMPULSE LINES	RUPTURE	0.1	720	30			#	1					#	#	$^{+}$	+				\exists	\exists	PIPE TUNNEL	
IPPNBLOP	IMPULSE LINES	PLUGGED	0.1	720	30	Н	\exists		\dashv	7	\dashv		\exists	\dashv	7	+	H				\exists	\exists	PIPE TUNNEL	-
IORNBLOP	FE - 4 - 14 FLOW ORIFICE	PLUGGED	0.1	720	30	\prod									\exists	_	\vdash					\exists	PIPE TUNNEL	
IXVNBLOX	VALVE MANIFOLD	ENADVERTENT CLOSURE	100	'/DEMAND	100					_				\exists	\pm	+	+					\exists	PIPE TUNNEL	
ITZNBLOF	FT - 4 - 14B FLOW TRANSMITTER FAS - 4 - 14B	FAILS TO FUNCTION FAILS TO	10	720_	30				1	\exists			\rightrightarrows	\Rightarrow	\Rightarrow	#	╁				\dashv	\exists	PIPE TUNNEL	
ICMNBLOF	SIGNAL COMPARATOR FSU - 4 - 14B	FUNCTION SHORT TO	10	720	30				1					#	#	‡	+						RSS (R=30) CABINET	
IDCNBLOS	POWER SUPPLY FIY - 4 - 4B	POWER DC VOLTAGE	1.0	720	30			H	7	\dashv				\dashv	\dashv	+	-			\Box	1	7	RSS (R-30) CABINET SOUTH RSABINET	
IOTNBLOV	ISOLATION TRANSFORMER TRANSMITTER REMOTE AMPLIFIER	SHIFT FAILS TO	1.0	720	30	\square	\Box	\dashv	\exists	\dashv	\dashv	\dashv	\dashv	\dashv	干	+	F	H	H		-	\exists	RSABIRETOD SOUTH CABIRETOD	_
IRANBLOF	12U - 2	FUNCTION SHORT TO	1.0	720	30			\exists	\exists					\exists	\perp	I	L	E			\exists		CABINET"	
IDCNBLOS ISDNBLFØ	POWER SUPPLY R-28 E.F. SEQUENCE DETECTOR	POWER	1.0	720 720	30			\exists	\downarrow				\exists	\exists	\exists	1	£					\exists	SOUTH SABINETON AMPLIFIED	

^{*}PROBABILITY, OF SECONDARY EVENT DCCURRING (UPPER NUMBER)
PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

~

REACTOR PROTECTIVE SYSTEM FOR LOSS OF FORCED FLOW

			F	RIJARY FAILU	RE				·		SE	CONDA	RY EVE	NT (1	0 . 1	*							
EVENT MANE	EVENI COMPONENI [LOW OUTLET PRESSURE] CHANNEL B	FAILURE MODE	FAILURE RATE.	FAULT OURATION	ERROR Factor	F18E	EARTHOUARE	STEAM	HI-1EUP	PRESSURE	HUMIBITY		MISSILE PIPE WHIP		0051	RADIATION	CORROS 10M	INDUCED VOLT	VIBRATION	SOLVENT		LOCATION	BEWARKS
IPPMBLOR	PRESS. IMPULSE LINES	RUPTURE	0:1	720	30	H	F	\top		П		$\overline{}$	1				\neg	\dashv		\dashv	٦.	PIPE TUNNEL	
IPPMBLOP	PRESS. IMPULSE LINES	PLUCCED	0:1	720	30	H		E	_					E			\exists	\exists		\exists	\exists	PIPE	
IBVMBLCX	BLOCK VALVE	INADVERTENT CLOSURE	100	1	100		1	_					_	\vdash			\exists			1	٩	SOLTH DNSOLE FLOOR	
IDVMBLØX	DRAIN VALVE	INADVERTENT OPEN	100 ·	1	100			\pm					#	\vdash					\exists	\dashv	_ c	SOUTH PLOSE	
ITZMBLOF	PT - 4 - 1B PRESS. TRANSMITTER	FAILS TO FUNCTION IMPROPER	10.	720	30		t	士	E	\Box			#	\vdash				4	\exists	#	P	SOUTH WALL SOUTH	
IPOMBLOX	PQ4 - 1B SIGNAL CONDITIONER PTU4 - 1B	IMPROPER GAIN SETTING SHOLT TO	1.0	720	30		+	-	L			#	#								ع 🗆	SOUTH RSS ARINET SOUTH RSS	
IDCMBLTS	POWER SUPPLY & CALIB. PAS4 - 1B	GROUND FAILS TO	1.0	720	30		1	+	E			H	+	H				=	\exists	#	4ء	ABINET SOUTH RSS	- · <u> </u>
ICMMBLSF	SIGNAL COMPARATOR PSV4 - 1B	SCRAM SHORT TO	10	720	30.		+	丰	-	H		Ħ	#	1						4	٦,	RSS ABINET SOUTH RSS ABINET	
IDCMBLCS	COMP. POWER SUPPLY BZ - P4 - 1B	GROUND FAILS TO	1.0_	720_	3.0	-	Ŧ	+	<u> </u>	H	_		丰	+					=	7	٦,	ABINET SOUTH	
IBZMBLOF	BUFFER AMPLIFIER BZU2 - 1	ISOLATE SHORT TO	10	720_	. 30	-	Ŧ	F	F	Н	_	H	+	-				\exists		4	-	SOUTH RSS ABINET SOUTH ABINET	
IDCMBLAF	D. C. POWER SUPPLY IY - P4 - 1B	GROUND DC VOLTAGE	1.0	720	30		Ŧ	F		Н	_			-						-]_	POSTH	
IOTMBLOV	ISO. TRANSFORMER INTERCONNECTING	SHIFT SHORT	1:0	720	30		L	E	<u> </u>		E	\exists	\pm	E							3	ABINET SOUTH RSS	
IWRMBLOS	CABLES FLUX RUN PERMIT	CIRCUIT RELAYS FAIL	1.0	720	30	士	\pm	上				\pm	\pm	\vdash						\exists		ABINET ON	
ISSMBLOC	SELECTOR SWITCH	ELOSED	100	/DEMAND	50:		\pm	上		\Box			士							\exists	+	CONSOLE	
	[HIGH OUTLET PRESSURE] CHANNEL B			·			\pm							Ė	E					4	7		
IPPMBHOR'	PRESSURE IMPULSE LINES	RUPTURE	0.1	720	30		+	\pm					\pm	F			\exists				\pm	PIPE TUNNEL	
IPPMBHOP	PRESSURE IMPULSE LINES	PLUGGED INADVERTENT	0.1	720	30	井	+	#		H			#	上					_		7	PIPE TUNNEL SOUTH	1. 11
IBVMBHCX	BLOCK VALVE	CLOSURE	100.0	11	100	1	+	丰	-	H		H	#	 -					_			SOUTH SOUTH SOUTH	
Трамвнфх	DRAIN VALVE PT - 4 - 1B	OPENING FAILS TO	100.0	1	100		\pm	\pm				Η.	Ŧ	E	_]	SOUTH ONSOLE FLOOR SOUTH	<u> </u>
ITZMBHOF	PRESS. TRANSMITTER PTU - 4 - 1B	FUNCTION SHORT TO	100.0	720	30		\perp				E		\pm							\exists	s	ONSOLE FLOOR OUTH ABINET	
IDCMBHTS	POWER SUPPLY & CALIB.	GROUND	1.0	720	30	\Box	\perp	工						Ľ.	<u> </u>						c	ABINET	

REACTOR PROTECTIVE SYSTEM FOR LOSS OF FORCED FLOW

	T					Г										1	*					- 1		
1 1		' '		R MARY FAILU	RE	⊢	_				_	SEC	0804	RYE	ENT C	7	} -	_		_	_	_		
EVENT.	EVENT COMPONENT	FAILURE MCDE	FAILURE RATE	FAULT DURATION	ERROR Factor	FIRE	F1000	EARTHQUAKE	STEAM	HI-TEMP.	PRESSURE	KUMIDITY	FREEZING	BISSILE	A IND	ısno	RADIATION	CORROSION	INDUCED VOLT	VIBRATION	SOLVENT		LOCATY ON	REMARES
	PO4 - 1B	IMPROPER CAIN				\Box	\top	\dashv	_	T	\neg	T	\neg		\neg	1	Τ				П		SQUTA	
IPOMBHOX	SIGNAL CONDITIONER	SETTING	100.0	720	30	\Box	_	T	\dashv	7	_	_	_	\dashv		\top	+	${}^{+}$	_	1	М	\dashv	SOUTH RSS CABLYET	
	PAS4 - 1B	FAILS TO		720			\top	寸	┪	\neg	\dashv	\neg	寸	\dashv	\neg	1	\top		Т	—	П	\neg	SOUTH	
ICMMBHSF	SIGNAL COMPARATOR	SCRAM	10.0	720	30					\Box		·	_1	\Box									SOUTH SOUTH	
[]	PSU4 - 1B	SEORT					\perp		\Box	\Box								oxdot					200131	
IDCMBHCS	COMF. POWER SUPPLY	TO_GROUNE	1.0_	720	30	Щ.		4	4	_	_	_	_	\perp		4_	╙	1_	_	_			CABINET_	
1 1	EZ - P4 - 1B	FAILS TO				\vdash	-	_	4	_	_	_	_	_	_	╄-	╀-	<u> </u>	ļ	_	Ш	_	RSS	
IBZMBHOF	BUFFER AMPLIFIER	ISCLATE	10.0	720	30	\vdash		-	-		-	-	_}	4	-		-	 	┡	1	ш	\vdash	CABINET SOUTH RSS SOUTH RS	
	BZU2 - 1	SHORT		١ ٠		$\vdash \vdash$	-	+	+	-+	-	-+	-	-	+	+	+		⊢	-	Н		_RSS	
LICMBHAS	D. C. POWER SUPPLY IY - P4 - 1B	TO GROUND DC VOLTAGE		. 720	30		+	+	+	\dashv	\dashv	\dashv				╁	╁	┼	⊢	⊢	\vdash		SOUTH	
іотмвноу	ISO. TRANSFORMER	SHIFT	1.0	720	30	∺	+	-+	-+	\dashv	\dashv	-		\dashv	+-	╁	+	+-	⊢		┨	-	SOUTH RSS CABINET	
IQIIIBIOV	INTERCONNECTING	SHORT	<u>, , , , ,</u>	120		\vdash		+	-+	-	-	-+	+	\dashv	+	+-	+	╁	┪	\vdash	Н	-	SOUTH RSS	
IWRMBHOS	CABLES	CIRCUIT	1.0	720	30		+	\dashv	\dashv	_	-	-		十	+	+-	+	1	1	1	Н		RSS CABINET	
	FLUX RUN PERMIT	FATES		7.5		1-1	十	\neg	\neg	_		7		$^{+}$	\top	\top	1	+	┢	 	М	_	ON	
ISSMBHOC	SELECTOR SWITCH	CLOSED	100.0	DEMAND	50	\vdash		\top	\dashv	\neg	ヿ	_		_	\top	\top	1	t	\vdash	т	⇈		CONSOLE	
			•										\neg	\neg		1		1	Г					
								\Box		\Box	\Box			\Box	\perp		\perp			<u></u>				
	FAULTS IN LOW AP	1				\sqcup		_	_	_		_	·		┵	1		┖	L	L	\Box			
	NETWORK CHANNEL B					\vdash		4	-+		-	\rightarrow	\rightarrow	-	+-		+	╀—	┞		Н		CO.::::::	<u> </u>
			_			⊢⊹	-	_	+	-		-		-	+	+.	+	╙	₽	├	ш		SOUTE TUNNEL	
IPPLBLOR	PRESS. IMPULSE LINES	RUPTURE	0.1	720	30	\vdash	-	+	-	-	-1	\rightarrow	\rightarrow	\dashv	+	+	+	┼—			Н		TUNNEL	
IPPLBLOP	PRESS. IMPULSE LINES	PLUGGED	0	720	30	\vdash	-	+	+	\dashv	\dashv	-+	-	-+	+	+	╀	1	⊢	╁			PIPE	
Trrescor	FRESS. INFOLSE LINES	INADVERTENT	V.	/20	30	\vdash	+	\dashv	+	+	\dashv	+	-+		-+-	╈	+	1	\vdash	 	Н		SOUTE TUNNEL SOUTE	
IBVLBLOC	VALVE MANIFOLD	CLOSURE	100	720	100	\vdash	+	\dashv	\dashv	+	_	-+	-	-+	+	+	+	+	┪	-	Н		-PARE.	
10.02200	DPT4 - 3B	FAILS TO		120		\vdash	1	十	_	7	_	_	\dashv	一	_	十	✝	t	t	1	Н		TUSKEL SOUTE TUSKEL TUSKEL R-3C RSS CAB.	
IPTLBLOF	PRESSURE TRANSMITTER	FUNCTION	10	720	30	<u> </u>		\dashv	7	┪	\neg	┪	\dashv	-	_	+-	 	┼	_	1	Н		TUNNER	
	PST4 - 3B	LOSS OF						\neg	\neg		\neg					\top	Т	T					R-30	
IDCLBLOF	POWER SUPPLY, XTR	FUNCTION	1.0	720	30				\Box	\Box				\Box		\perp							KSS CAB.	
	SC4 - 3B	FAILS TO		,		Ш								工						<u> </u>			R-3C	
ICMLBLOF	SIGNAL COMPARATOR	FUNCTION	10	720	30	LJ:		_	_	_					_	_	╄	┺	_	╙	Ш		RS CAL. RS CAL. RS CAL. RS CAL. RS CAL.	
		FAILS				\vdash	_	+	4	_	_	_	\rightarrow	\dashv	_	+	╄-	1_		ļ.,	L	Щ	RSS CAE.	
IRSLBLOO	RESISTOR, 2000	OPEN	0.1	720	30	 :			4	_	-	-4	-	\dashv	+	+	╀	╄	ļ.,	₩	⊢	_	so, ççəs.	
	IA4 - 3B	FAILS TO				\vdash	-+-	+		\dashv	\dashv	\dashv	-	-+	+-	+-	+-	+	╁	┼	Н		RSS CAE.	
IAMLBLOF	ISOLATION AMPLIFIER	BUFFER	10	720	30	$\vdash \vdash$	+	+	\dashv	-		-+	-+	\dashv	+	+	+	+	₩	\vdash	┢┉┤		50, <u>-</u> 6755	
IDCLBLOF	PSSC4 - 3B	LOSS OF FUNCTION	1.0	700	20	 	+	+	+	+	\dashv	-			+	+	+	1	╁	⊢	Н	\dashv	SS ÇĀF.	
TUCTBLOK	POWER SUPPLY, S. C.	SHORT	1.0	720	30	$\vdash \vdash$	+	+	+	-+	-+	-+	\dashv	-+	+	+	╁	+	t	t	Н	\dashv	R-30	
ICALBLOS	INTERCONNECTING CABLES	CIRCUIT	0.1	720	30		+	+	+	\dashv	\dashv	-+	-+	-+		+	+	1	H	t	Н	-	85 CAE R-30 85 CAE R-30 85 CAE 8-30	
	FLUX RUN PERMIT	CIRCUIT RELAY FAILS CLOSED	ш.т.			\vdash	+	+	+	┪	+	\dashv	-t	\dashv	\top	+	+	1-	1-	t	\vdash		ON COSS.	
ISSLBLOC	SELECTOR SWITCH	EAUSED	1.0	/DEMAND	50	\sqcap	_	十	_	┪	_	_	\dashv		+	 	1-	1	1	†	М	_	CONSOLE	
							I	\exists	丁		_	7	\neg	\exists	1	1	I	L.	\Box					
		L					Τ	\Box			二		\Box	\Box	I	\perp								

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)
**ROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

REACTOR PROTECTIVE SYSTEM FOR LOSS OF FORCED FLOW

	 ,,		P	RIMARY FAILU	RE							SEC	ONDA	RY EV	ENT (10-1	,*								<u> </u>
EVENT Made	EVENT COMPONENT FAULTS IN HIGH ΔP NETWORK CHANNEL B	FAILURE MODE	FAILURE RATE	FAULT DURATION	ERROR Factor	FIRE	F1000	EARTHOUAKE	STEAM	Ht-TEBP.	PRESSURE	1			1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		NO: LI	CORROSION	INDUCED YOLF.	VIBRATION	SOLVENT		LOCATION	REWAR	ıs
TPPLBHOR	PRESS. IMPULSE LINES	RUPTURE	0.1	720	30	H	7	7	7	\dashv	4	4	7	1	+	F	F					7:	SOUTH		
IPPLBHOP	PRESS. IMPULSE LINES	PLUGGED	0.1_	720	30				\exists			4	4										PIPE FIPE FIPE FIPE FIPE SOUTH PIPE FIPE FIPE		
IBVLBHOC	VALVE MANIFOLD	INADVERTENT CLOSURE	100	720	100		+	_	1		_	\exists	_	\pm	_		L					1	PIPE		
IPTLBHOC	DPT4 - 3B PRESS. TRANSMITTER	FAILS TO FUNCTION	10	720	30	H	_	\exists	1	\dashv	\dashv	_	\exists	\pm	\pm	Ł	_				Н		PIPE		
IDCLBHOF	PST4 - 3B POWER SUPPLY, XTR	LOSS OF FUNCTION		720	30	H	+	\dashv	\Rightarrow	\dashv	\dashv	\dashv	4	#	\dagger	t						R	R-30 SS CAB. R-30NS- SS EARs.		
ICMLBHOF	SC4 - 3B SIGNAL COMPARATOR	FAILS TO FUNCTION FAILS	10_	720_	. 30	H	_	#	_		_	4	+	#	#	+	1					B	SŠ ČÅRs. R−30		
_ IRSLBHOФ	RESISTOR, 200Ω IA4 - 3B	OPEN FAILS TO	0.1	720	30	H	#	7	7	\exists	_		4	_	‡	+	-	-	_	-		- R	S CAB.		-
IAMLBHOF	ISOLATION AMPLIFIER PSSC4 - 3B	BUFFER LOSS OF	10	720	30	H	7	\dashv	4	=	\dashv		_		-	#	\vdash	-		-	Н		SS CARS. R-30		
IDCLBHOF	POWER SUPPLY, S. C.	FUNCTION SHORT	1.0	720	30		\exists	\exists	\exists	\exists		\equiv		_		\perp			_				E CONS. R SONS. R SONS. R SONS. R SONS. R SONS. R SONS. R SONS. R SONS.		
ICALBHOS	INTERCONNECTING CABLES FLUX RUN PERMIT	CIRCUIT EAILS ECOSED	0.1	720	30		\pm		\exists		\exists			\pm	\pm	+	E					_	ON		
ISSLBHOC	SELECTOR SWITCH	CLOSED	1.0	/DEMAND	50		#	_	\dashv		_			_	_	‡	F	‡_			H		CONSOLE		
							1	4	#		_		\dashv	#	#	#	F	上				\dashv			
						H	-	-	_	-	4	\dashv	7	7	+	+	-	F	H		П	7			
	,					H	\exists		\exists					\dashv	+	+	-	\vdash	ļ. —		\Box				
						Н			_			_				1	\vdash	L	L	_		\exists			
							\exists	\exists			\exists	\exists	\exists	\pm	\pm	\pm	\perp	\pm		\vdash		4			
						H	#	\Rightarrow	_					\pm	1	1	${}$	ŧ	E			٦.			
		ļ .					#	\dashv	4	\exists				_	#	‡	丰	‡	F	F		1		-	
						H	1	4	1				H	#	#	+	1	1	-	F		H			
		1			<u> </u>	H		\dashv	\dashv	\exists		\exists	H	7	#	1	F	+	1	H		Π-			
		<u> </u>	<u> </u>	<u> </u>			土								\perp	士	1	1	1			二			

5.3.1 System Description The emergency flow system is comprised of two pumps, their associated controls, the check valves, manual valves, flow element, and piping connected in parallel with the primary coolant Pumps A and B as shown in Figure A-4. The pumps derive power from a battery-backed power source and a diesel power source, both of which supply power during reactor operations. Either pump, by operator selection, can get power from either source, and in the event of loss of any one source, a pump will automatically switch to the other source.

During reactor operations, one pump is normally operating, and the other is on standby. If the operating pump fails, the standby pump is automatically started. Either pump can be designated for operation by manual positioning of selector switches.

Either of the two pumps (2,000 gpm each) is capable of providing adequate coolant circulation for the removal of reactor decay heat.

- 5.3.2 System Analysis. The emergency flow system was evaluated to determine the probability that either one of the emergency flow pumping systems would not be available when required to respond to a loss of primary coolant flow. Included in the analysis were the instrumentation, controls, and power sources for the pumps.
 - (1) <u>Assumptions</u>. For purposes of the analysis the following as sumptions were made and ground rules established:
 - (a) Emergency Pump 644-64 is the operating pump, and Pump 644-65 is the standby pump.
 - (b) If either of the pumps operates, it will provide adequate coolant flow; that is, flow is not degraded.
 - (c) The primary coolant pumps do not fail in a manner that would block emergency flow in that particular primary loop. The emergency coolant must flow through the primary pumps.
 - (2) Fault Tree and Fault Summary. Figure A-8 and Table A-III are the fault tree and the fault summary, respectively, developed for the "loss of emergency flow" event. Numerous single events can fail the emergency flow system. For the most part these are relatively low probability events; however, some single events, if they occur, will result in the loss of flow accident and failure of the emergency flow systems. These result from some piping and valves being common to both the primary coolant system and the emergency flow system. Highly potential common mode failures occur in the emergency flow control system because both pumps are controlled from a single control unit, and cables associated with both pumps are routed in the same conduit.




Fig. A-8 Emergency flow system fault tree.




Fig. A-8 Emergency flow system fault tree (contd.).

TABLE A-III

LOSS OF EMERGENCY FLOW

			P	RIMARY FASLUI	RE						s	ECON	DARY	EVENT	(10	· , *							
EVENT NAME .	EVENT COMPONENT	FA?LURE MODE	FAILURE RATE	FAULT DJRATION	ERROR . Factor	FIRE	£1000	EARTHQUAKE	X - 15KP	PRESSURE	HIMEDITA	FREEZING	HISSILE	dtHB 3did	S I NO	0051	RADIATION	INDUCED YOU	VIBRATION	SOLVENT		LOCATION	REMARES
DXVOO35X	OPERATIONAL ERROR MANUAL VALVE P35	INADVERTENT CLOSED	10-3	1	10		\dashv	7	#	1	Ļ	+			\dashv	7	7	1	T	口		PIPE	
DXV0740P	MANUAL VALVE P40	PLUGGED	10-8	1	300	H	4	7	+	+	-	+	\vdash	- <u>5</u>		7	+	+	╀	F	F	CUBICLE	
DCV0238P	CHECK VALVE P38	PLUGGED	10-4	1	300			7	Ξ	-	F	$oxed{\mathbb{L}}$		-5 -2 -5	\exists		\pm		+	\vdash		EMERG. CUMP CHICKE PUMP	
DCVOP38R	CHECK VALVE P38	RUPTURE	10-8	720	10	Н		\perp		-	┢	\pm	Ė	-2		\pm	\pm	\pm		士	L	PUMP CUBICLE EMERG.	
DCVOP38C	CHECK VALVE P38	CLOSED	10-4	1	30	H		\pm	‡	\pm	+	土		-5 -2		\pm	+	+	+	\vdash		CURTOR PUMP	
DXVOP36C	MANUAL VALVE P36	CLOSED	10-4	11	3			#	#	+	t	#		-5 -2 -5		#	#	+	+	#	\vdash	CUBICLE	
DXVOP40X	OPERATIONAL ERROR VALVE P40 OPERATIONAL ERROR	INADVERTENT CLOSED INADVERTENT	10-3		100	Ħ	\dashv	_	╪	+	ŧ	Ť	1.	-2 -2 -5		+	#	+	+	+	F	EMERG. PUMP CURICLE PIPE	
DXVOP26X	MANUAL VALVE P36 EMERG.	CLOSED NO	10-3	1	100	H		\dashv	+	1	F	\mp	\vdash	-2 -5	\dashv	\exists	7	+	\mp	F	F	TIMBLE	
DPM0064F	FUMP 64 PUMP 64	OUTPUT SHORT TO	10 ⁻⁵	720	10	5			+	-	E		E	-2	\exists	+	-	\pm	E		-	PROCESS CHIP RM. PROCESS CHIP RM. PROCESS CHIP TO	BRIN PONTE INK
DCA0064S	POWER CABLE PUMP 64	GRND. (OR PWR	10 ⁻⁷	720	10	1	\exists		\pm	-		\pm				\pm	+	t	╁	\pm		PUNTE BY. CHY 18	SAME CONDUIT
DCA00648	POWER CABLE EMERG. PUMP CH	OPEN SHORTS TO GRND. (OR. PWR.)	10-7	720 720	10	- 5 1	\exists	#	‡	+	ļ	‡	‡	H		#	+	‡	+	+	L	PUMP RM. PROCESS ROOM	CONTROLS FOR BOTH PUMPS IN SAME PANEL
DMS0064B	EMERG. PUMP C+1	OPENS	10 ⁻⁶	720	10	Ė	\dashv	+	+	+-	Ŧ	‡	+		\exists	#	#	+	+	+	-	PROCESS ROOM	SAME PANEL
DSWPBLAS	PUMP C TO 1 PNL A	SHORTS	10-7	720	10		\exists	\mp	\pm	-	F	\pm		H	\exists	1		1	+			PROCESS	
DCA0061S	CONTROL CABLE 61	SHORT TO GRND.	10 ⁻⁷	720	10				\pm	\pm		\pm				\Rightarrow		\pm	+			PROCESS ROOM PROCESS	
DCA0062S	CONTROL CABLE 62 POWER CABLE	SHORT TO GRND. SHORT TO	10 ⁻⁷	720	10			#	+	\pm	+	‡	╘			#	#	+	+	\pm		ROOM	POWER CABLES 63
DCA0063S	63 POWER CABLE	GRND.	10-7	720	10	_5 1	H	#	‡	‡	+	Ì	Þ			7	‡	‡	+	#	H	ROOM PROCESS C+1 TO ELEC. BLDC C+1 TO ELEC. BLDC	EN SAME CONDUIT
DCA0063B	63 POWER CABLE	OPEN SHORT TO	10 ⁻⁶	720	10	5		\mp	+	+	Ŧ	丰	\mp	H	\exists	#	7	Ŧ	\mp	F	F	PROCESS CE	POWER CABLES 63 AND 66 IN SAME CONDUIT
DCAQQ66S	66 POWER CABLE	GRND.	_10 ⁻⁷	720	10	1		+	\pm	\perp	F	Ŧ		F		7	\pm	I	\pm	\pm		PROCESS CE PROCESS CE MCC-3A MCC-3A	IN SAME CONDUIT
DCA0066B	66 PUMP POWER CABLE	OPEN SHORT TO	10 ⁻⁶	720	10	\sqsubseteq			\perp		E	$oxed{\bot}$						E	E		E	MCC-3A PROCESS CI	· · · · · · · · · · · · · · · · · · ·
DCAOG655	65 PUMP POWER CABLE	GRND.		720	10			+	\pm	\pm	+	\pm				_	1	\pm	\pm	\pm		PROCESS CI	LE
DCAOC65B	65	OPEN	10-6	_720	10_	L	LL	i_		Т.				Ц.	Ш	_		Щ.				PUMP CUBIC	ILE

^{*}PROBABILITY OF SECONDARY EVENT OCCURRING (UPPER NUMBER)

PROBABILITY OF COMPONENT FAILURE GIVEN SECONDARY EVENT (LOWER NUMBER)

LOSS OF EMERGENCY FLOW

<u> </u>		<u> </u>	P	RIMARY FAILU	RE				.*			3 E C	ONDA	R' EV	(N1 (10.1	,*	_						
EVENT MAME	EVENT CCWPONENT	FAILURE Mode	FAILURE RATE	FAULT DURATION	ERROF FACTOR	FIRE	FL000	EARTHQUARE	STEAM	HI-TEMP				ונ	TING CHIP		11.0N	CORROSION	INDUCED VOLT.	VIBRATION	SOLVENT	,	LOCATION	REMARKS
	DISTRIBUTION PN1		_7			_5	1	\downarrow		5	コ	\Box		1		ı							ELEC.	
NCBPNFFS	FF CIRCUIT BREAKER DISTRIBUTION PN1	SHORT	· n ⁻⁷	720	10		-	+		1	\dashv	-+	\dashv	-	+	-5 1		-	_	₩	Н	-	BLDG.	
NCBPNFFB	FF CIRCUIT BREAKER	OPEN	10 ⁻⁶	720	10	\Box	\pm	#		5	#	\rightrightarrows	\Rightarrow	\pm	士	-5							ELEC. BLDG.	
NCBPNFFX	OPERATIONAL ERROR CK + BKR FF	ENADVERTEMT OPEN	:0-3	1	100	_5 1	+	\pm		1	\pm	\pm	\pm	\pm	+	_1 -5				L			ELEC. BLDG.	
NCB3A3ES	MCC-3A COMPT.3E CK + BKR	SHORT		720	10	\vdash	+	+	+	Ŧ	_	4	\dashv		5	\vdash	\vdash			F	Н	\blacksquare	COMPRESSOR BLDG.	
NCB3A3EB	MCC-3A COMPT.3E CK + BKR	OPEN	±0-6	720		H	-	1	\pm	\pm	\exists		1	7	5 2	E	E		Е				OMPRESSOR BLDG.	
NCB3A3EX	OPERATIONAL ERROR MCC-3ACD 3E	OPEN	.0-3	1	100	H	\pm	\pm	\pm	4	\exists	\exists	\pm		5								OMPRESSOR BLDG.	
NBSMC3AF	MCC-3A	NO POWEE	<u>:</u> 0 ⁻³	720	10	\vdash	+	\pm	\pm	\perp	1	\exists	+	<u> </u>	5 2	Ł	L						COMPRESSOR BLDG.	
DXVOP41P	MANUAL_VALVE P41	PLUGGED	:o ⁻⁸	1	300	\vdash	+	+	\pm	+	\pm	-	-+	7-	5 2	Ł						-	CUPICLE CUPICLE	
DCVOP39C	CHECK VALVE P39	CLOSED	∴o ^{−4}	1	300	\vdash	\pm	\pm		-		\dashv		<u> </u>	5 2	\vdash							CUBYCLE	
DXVOP41X	OPERATIONAL ERROR MANUAL VALVE P41	ENADVERTENT CLOSED	:0-3	1	100	H	+	+		\perp		\dashv	+		3	E			\vdash	-			PUMP CUBICLE	
DXVOP37C	MANUAL VALVE P37	CLOSED	0-4	1	30	H	+	7	7	7	-	\dashv	\dashv		5 2	\vdash	\vdash	F	F				PUMP CUBICLE	
DXVOP37X	OPERATIONAL ERROR MANUAL VALVE P37	INADVERTEMT CLOSED	0-3	1	100	H	\mp	\pm	\mp	7	\dashv	-	7		5 2	E	E				Н		EMERGE PUMP CUBICLE CUBICLE	
DCVOP39R	CHECK VALVE P39	RUPTURE	-0-8	1	100			\pm	+	_	\dashv	-	\exists					_					COBICTE	
DCVOP39P	CHECK VALVE P39	PLUGGED	10-4	1	100	\vdash	+	-	-	\dashv		-	\exists		2						Н		CUBICLE	
DPM0065F	EMERGENCY PUMP 65	NO OUTPUT	10-5	720	10		_		\perp	_	-		\dashv		2	L		Ŀ			Н		CUBICLE CUBICLE	
NBSO027F	DISTRIBUTION PANEL 348-27	NO POWER	10-3	7.	10	5	+	+		5		\dashv	\dashv	+	+	\vdash	\vdash	\vdash	_	-	\vdash		ELEC. BLDG.	
FCNDUITI	FIRE DUE TO SHORT IN CONDUIT #1		10-5	1	10	H	-	7	\exists		7	7	7	7	Ŧ	-	E	E					·	
FCTLPNL1	FIRE IN EMERG. PUMP C+1 PN1		10-5	1	10	H	+	4		+	7	\exists	7	+	+	\vdash	E	E		E			PROCESS C+1 ROOM	
DXVOP31R	MANUAL VALVE P31	RUPTURE	10 ⁻⁸	720	10	H	\mp	7	7	7	7	7	-	-	Ŧ	\vdash	-			F			PIPE TUNNEL	
DXVOP31P	MANUAL VALVE P31	PLUGGED	10-4	1	300	H	Ŧ	Ŧ	\mp	\mp	7	7	\dashv	Ŧ	-	-	-	-		-			PIPE TUNNEL	
DPP0020P	PIPE 20	PLUGGED	10-10	720	300	H	\top	\mp	\mp	\mp	7	\dashv	\dashv	-	-	F	-	ŀ	_	\vdash	Н		PIPE TUNNEL	
DPPOO2OR	PIPE 20	RUPTURE	10-10	720	300	H	Ŧ	7	\exists	7	7	4	7	7	Ŧ	F	F	F		F	Н	-	PIPE TUNNEL	

LOSS OF EMERGENCY FLOW

		1	PI	RIMARY FAILU	RE							SECO	NDARI	r EVENT	(10)·1 ₎ 3	ķ						
EVENT NAME	EYENT COWPONENT	FAILURE MODE	FAILURE RATE	FAULT OURATION	ERR OR Fact or	FIRE	F1000	EARTHOUARE	STEAM	HI-1EMP				EH IP	W1M0	DUST		CURROSION	INDUCED VOLT	VIBRATION	SOLVENT	LOCATION	REMARKS
DØRFE14P	ORIFICE FE-14	PLUGGED	10 ⁻⁵	1	_100	H	4	7	Ŧ	+		_	+	- ₅				_	_	_		PUMP CUBICLE	
DXVOP4OR	MANUAL VALVE P40	RUPTURE	_10 ⁻⁸	720	10	Н	1	+	\pm	-	\blacksquare	\blacksquare	-	-5 -2				3	\exists		\pm	PUMP - CUBICLE	
DXVOP41R	MANUAL VALVE P41	RUPTURE	10-8	720	10	\Box	\pm		\pm	+	\mp	\mp	\pm	-5 -2		\exists	\exists	\exists				PUMP	
DXVOP36R	MANUAL VALVE P36	RUPTURE	10-8	720	10	\mathbf{H}	+	-	\pm	+	\pm	\pm	\pm	-5 -2	_	\dashv	_			-	\pm	CUBICLE	,
DXVOP37R	MANUAL VALVE P37	RUPTURE	10-8	720	10	\vdash	\pm		\pm	\perp	\pm		\pm	-5 -2				\exists			\pm	PUMP CUBICLE	
DPP0021R	PIPE 21	RUPTURE	10-10	720	300		\pm	\pm	\pm	_	\pm	\pm	\pm	\pm							\pm	PIPE	1
DPP0021P	PIPE 21	PLUGGED	10-10	720	300	\vdash	+		\perp		\pm	+	+									PIPE	
DXVC035P	MANUAL VALVE	PLUGGED	10-4	_ 1	300	\vdash	\perp	\pm	\pm	\pm	-	_	\pm									PIPE TUNNEL	
DXVC035R	MANUAL VALVE P35	RUPTURE	10-8	720	10		\exists	\pm	\pm	-	1	-	\pm	\perp				_				PIPE TUNNEL	
DXVOP34R	MANUAL VALVE P34	RUPTURE	10-8	. · 720	10	Н	\pm	-	_	-	-	\perp	\pm				_					PIPE TUNNEL	
DXVOP34P	MANUAL VALVE P34	PLUGGED	10-4	1	300	Н	\pm	\pm		_	\pm	\pm	\perp		_							PIPE TUNNEL	
						\vdash	\perp	\perp					\perp	1=									
							\pm	÷	\pm	\perp	\pm	\pm	\pm	+-								<u> </u>	
							\pm	\perp	\pm	\pm	\pm	\pm	\pm										
	·	ļ	<u> </u>			\vdash	\pm	\pm	\pm		_		±								_	_	
	•					Н	\pm	\pm	\pm	t	\pm	\pm	+	+-									
							\exists		\pm	\pm	\pm	\pm	\pm						_				
						Н	\pm	1	1	+	\pm	\pm	\pm	上	_								
						Ы	-	-	\pm	\pm	\pm	\pm	\pm	上		E					\perp		
			·			Н	\pm	\pm	\pm	+	\pm	\pm	\pm	\pm				<u> </u>					
	· <u></u>		·			Н	\pm		\pm	\pm	\pm	\pm	1.	1								1	
	· · · · · · · · · · · · · · · · · · ·						\dashv	Ŧ	\mp	4	4	-F	Ŧ	#	_	F	F			-	\vdash	4	

- (3) <u>Data.</u> Data used to quantify the emergency flow system fault model were obtained from Reference A-1.
- 5.3.3 Results. The emergency flow system was analyzed using the SAMPLE computer code in the same manner explained in Section 5.1.3. The result for the median probability value for failure of the emergency flow system to respond to a loss of flow accident is 6×10^{-3} /operating cycle. The 90% range is from 2×10^{-3} to 6×10^{-2} /operating cycle.

The probability reported is the probability that the emergency flow system is not available when called upon following a loss of primary flow accident. The probability that the system will fail to continue operating after accident initiation is assumed to be unity or that it will not fail after emergency flow is established. The significant contributors to the reported probability were:

- (1) Closure or plugging of P35 manual valve.
- (2) Fire in Conduit 1 or emergency pump panel.
- (3) Open motor starter to emergency pumps.
- (4) Shorts in emergency circuits.

6. EVENT SEQUENCE PROBABILITIES

The probability of occurrence of the three event sequences on the event tree, Figure A-3, was found using the SAMPLE code. The code was used to calculate probabilities of failure for combined fault trees. Therefore, any dependence between systems is taken into account.

The probability of success is equal to one minus the probability of failure. For the automatic safety system with a probability of failure of 6.2 x 10⁻⁶, the probability of success would be 0.9999938 or very close to unity. The probability of success used in all cases was, therefore, unity.

The following symbols are used in the calculations for probabilities.

	Success	Failure
Loss of Primary Flow		$P_{\mathbf{\hat{F}}}$
Automatic Reactor Shutdown System	P_{S}	$P_{ar{s}}$
Emergency Flow System	$^{\mathbf{P}}_{\mathbf{E}}$	$P_{\bar{E}}$

Sequence one is the sequence of events that should happen following a loss of primary flow accident. The automatic reactor shutdown system and the emergency flow system function properly. The probability of S_1 occurring is equal to

$$P_{\overline{F}} \times P_{S} \times P_{E} = P_{\overline{F}} \times 1 \times 1 = P_{\overline{F}}$$

as reported in Section 5.1.3, the median probability value of $P_{\bar{F}}$ is 2 x 10^{-2} /operating cycle, and the 90% range is 7 x 10^{-3} to 1 x 10^{-1} /operating cycle.

Sequence two is the sequence in which the automatic safety system functions properly but the emergency flow system fails. To find this probability, the fault trees for the loss of primary flow accident and failure of the emergency flow system were combined. The combined trees were analyzed with the SAMPLE code and the median probability value is 8×10^{-4} /operating cycle. The 90% range is 1×10^{-4} to 2×10^{-2} /operating cycle. This probability cannot be found by

$$P = P_{\overline{F}} \times P_{S} \times P_{\overline{E}}$$

because the emergency flow system is not independent of the primary system. Sequence three results if the automatic reactor shutdown system fails. The emergency flow system is not included because core melting will occur regardless of the emergency flow system action. Manual actuation of the shutdown system is available to prevent this sequence from occurring, but has not been credited in this study. To determine the probability of S3, the fault trees for loss of primary flow and the automatic safety system were combined and analyzed with the SAMPLE code. Because of complete independence between the two systems, the median value of probability can be found by combining the probability values obtained by evaluating individual trees; that is:

$$P = P_{\overline{F}} \times P_{\overline{S}}$$

but the range cannot be found without combining the trees and using the SAMPLE code. The resultant median probability value is 1×10^{-7} /operating cycle and the range is 3×10^{-8} to 9×10^{-7} .

7. CORE DAMAGE

Once sequence three, (S3) in Figure A-3, is shown to result in core melting, the amount of core damage becomes important. The degree of core damage expected under given conditions can be obtained by use of a computer program designated RELAP4^[A-3], written in FORTRAN IV, that describes the behavior of water-cooled nuclear reactors during postulated accidents such as loss of coolant, loss of flow, pump failure, or power transients.

7.1 Model

RELAP4 was used to evaluate the ETR loss of flow accidents (with and without emergency flow and with and without reactor scram).

The reactor core was modeled as 20 volumes connected to upper and lower plenums representing the reactor tank as shown in Figure A-9. The two plenums, Volumes 1 and 2, were input as timed volumes with the inlet pressure held constant and the outlet pressure increased to model the flow coastdown expected when two primary coolant pumps are used. The flow coastdown expected with two pumps operating is shown in Table A-IV.

7.2 Geometric Description

Volumes, flow areas, elevations, and volume heights are necessary geometric input parameters to RELAP4. The volume geometries are described in Tables A-V and A-VI, and the core section geometries are described in Table A-VII. Junction data are listed in Tables A-VIII and A-IX.

7.3 Heat Transfer

A heat conductor model is used to account for heat transfer to and from the fluid in given volumes. The heat addition rate to the fluid is calculated as the product of the surface flux and the heat transfer area at the conductor surface adjacent to the fluid. The bases for the ETR heat transfer correlations are as follows.

7.3.1 <u>Bases.</u> RELAP4 has several correlations which are used in calculating heat transfer rates to the coolant. The correlation used is dependent on the thermodynamics of the coolant. The correlations and the applicable conditions are discussed in the RELAP4 manual [A-3].

The user can choose the correlations to be used to calculate the critical heat flux and subsequent film boiling heat transfer rates. For this analysis, the Savannah River correlation [A-4] was used to predict the critical heat flux, and the Dougall and Rohsenow correlation [A-5] was used to predict the film boiling heat transfer rate.

For the core, a metal-water ratio of four was used to calculate the mass of metal. This mass was incorporated adjacent to the core reflector volumes. The upper and lower plenums used the vessel as a heat sink.

7.3.2 <u>Slab Modeling</u>. In RELAP4 all heat generating or absorbing surfaces adjacent to volumes are termed slabs. Slabs having internal heat generation capabilities (core slabs) are assigned additional properties. Characteristic properties are defined for slabs. Table A-VII defines the volumes adjacent to the slabs and the characteristic properties defined for each slab.

The geometry values listed in Table A-X were derived from the basic data listed on system drawings. The core slab properties were derived from the data in Table A-XI. The derivation of the heat generation values in Table A-XII was based on the power profiles measured in the Engineering Test Reactor Critical (ETRC) Facility for the SLSF core at the beginning of life. Table A-XII shows the makeup of each volume and the power distributions in the elements and corresponding volumes. The vertical profile was established from vertical flux profiles measured in the ETRC.




Fig. A-9 ETR core model for risk evaluation.

SET	NUM PT8	TIPE (SECTROS)	PRESSURE (PSIA)	TEMPERATURE (DEG F)	MINTURE QUALITY	MIXTURE LEVEL (FEET)	
1		0.	\$176560E+03	.137000E+05	e.	.900000E+01	(AOF 5
	20	.20000CE+00	.1710006+03	.1379006-03	n ,	9600005+61	
		.3100055+90	1722006+83	.137000E+U3	0.	.900000-+01	
		-50000CE+00	.175500E+03	.137000E+03	0.	.90000n2+G1	
		.700006E+00	.1786006+03	.13700nF+03	0	.9000005+01	
		.900000€+00	.182000E+03	.1370006+03	า	.9000002+61	
		.1500066+01	.191000E+03	.137000E+63	5	9000005+61	•
		.2000005+01	.1960n0E+03	137000E+05	5 ,	9000005+01	•
		.25000CE+01	.149600E+05	.137000E+03)	9000000+01	
		.30000CE+01	.2025006+03	.137000E+03	5	.900000=+01	-
		.35000CE+01	.204500E+03	.137000E+03	5	.9600005+61	
		4000006+01	.206000E+03	.137000E+03	ງຸ້	.900000E+C1	
		.50000CE+01	.208400E+33	.137000F+03	5	790000CE+C1	
		.60000CE+01	.209700E+03	.1370002403) ,	900000E+C1	•
		.70000CE+01	.210700E+03	.137000E+05	5,	900006E+C1	
		.80000CE+01	.2112G0E+03	.137000E+03	ο,	.9000005+61	
		.100000€+02	.2118006+03	.137000E+03	5 ,	.900000E+C1	ı
		.15000CE+02	.212400E+03	.137000E+03	ə,	.900000E+C1	
		.260000E+92	£0+300E+03	.137000E+03)	.900000E+C1	
		.60000CE+03	.213400E+03	.137000E+03	٥.	.900000±+C1	
2		0.	.205500E+03	.110000E+03	٥,	. 254000E+65	(VOL 1

9

TABLE A-V

CORE VOLUME GEOMETRY

VOLUME DATA ACTUALLY HEING USED.

	S=PH FRIC	FLOW APEA (FT**2)	EGUIVALENT DIAMETER (FT)	LENGTH (FT)	L/2A (FT**=1)	HORIZ. AREA (FTRHZ)	TEMPERATURE (F)	SATURATION TEMP. (F)
1	0	.102400F+03	.114184E+02	.173262E+'02	.846004E=01	.785044E+02	.110000E+C3	.384070É+03
5	0	\$128008+02	.7249786+01	.705488E+01	.921796E-01	351333E+02	.137000E+05	.353647E+03
3	. 0	.388000E=01	10-3000005-01	.670103E+00	.P63535E+01	.531353F +01	.183700E+03	.371685E+03
4	0	348000E=01	.200000E=01	.832474E+00	1072781+02	38CUOOE-01	155800E+03	374415E+03
5	,0	.388000E-01	.200000E=01	.832474E+00	.107278E+02	.38C000E-01	.129600E+03	377077E+03
. 6	0	.388900E-01	.2000006-01	.111856E+01	.144144E+02	.620060E=01	.112400E+03	.379675E+03
7	0	.194000E+00	.200000E=01	.1041246+01	.268360E+01	.1975816+00	.174000E+03	.37214RE+03
8	0	.194000E+00-	.200000E=01	-104124E+01	1.248350E+01	.1923B1E+00	140000E+03	.375757E+03
9	0	.194100E+00	.200000E=01	.104124E+n1	.268360E+01	.197381E+00	.115000E+03	.378615E+03
10	. 0	.155000E+00	.200000E-01	.103871E+01	.33506RE+01	.153333E+00	.174600F+03	.372149E+C3
11	Q	.155000E+00	.200000E-01	.103871E+01	.335068E+01	.15333E+00	.134000F+03	.3757576+03
-12	0	.155000E+00	.20000000-01	.103871E+01	.33504RE+01	.15333E+00	.1142008+03	.378H16E+03
13	0	.233n00E+00	.200000E=01	.103P63E+01	.222881E+01	.23C476E+00	1714006+63	1 .3721466+03
14	0	.233000E+00	.2000006-01	.103863E+01	.222881E+01	.2304766+00	.135000E+03	.375757E+03
15	· Q	.233000E+00	.200000E=01	.103H63E+01	.222881E+01	.23C476E+00	.113500E+03	3788166+03
16	ď	.310000E+00	.2000006-01	.1561296+01	.251821E+01	.3082806+00	.150100E+03	.3730625+03
17	0	.310000E+00	.2000001-01	.156129E+01	10+3158165	.316254E+00	120110E+03	.37H385E+03
18	Q	.272000E+00	10-3000008-01	.3113976+01	.572421E+01	.278547E+00	.1350006+03	.375757E+03
19	Q	.2720005+00	.170000E-01	.311397E+01	.572421E+01	.272347E+00	.132000F+03	.375757E+03
20	Q	.350000E+00	.170000E+01	.310000E+01	442857E+01	.348875E+00	.130000E+03	.375757E+03
.51	. 0	.110400E+01	.200000E=01	.312500E+01	.141531E+01	.11C932E+01	.115000E+03	.375757E+03
55	٥	.110400E+01	200000E=01	.312500E+01	.141531E+01	.11C932E+01	.112000E+03	.375757E+03

TABLE A-V1

CORE VOLUME GEOMETRY

1	VOLU	HE U	ATA PACTU	ALLY BRING USED.					1
NUM INDX OEP	VOL	BUBL	TIME	PRESSURE	ENTHALPY	VOLUME .	HEIGHT	MIXICHE	ELFVATION
1							_		
3 2 0	1	1	2	.205500E+03	.785127E+02	.1774206+04	.226000£+02	\$0+10006+02	.816000E+02
1	2	1	1	.170500E+03	.105371++03	.316290E+05	.9000006+01	.9000000€+01	.695760E+02
\$ 2 0	3	2	0	.17700E+03	.15210HE+03	10-3000035-	78000000+00	.780000E+00	.785200E+02
6 2 0	4	5	9	.185700E+03	.1241896+03	.323C00E=01	.850000E+00	.8500001+00	.792700E+02
7 2 0	5	2	0	189+100E+03	.9862836+02	.323cn9E=01	.850000E+00	. 450000E+00	.601000E+02
8 2 0	. 6	S	ŋ	.19500CE+03	.8087921+02	.434COOF=01	.70000CE+00	.7000006+00	.8r9300F+G2
9 2 0	7	2	٥	.17810UE+03	1474016+03	.202conE+00	.105000E+01	.105000F+01	.745200E+02
10	8	2	0	.186000E+03	.1084076+03	2C2C00E+03	.105000E+01	.105000E+01	,795500E+0Z
11 2 0	, 9	2	0	.1930006+03	.834674E+C2	.5650005+00	.105000E+01	.1050906+01	.80580CE+U2
12 2 0 .193000E+03 .82669SE+02 .1e1C00E+03 .105000F+01 .105000E+01 .765200E+01 13 2 0 .178000E+03 .13978SE+03 .242C00E+03 .105000E+01 .105000E+01 .765200E+01 14 2 0 .186000E+03 .104410E+03 .242C00E+03 .105000E+01 .105000E+01 .795500E+01 15 2 0 .193000E+03 .819713E+02 .242C00E+03 .105000F+01 .105000E+01 .805800E+01 16 2 0 .180000E+03 .118483E+03 .484000E+03 .157000E+01 .157000E+01 .800700E+01 17 2 0 .192000E+03 .885541E+02 .484000E+03 .156000E+01 .156000E+01 .800700E+01 18 2 0 .186000E+03 .101414E+03 .847C00E+03 .311000E+01 .311000E+01 .785200E+02 19 2 0 .186000E+03 .100416E+03 .847C00E+03 .311000E+01 .311000E+01 .785200E+02 20 2 0 .186000E+03 .984200E+02 .168500E+01 .311000E+01 .311000E+01 .785200E+02 21 2 0 .186000E+03 .834494E+02 .345C00E+01 .311000E+01 .785200E+02	10	S	0	.178000E+63	.1429916+03	.161C00E+03	.105000E+01	.105000E+01	.785200E+02
13 2 0 .178000E+03 .139785E+03 .242C00E+00 .105000E+01 .105000E+01 .785200E+00 14 2 0 .186000E+03 .104410E+03 .242C00E+00 .105000E+01 .105000E+01 .795500E+00 15 2 0 .193000E+03 .819713E+02 .242C00E+00 .105000F+01 .105000E+01 .805800E+00 16 2 0 .18000E+03 .118483E+03 .484000E+00 .157000E+01 .157000E+01 .785200E+00 17 2 0 .192000E+03 .885541E+02 .484000E+00 .156000E+01 .156000E+01 .800700E+00 18 2 0 .186000E+03 .101414E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+00 19 2 0 .186000E+03 .100416E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+00 20 2 0 .186000E+03 .984200E+02 .168500E+01 .311000E+01 .311000E+01 .785200E+00 21 2 0 .186000E+03 .834494E+02 .345000E+01 .311000E+01 .311000E+01 .785200E+00	-11	2	0	.186000E+03	.10640HE+03	.1+1000E+00	.105000F+01	.105000E+01	.7955006+02
14 2 0 .186000E+03 .104410E+03 .242C00E+00 .105000E+01 .105000E+01 .79500E+00 15 2 0 .193000E+03 .819713E+02 .242C00E+00 .105000E+01 .105000E+01 .805800E+00 16 2 0 .180000E+03 .118483E+03 .484000E+00 .157000E+01 .157000E+01 .785200E+00 17 2 0 .192000E+03 .885541E+02 .484000E+00 .156000E+01 .156000E+01 .800700E+00 18 2 0 .186000E+03 .101414E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+00 19 2 0 .186000E+03 .100416E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+00 20 2 0 .186000E+03 .98420CE+02 .168500E+01 .311000E+01 .311000E+01 .785200E+00 21 2 0 .186000E+03 .834494E+02 .34500E+01 .311000E+01 .311000E+01 .785200E+00	12	2	0	.193@00E+U3	.826695E+02.	.1610006+00	.10500000+01	.105000E+01	.H05H00E+02
15 2 0 .193000E+03 .819713E+02 .242C00E+00 .105000F+01 .105000E+01 .805800E+0 16 2 0 .180000E+03 .118483E+03 .444000E+00 .157000E+01 .157000F+01 .7M5200E+0 17 2 0 .192000E+03 .885541E+62 .444000E+00 .156000E+01 .156000E+01 .800700E+0 18 2 0 .186000E+03 .101414E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+0 19 2 0 .186000E+03 .100416E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+0 20 2 0 .186000E+03 .984200E+02 .168500E+01 .311000E+01 .311000E+01 .785200E+0	13	S	0	.1780nnE+03	.139785E+03	. 2420006+00	.105000E+01	.1050006+01	.765200E+02
16 2 0 .180000E+03 .118483E+03 .484000E+00 .157000E+01 .157000E+01 .7M5200E+01 17 2 0 .192000E+03 .8M5541E+02 .484000E+00 .156000E+01 .156000E+01 .800700E+01 18 2 0 .186000E+03 .101414E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+01 19 2 0 .186000E+03 .100416E+03 .847000E+00 .311000E+01 .311000E+01 .785200E+02 20 2 0 .186000E+03 .984200E+02 .168500E+01 .311000E+01 .311000E+01 .785200E+02 21 2 0 .186000E+03 .834494E+02 .345000E+01 .311000E+01 .311000E+01 .785200E+02	14	2	0 -	.186000E+03	.104410€+03	.2420008+05	.105000E+01	.10500nE+01	.7955#0E+02
17 2 0 .192000E+03 .885541E+02 .484C00E+00 .156C00E+01 .156C00E+01 .80070CE+01 18 2 0 .186000E+03 .101414E+03 .847C00E+00 .3110C0E+01 .3110C0E+01 .7852C0E+0 19 2 0 .186000E+03 .100416E+03 .847C00E+00 .3110C0E+01 .3110C0E+01 .7852C0E+0 20 2 0 .186000E+03 .9842CCE+02 .1685COE+01 .3110COE+01 .3110COE+01 .7852COE+0 21 2 0 .186000E+03 .834494E+02 .345CCOE+01 .3110COE+01 .3110COE+01 .7852COE+0	15	5	0	.193000E+03	.819713E+U2	.242000E+00	.105000F+01	.105000E+01	.405400E+02
17 2 0 .192000E+03 .885541E+02 .484C00E+00 .156C00E+01 .156C00E+01 .80070CE+01 18 2 0 .186000E+03 .101414E+03 .847C00E+00 .3110C0E+01 .3110C0E+01 .7852C0E+0 19 2 0 .186000E+03 .100416E+03 .847C00E+00 .3110C0E+01 .3110C0E+01 .7852C0E+0 20 2 0 .186000E+03 .9842CCE+02 .1685COE+01 .3110COE+01 .3110COE+01 .7852COE+0 21 2 0 .186000E+03 .834494E+02 .345CCOE+01 .3110COE+01 .3110COE+01 .7852COE+0	16	2	0	180000E+03	.118483E+03	_484600E+0D	.157000E+01	.157000E+01	.7H5200E+02
16 2 0 .186000E+03 .101414E+03 .847G00E+00 .311000E+01 .311000E+01 .78520CE+0 19 2 0 .186000E+03 .100416E+03 .847G00E+00 .311000E+01 .311000E+01 .785200E+0 20 2 0 .186000E+03 .98420CE+02 .168500E+01 .311000E+01 .311000E+01 .785200E+0 21 2 0 .186000E+03 .834494E+02 .345C00E+01 .311000E+01 .311000E+01 .785200E+0	_	2	0			4840006+00	.156000E+01		.800700E+02
20 2 0 .186300E+03 .98420CE+02 .168500E+01 .311000E+01 .311000E+01 .785200E+0 21 2 0 .186300E+03 .834494E+02 .345C00E+01 .311000E+01 .311000E+01 .785200E+0	18	2	0	.186000E+03	101414E+03	.847000E+03	311000E+01	.31100nf+01	785200E+02
20 2 0 .186300E+03 .98420CE+02 .168500E+01 .311000E+01 .311000E+01 .785200E+0 21 2 0 .186300E+03 .834494E+02 .345C00E+01 .311000E+01 .311000E+01 .785200E+0	19	2	٥	<u> </u>	1004166+03	847G00E+0)	. 311000E+01	.311000E+01	.7852008+02
- Ti - Ti - Ti - Ti - Ti - Ti - Ti - Ti		. 2	Ö			.168500E+01	.311000E+01	.311000E+01	.785200E+02
- Ti - Ti - Ti - Ti - Ti - Ti - Ti - Ti	21	2	٥	.186300E+03	.834494E+02	.345C00E+01	.31100nE+01	.311000E+01	.7852006+02
			ō		· · · · · · · · · · · · · · · · · · ·	▼ "	7 _ '		.785200E+02

TABLE A-VII CORE SECTION GEOMETRICS

FUR	20	HEA	T C01	NOUETING SLABS.								
L /OL					RIGHT SUMPACE AREA, FT##2	VULUME FT##3	LEFT HYDRAULIC DIAMETER. FT	HIGHT HYDRAULI CIAMETER, FT		-	UNCTIONS R IN R	
••••					RHT HEATED ED DIAMETER, FT	LEFT CHANNEL LENGTH, FT	RIGHT CHANNEL LENGTH, FT	INIT FRACT OF HEAT REMOVED				
0	3	1	55	0 •	.510000E+01	.180000E=01	0 •	0.	0	0	5	1
0,	4	1 0	2 2 S	0 • 0 •	.640000E+01	.220000E=01	0 • 0 •	0.	0	0	3	5
0	5	1	22	0 •, 0 •	.640000.E+01	.220000E=01	0 • 0 •	0.	0	0	4	3
0	6	1 0	55	0 • 0 •	.510000E+01	.180000E=01	0.	0.	0	0	5 ·	4
0 .	7	1	2 S	0.• 0.•	.400000E+02	.135000E+00	0.	0.		0	7	6
0	8	· · i	55	· 0 • 0 •	.400000E+02	.135000E+00	0 • 0 •	0.	.0	0	8	7
.0	9	1	55	0.	.400000E+02	.135000E+00	0.	0.	0	0	9	ş
	10	. 1	55	0. ₀ 0. ₀	.320000E+02	.108000E+00	0 •	0 •	• 0	0	11	10
o ·	11	1 0	2.2	0.	.320000E+02	.108000E+00	0.	:0 .	0	0	12	11
0	12	10	2,S	0 • 0 •	.320000E+02	.108000E+00	0.	¹ 0 .	. 0 .	0	13	12
Ó	13	1.	55 0	0.	.480000E+02		_ =	0.	Ö	.0	15	14
	0 0 0	0 3 0 4 0 5 0 6 0 7 0 8	C R GEOM/OL VOL NUM L C IND 0 3 1 0 0 4 1 0 0 5 1 0 0 6 1 0 0 7 1 0 0 8 1 0 0 11 1 0 0 12 1	L R GEOM STA /OL VOL NUM INO L C R C IND IND 0 3 1 0 0 22 0 4 1 1 0 22 0 5 1 1 0 22 0 6 1 1 0 22 0 7 1 0 0 22 0 7 1 0 0 22 0 8 1 1 0 22 0 9 1 1 0 22 0 11 1 1 0 0 22 0 11 1 1 0 0 22 0 12 1 1 0 0 22	L R GEOM STW LEFT SURFACE OL VOL NUM INO AMEA, FT**2 L C R C LFT MEATED EG IND IND CLAMETER, FT 0 3 1 0 0. 0 22 0. 0 4 1 1 0. 0 22 0. 0 5 1 1 0. 0 22 0. 0 6 1 1 0. 0 22 0. 0 7 1 0 0. 0 22 0. 0 8 1 1 0. 0 22 0. 0 9 1 1 0. 0 22 0. 0 11 1 1 0. 0 22 0. 0 12 1 1 0. 0 22 0. 0 13 1 0 0.	L R GEOM STN LEFT SURFACE RIGHT SUNFACE AFEA, FT**2 L C R C LFT HEATED EG RHT HEATED EG DIAMETER, FT 0 3 1 0 0510000E+01 0 22 0. 0. 0. 0 4 1 1 0640000E+01 0 22 0. 0. 0. 0 5 1 1 0640000E+01 0 22 0. 0510000E+01 0 22 0. 0 0 6 1 1 0640000E+01 0 22 0. 0 0 7 1 0 0640000E+01 0 22 0. 0 0 8 1 1 0640000E+02 0 22 0. 0 0 9 1 1 0640000E+02 0 22 0. 0 0 10 1 0 0400000E+02 0 22 0. 0 0 11 1 1 0320000E+02 0 22 0. 0 0 12 1 1 0320000E+02 0 22 0. 0 0 13 1 0 0480000E+02	C	R GEOM STALEFT SURFACE RIGHT SUNFACE VULUME LEFT HYDRAULIC VOL NUM IND APEA, FTA*2 APEA, FTA*2 FTA*3 DIAMETER, FT	C	L R GEOM STR LEFT SURFACE RIGHT SURFACE VOLUME OI AMERICAL PROBLEM OIL VOLUME INDITION AMERICAL PROBLEM OIL VOLUME INDITION AMERICAL PROBLEM OIL VOLUME INDITION AMERICAL PROBLEM OIL INDITION AMERICAL PROBLEM OIL INDITION OIL AMERICAL PROBLEM OIL INDITION OIL AMERICAL PROBLEM OIL INDITION OIL AMERICAL PROBLEM OIL INDITION OIL AMERICAL PROBLEM OIL INDITION	Color Colo	L R GEOM SIN LEFT SURFACE RIGHT SUNFACE VOLUME COL VOLUME NUM INC. AMEA, FIX-2 AMEA, FIX-2 FIX-3 ON AMEA, FIX-2 AMEA, FIX-2 AMEA, FIX-2 FIX-3 ON AMEATER, FT CHANNEL INIT FRACTUF N. I.

10

TABLE A-VII (contd.)

CORE SECTION GEOMETRICS

12	. () - 14	1.0	22	0 • 0 •	.480000E+02	.162000E+00	0.	0,	. 0	0	16	15
13	· · · (15	1	55	0.	.480000E+02	.162000E+00	0 • 0 •	.O ₄ ,	0	0	17	16
14,	C	16	1 0	55	0.	.920000€+02	,320000E+00	0.	0.	. 0	0	19	. 18
15	(0 17	i 0	22 1	0 • 0 •	.920000E+02	.320000E+00	0.	0.	0	0	50	19
16	Ċ	18	1	25	0.	.161000E+03	.560000E+00	0.	0.	0	0	- 55	-51
17	.0	19	1	55 0	0.	.161000E+03	.560000E+00	0.	. 0.	. 0	0	24	23
18	0	9 - 20	1	55	0 • 0 •	.200000E+03	.810000E+00	0 •	0 • .	0	- 0	59	25
19	0	21	0 5	.0	0 • 0 •	.250000E+02	.135000E+02	C . O .	0 .		0	28	27
20	0	55	· 2	0	0.	.750000E+02	.395000E+02	0.	·· 0 •	.0	0	30	29
		XIAL	STAC	KS 0	F MEAT SLARS = 1 THROUGH E 5 THROUGH IF 11 THROUGH IS 14 THROUGH IS 16 THROUGH IS 17 THROUGH IS 18 THROUGH IS 19 THROUGH IS	1 DI 1 DI 1 DI 1 DI 1 DI 1 DI 1 DI	MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT MENSIONAL HEAT	TRANSFER TRANSFER TRANSFER TRANSFER TRANSFER TRANSFER TRANSFER TRANSFER TRANSFER TRANSFER			·	·	

TABLE A-VIII

JUNCTION DATA

JUNCTION	DATA	ACTUALLY	BEING	USED.
----------	------	----------	-------	-------

	FROM	7.0	Pilis	CHK	INITIAL	JUNCTION	JUNCTIUM	JUNCTION	LE4×
NUM	VOL	AOL	LEAK	AMEN	FLOA	EFL« THEY	ELEVATION.	QIAMETER .	CONTRACTION
			FILL		(LP"/SEC)	(FT++2)	(F1)	(FT)	CCEFFICIENT
1	.3	2	0	9	.841000E+02	.388000E-01	.785500E+02	.2000006=01	.100000F+01
2	4	3	0	0	.841000E+92	.388900E=01	.792900E+02	.2000006=01	.100000E+61
3	5	4	0	0	*R41000F+05	.388000E=01	.801100E+02	.200000E=01	.1000F0E+01
. 4	6	-5	0	0	.841000E+02	.388000E=01	.8094006+02	*subboode=0.	.101010F+01
5	1	6	0	0	\$41000E+0S	.388000E=01	\$162006+02	.2000006-01	.100000E+01
6	7	2	0	. 6	.420500E+03	.194000E+00	.785500E+02	.20000000-01	,100000E+01
7	8	7	0	r	.420500E+03	.194nnak+00	.79560UF+02	10=3000005.	.1000002+01
8	9	8	0	0	.420500E+03	4194000E+00	.805900£+02	.200000E=01	.160000E+01
9	1	9	0	0	.420500E+03	.194000E+0n	.816200E+02	.200000E=01	.100000E+01
10	10	2	0	0	.336400E+03	.155000E+00	.785500E+02	.200000E=01	.100000E+01
11	11	10	0	0	.336400E+05	.155000E+00	.795600E+02	.2000008-01	.1000005+01
12	12	11	0	0	.336400E+03	•1550n0E+0n	.805900E+02	.200000E=01	.100000E+01
13	1	12	0	0	.3364008+03	.155000E+00	.816200£+02	10-3000005-01	.1000006+01
14	13	5	0	0	.504600E+03	.23300nE+no	.7855008+02	.200000E=01	.100000E+01
15	14	13	0	0	.504600E+03	.255000E+00	.795600E+02	.200000E=01	.1000ncE+01
16	15	14	٥	0	.504600E+03	.253000E+00	.805900E+02	.200000E-01	.100000F+01
17	1	15	0	0	.504600E+03	.2330006.+00	.816200E+02	10-100005	10000006+01
18	16	2	0	0	.672800E+03	.310000E+00	.785500F+02	10-3000005	1000000+01
19	17	16	0	0	.672300E+03	.310000E+00	50+3008008	.200000E=01	.100000E+01
20	1	17	0	0	.672800E+03	.310000E+00	.816200E+02	.200000E-01	.100000E+01
21	18	2	0	0	.589700F+03	.272000E+00	.785500E+02	.2000006-01	10+30000te+01
55	1	18	٥	0	.584700E+03	.272000E+00	.8162008+02	200000E=01	.1000005+01
23	19	2	٥	0	.566700E+03	.272000E+00	.7855008+02	.170009E=01	.1000006+01
24	1	19	0	U	.588700E+03	.272000E+00	. #16200E+02	.170000E-01	. 10000CE+01
25	20	.5	0	0	.7614005+03	.350000£+00	.785500E+02	.170000E-01	.100000E+01
26	.1	-20	0	0	.761400E+03	.350000E+00	816200£+02	.170000E-01	.100000E+01
27	21	2	0	0	.743100E+03	.11040HE+01	785500E+02	.200000E=01	.100000E+01
28	-1	21	0	0	.743100E+03	.110400E+01	\$14500E+02	.200000E-01	.100000E+01
5.0	22	2	0	. 0	.7307C0E+03	.110400E+01	.785500E+02	.200000E=01	.100000E+01
20	1	55	0	0	.730700E+03	.110400E+01	.819500E+05	.200000E-01	.100000E+01

TABLE A-IX

JUNCTION DATA

JUN	VERT JUN			MOM EQ.	JUNCTION INERTIA	SP. ENERGY LOSS CUEF	SP.ENERGY LOSS COEF.	RESIDUAL LOSS COFF.	RESIDUAL DELTA P (PSIA)	ENTHALF	Y TRANS
NU-	XONI	-		•	E T T T T E H	(FORMARU)	(REVERSE)	(NON-DIR)	DECIM P (PSIM)	INLET	OUTLET
1	0	- 1	3	0	.A72813E+01	.998121E+00	.449577E+00	.7956755+00	. 6665696+01	NO	NO
2	0	-1	3	n	1936316+02	0.	0.	.25371fE+00		* ;0	NO
3	0	-1	3	0	.2145556+02	0.	0.	.19194E+00	1579996+01	NO	NU
4	0.	-1	3	. 0	.251422E+02	0.	0	.103936E+00	A51757E+00	HO	NO
5	0	- 1	3	. 0	144930E+05	.449829E+00	.999242E+00	.640695E-01	•	NO	NO
6	0	-1	3	0	.277638E+01	.990623E+00	.4478B5E+00	.805955E+00	6744035+01	٨Ŋ	ĸū
7	Ö	-1	3	0	.536720E+01		0.	287984E+00	•	NO.	NÜ
8	Ô	-1	3	Ō	.534720E+01		0.	1892036+00		NO	ND
ğ	ŏ	- i	3	ŏ	.276820E+01	=			•	NO	NO
10	ŏ	- i	3	ŏ	344346E+01				•	סוי	NO
11		- 1	3	0	.6701358+01	0.	0.	.290220E+00	.24085E+01	NO	NO.
12	0	-1	3	Ô	.67.0135E+01		0.	.1697756+00		• NO	NÜ
13	ŏ	-i	.3	· ŏ	343528E+01				• · · · · · · · · · · · · · · · · · · ·	NO	NO
14	Ŏ	• 1	Š	Ŏ	232159E+01			-		NO	'NO
15	Ŏ	-1	3	Ŏ	445762E+01		0.	.2963376+00		NO	ND
16	0	-1	3	٥	.445762E+01	0.	0.	.194557E+00	.159216E+01	NU	Nü
17	ŏ	-1	3	Ŏ	.2313416+01					NÖ	NO
18	ŏ	-1	ĩ	Ŏ	261099E+01		_	-	•	NO.	NU
19	ŏ	• i	3	ŏ	5036426+01		0.	4453946+00			NO
20	ŏ	- i	ž	ŏ	2602816+01					NO	NO
21		-1	3	3	.581599E+01	.986865E+00	.447035E+00	1506288+00	.131957E+01	NO	NO
55	ŏ	- i	3	ő	5808811+01	·	- · · · · · · · · · · · · · · · · · · ·	▼ :	• • • • • • • • • • • • • • • • • • • •	NO	NO
23	Ğ	-1	ر خ	ő	5616996+01		•			NO	*0
24	ŏ	-i	3	ò	580881E+01					NO	NÚ
25	ŏ	-1	3	ŏ	452135E+01			-		NO ,	NO NO
56	. 0	-1	3	0	.451317E+01	.4484626+00	.993176E+00	.307549E+00	.2537348+01	NO '	NO
27	ŏ	-1	3	ŏ	.150809E+01		•	•	-	ND	ND
28	ŏ	- i	3	ŏ	149991E+01		*		•	NO	NO
29	ŏ	-i	ĩ	ŏ	1508098+01			* *	· · · · · · · · · · · · · · · · · · ·	NO	NO.
30	Ŏ	-1	3	ŏ	149991E+01	· · · · · · · · · · · · · · · · · · ·	*		· · · · · · · · · · · · · · · · · · ·	NO	NO
		PARAM	FTFHR	IN JU	NETION MATRIX						
HMEF	A OF				(MS	1 = 5			•		, ,
	ROF	•		TTOAS	(NTRI					•	
		-		JUNCTI	•	1 = 19					
		_	-		NCTION (MPP	31					
				TIONS	(NTOT1						

DATA	FOR	3	HE A	r și	AB GED	METR:	ES		
GEOM TYPE		GAP IND			Xộ Tạ	Ņ. E 1		REGION WIDTH	POWER FRAC
1	1 2 3	0 0	1 2	. i	0.		,	.833000E=03 .125000E=02 .833000E=04	•
						SUN	OF	POWER FRACTIONS	18 .100000E+01
GEOM TYPE			MAT		XO TO	N=1		REGION WIDTH	POWER FRAC
1 .	1,		1,	1	0 •			.750000E=02	.100000E+01
						SUM	OF	POWER FRACTIONS	IS .100000E+01
GEON TYPE		GAP IND	TAN		XO TO	NE1		REGION WIOTH	POHER FRAC
1.	1;		3	1	. 1 0	0.000	+ 0.0	,80000QE+00	.100000E+01
			•			8.UM.	OF	POWER FRACTIONS	18 .100000E+01

CORE GEOMETRY

RELAP4 Volume	Core Volume	Number of Fuel Elements	Volume Length (ft)	Fluid Volume (ft ³)	Flow Area (ft ²)	Flow Rate (1b/sec)	% of Total Reactor Power	Slab Metal Volume (ft ³)	Heat Transfer Area (ft ²)
3	. 1	1	0.67	0.026	0.0388	84.1	0.49	0.018	5.1
4	2	1	0.83	0.325	0.0388	84.1	0.97	0.022	6.4
5	3	1	0.83	0.325	0.0388	84.1	0.98	0.022	6.4
6	4	1	0.77	0.030	0.′0388	84.1	0.61	0.018	5.1.
7	5	5	1.05	0.202	0.194	420.5	4.46	0.135	40
8	6	5	1.05	0.202	0.194	420.5	5.95	0.135	40
9	· 7	5	1.05	0.202	0.194	420.5	4.46	0.135	40
10	8	4	1.05	0.161	0.155	336.4	3.42	0.108	32
11	9	4	1.C5	0.161	0.155	336.4	4.56	0.108	32
12	10	4	1.05	0.161	0.155	336.4	3.42	0.108	32
13	11	.6	1.C5	0.242	0.233	504.6	4.84	0.162	48
14	12	6	1.C5	0.242	0.233	504.6	6.45	0.162	48
15	13	- 6	1.05	0.242	0.233	504.6	4.84	0.162	48
16	14	8	1.57	0.484	0.310	672.8	8.90	0.320	92
17	15	8	1.57	0.484	0.310	672.8	8.90	0.320	92
18	16	. 7	3.15	0.847	0.272	588.7	11.40	0.560	161
19	17	7	3.15	0.847	0.272	588.7	7.92	0.560	161
20	18	14	3.15	0.085	0.350	761.4	13.44	0.810	200
21	19	$\mathtt{R}_{\mathtt{I}}$	Full				. 3.19		
22	20	Ro	Full				0.80		

TABLE A-XII

CORE POWER DISTRIBUTIONS

DATA FOR 20 CORE SECTIONS.

CORE	SLAB.	PR	INT 1		INITIAL CLAD	SECTION POWER	PROMPT HOD	DELAY MOD
SECT	NUM	AT	NOUE	5	THICKIESS	FFACTION	FRACTION	FHACTION
1	1	1	2	3	0.	\$0-30000e.	.3000000E=01	.264900E+00
2	5	1	2	3	0.	.970000E=02	.300000E-01	.2600000++00
3	3	1	S	3	0.	.980000E=02	.300000E=01	.26000000+00
4	4	1	5	3	.c .	.61000nE=02	.3000006-01	00+3000045
· 5	5	1	2	3.	0.	.446000E=01	.300000E=01	.260000E+00
6	è	1	2	3	() •	.595000E=01	.300000E=01	.260000E+00
7	7	1	5	3	0.	.446000E=01	.30000CE=01	.260000E+00
8	6	1.	2	Ś	0.	342000E=01	.300000E=01	.560000£+00
9	9	i	2	3	· 0 .	.455000E-01	.500000E=01	56000000+00
10	10	1	5	3	0.	.342000E-01	300000E-01	.2600000E+00
11	11	1	2	3	0	.484006E=01	.300000E-01	.2600006+00
12	12	ĭ	2	3	0.	.645000E=01	.300000E=01	2600006+00
13	13	ī	Ž	3	. C.	.484000E=01	.300000E-01	.260000F+00
14	14	1	2	3	0.	.890000E-01	.300000E=01	2600008+00
15	15	ī	2	3	0.	.890000E-01	.300000E-01	2600000+00
16	16	1	2	3	ο.	.114000E+00	.300n0GE=01	.260000E+00
17	17	1	5	3	. C .	.792000E=01	.30000CE-01	.260000E+00
18	16	1	2	3	0.	.134400E+00	.300000E-01	.2600000E+00
19	19	1	2	3	0.	.319000E=01	30000GE-01	.260000E+00
20	20	i	2	3	0.	.8000008-02	,300000E=01	.260000E+00

NO METAL WATER REACTION WILL BE CALCULATED

SUM OF POWER FRACTIONS = 1.0000000

The fraction of the prompt energy deposited directly in the moderator was input as 0.03. The fraction of the delayed energy deposited directly in the moderator was input as 0.26.

Metal-water reaction was not considered in the RELAP4 analysis. The fraction of the energy produced in the fuel plate cladding was input as 0.022. The oxide thickness was input as 1.0 mil. This oxide thickness represents a three-sigma standard deviation value for deposition on elements operated in the most recent ETR cycle.

7.4 Kinetics

The RELAP4 kinetics model has the capability for solving the kinetics equation described in the manual, incorporating possible sources of reactivity feedback. The code allows for input of any reactivity feedback source which may be significant.

The kinetics equation was solved for the ETR system using parameters defined in Table A-XIII. A β/ℓ value of 175 was used. The power calculation was based on one prompt neutron group, six groups of delayed neutrons, and eleven delayed gamma emitters. A value of 1.0 for the U-238 consumed per U-235 fission was used because the ETR fuel is highly enriched. The fraction of total power released at the time of fission was assumed to be 0.93 with 0.07 released as delayed gamma emitters.

Feedback due to void formation and feedback due to expansion of the fuel plates were considered. Water temperature feedback and the Doppler effect were considered insignificant.

To determine the reactivity effect of a reduction of moderator, void coefficients for each core volume were calculated from the core power distribution. These coefficients were used to determine the reactivity feedback from vapor voiding in the fuel element as well as feedback from displacement of the fuel plates due to increased temperature expansion. Because displacement is directly related to the fuel plate temperature, that feedback was input as reactivity per unit plate temperature change. Table A-XIV shows the calculated values of the coefficients for both voiding and displacement for each core volume and the method of calculation. The supplied void coefficients were based on data obtained at xenon equilibrium conditions when the core power distribution is flattest. Consequently the feedback will be conservative for a beginning of life power generation profile.

For calculation of the void feedback, the fraction of surface heat flux used to produce vapor bubbles was assumed to be 0.05, and the vapor bubble lifetime was assumed to be 0.001 second. These values were recommended for use in both highly subcooled and slightly subcooled flow in Reference A-6. The vertical profile used to determine void coefficients in the volumes distributed axially within each set of elements was the same as the profiles used for the heat generation values.

TABLE A-XIII

REACTOR KINETICS PARAMETERS

PONER Type	BETA OVER	INITIAL REACTIVITY	U-238 ATOMS C OTA 225-U RBP	•		
. 2	.1750008+43	0.	.100000	E+01		
FRACTION OF SURF	ACE HEAT FLUX UTILI	ŽED IN PRODUCIN	G SUBCOOLED VAP	OR BURBLES # 5	5.00000E-02	
VAPOR BUBBLE LIFE	ETIME (SEG)	• **		= 1	.00000E=03	•
1 PROMPT AND 6 DEPROMPT ENERGY FR	ELAYED WEUTHOW GROU ACTION # .930	PB PLUS 11 DELA	YED GAMMA EMITT	ERS	,	
REACTIVITY DATA	TARLE 1					,
DATA THIP PTS ID	1146	REACTIVITY	TIME	REACTIVITY	TIME	REACTIVITY
1 2	.10000E+04	0.		•		
REACTIVITY CURVE	VERSUS NORMALIZED	DENSITY.			3	
DATA PTS.	NORMALIZED DENSITY	REACTIVITY (UOLLARS)	NORMALIZED DENSITY	REACTIVITY (DOLLARS)	NORMALIZED DENSITY	REACTIVITY (DOLLARS)
-2	o	100000E+01	.100000E+01	0.		
DOPPLER REACTIVE	TY CURVE.					•
DATA PT8.	METAL TEMPERATURE	REACTIVITY (COLLARS)	METAL TEMPERATURE	REACTIVITY (UOLLARS)	METAL Temperature	REACTIVITY (DOLLARS)
•2	\$0+430,000e+0\$	0.	.500000E+04	0.		
		•				

TABLE A-XIII (contd.)

REACTOR KINETICS PARAMETERS

CORE REG NUM	WATER DENSITY WEIGHTING FACTOR	DOPPLER WEIGHTING FACTUR	BETAL TEMP. CDEFFICIENT 13/DEG F1	WATER TEMP. COEFFICIENT (SZDEG P)
	.813000E=01	0.	500000E-06	0.
e i c	.233000E+00	o,	■.14000UE-05.	O.
i	00+30005+00	0.	140000F-05	0
ű ·	.913ncnE=01	0.	560000E-06	0.
5	.819400E+00	0.	510000E=05	9.
6 .	.14Kh09E+91	0.	#.920000F#05	0.
7	.807200E+00	0.	500000E-05	0.
Š	.661000E+00	0.	410000E-05	0.
8 9	.119700E+01	0.	7400,008-05	0.
10	.651600E+00	9.	4000008-05	0.
11	.949000E+00	. 0 •	-:59000 <u>0</u> 2E=05	α.
12	1721006+01	0.	106000E=04	a,
13	.935000E+00	0.	575000E-05	a.
14	.21100LE+U1	0.	130000E=04	a.
15	.209300E+01	0.	13000nE-04	0.
16	.255700F+01	0.	15800DE+D4	α.
17	.149400E+G1	0.	- 92400DE-05	a.
16	.183007E+01	0	18400DE-04	G.
19	t.	0.	0.	G .
20	ć.	0.	0.	C.

2

•

TABLE A-XIV
FEEDBACK PARAMETERS

RELAP4 Volume	Core Volume	Volume Fraction	\$/Fraction of Void[a] at Xenon Equilibrium	Voiding (\$/Fraction of Void) at Xenon Equilibrium	Displacement (\$/°F) at Xenon Equilibrium
3	1	0.0046	17.666	0.0813	0.000109
4	2	0.0057	40.885	0.2330	0.000252
5	3	0.0057	40.703 ~	0.2320	0.000251
6	4	0.0053	17.231	0.0913	0.000106
7	5	0.0355	23.083	0.8194	0.000143
8	6	0.0355	41.861	1.4860	0.000258
9	7	0.0355	22.738	0.8072	0.000140
10	8	0.0283	23.352	0.6610	0.000144
11	9	0.0283	42.348	1.1980	0.000261
12	10	0.0283	23.003	0.6510	0.000142
13	11	0.0426	22.278	0.9490	0.000138
14	12	0.0426	40.401	1.7210	0.000249
15	13	0.0426	21.945	0.9350	0.000135
16	14	0.0852	24.760	2.1100	0.000153
17	15	0.0852	24.521	2.0930	0.000152
18	16	0.1490	17.162	2.5570	0.000106
19	17	0.1490	10.025	1.4940	0.000062
20	18	0.1900	9.661	1.8360	0.000060

Voiding = (Volume Fraction) (\$/Fraction of Void)

Displacement = (Fraction of Void/°F) (\$/Fraction of Void) $(\frac{0.050}{0.115})$

Fraction of Void/ $^{\circ}F$ = Coefficient of Thermal Expansion

= 14.2×10^{-6} /°F (68-572°F)

 $(\frac{0.050}{0.115}) = \frac{\text{Width of the plate}}{\text{Width of the channel}}$

[[]a] Void coefficients were based on data obtained at xenon equilibrium conditions when the core power distribution is the flattest.

7.5 Results

Due to instabilities in the RELAP4 code, the results could not be analytically determined for the complete loss of flow with no reactor scram. However, for purposes of subsequent calculations, 50% of the core was assumed to melt.

For the case with loss of flow and reactor scram, no core melting is expected. The loss of flow incident does not postulate a break in the primary containment. Thus, fission products released to the primary coolant are assumed to leak to the building commensurate with the maximum allowable system leakage of 75 gpm (a conservative estimate).

With 50% of the core melting after complete loss of coolant flow, the amount of fluid leakage to the containment building is determined as follows:

7.5.1 ETR Loss of Flow.

(1) Assumptions.

- (a) Reactor does not scram on low vessel delta pressure
- (b) Reactor does not scram from high pressure.
- (c) Reactor does not scram from high surge tank level.

(2) Estimated Sequence of Events.

Time (sec)	Event
0	Complete loss of flow, reactor operation for 30 days.
25	Flow has coasted down to zero. Fuel plate temperature in hot volume = 425°F. Reactor power = 44 MW.
26	Fuel plate insulates due to steam formation.
27	Fuel plate reaches melting temperature at hot spot.
30	Estimated 50% of core has reached melting temperature. Estimated reactor power is 20 MW.

(3) Assumption. 5°F rise in ETR system temperature results in a 25-psig rise in pressure. System volume is about 55,000 gallons or 455,000 pounds.

Coefficient of thermal expansion, $\beta = 0.418 \times 10^{-3}$ per degree F.

Rate of temperature rise = 150° F/hr.

Rate of volumetric rise = 461 ft³/hr; this is 3,448.5 gal/hr or 57.5 gpm.

Therefore, liquid release rate to the containment = 57.5 gpm, which is well within the permissible leakage limit of 75 gpm.

Since the reactor can operate with 75 gpm leakage, the assumption can be made that all fluid is leaked to the containment at a rate of 75 gpm, with a source equivalent to 50% core melting.

8. CONSEQUENCES

Although 50% of the ETR core has been assumed to melt, the fission product release from the primary containment is rather tenuous because of the tortuous path the fission products must take before release occurs. With the integrity of the primary containment remaining intact except for the ruptured relief valves, fission products are entrained in the primary coolant which has been assumed to leak into the reactor pipe tunnel at a rate of 75 gpm. Since the reactor coolant system (RCS) has been depressurized, the leak continues as water (instead of steam) at the 75 gpm rate at which water is being added to the core.

The solids portion of the fission-product inventory will remain in the water, thus posing no potential for offsite exposure. The noble fission gas inventory, contained in 50% of the core, is pessimistically assumed to be contained in the first 4,500 gallons which will leak during the first hour. Actually, more realistic behavior of the noble fission gases would be to evolve from the water within the primary containment system and thus largely be contained within this containment. Of the 50% core halogen inventory, half of that present is assumed to evolve from the primary coolant as it is released from the RCS. For all the fission products released from the RCS, credit for no holdup or scavenging is assumed for the pipe tunnel or heat exchanger building. Thus, the leak rate of the released fission products to the atmosphere is 0.0139%/sec for the noble fission gases and 0.069%/sec for the halogens and is assumed to continue for a period of one hour. Under the most probable circumstances, the fission products would be exhausted out of the pipe tunnel to the heat exchanger building, then out the stack.

Once the material has been released from the stack top, resulting radiological doses to offsite individuals are determined probabilistically. The location of an individual is a factor in the determination of his radiological dose with his distance and direction from the release

point being important considerations. The meteorological weather regime (inversion or lapse) and the wind speed that persists at that time of release are also factors that determine the radiological dose.

The nearest site boundary (where an individual may be located potentially) is approximately 1.12×10^4 meters distant from the Test Reactor Area (TRA) at a direction west-northwest of TRA. The nearest population center to TRA is Arco, Idaho, which is 13° north of west and lies about 2.74×10^4 meters distant. Probability of lapse and inversion weather conditions existing at TRA, based on an annual basis, are 52.1 and 47.9%, respectively. With the wind speed residing in the denominator of the diffusion equation, the resulting radiological doses are inversely proportional to the wind speed. Figures A-10 and A-11 show how diffusion calculations depend on both the direction and speed of the wind. Although these wind roses are based on data taken at Central Facilities Area (CFA), they are applicable to TRA, which is only 4.1 miles distant from CFA. The directions indicated on the wind roses are the directions from which the wind is blowing, that is, a north wind is blowing from north to south.

In summary, the consequence probabilities are multiplied together to obtain the overall probability that an individual at some location will receive a radiological exposure. This probability has been obtained for illustration purposes for an individual at Arco, Idaho.

()

Probability for lapse condition	=	0.52
Probability for wind direction	= .	0.0125
Probability for 6 m/sec wind speed	= '	0.5
Overall probability	=	0.00325

The radiological consequences for this downwind position (at Arco) are summarized in Tables A-XV through A-XVIII. The calculated thyroid inhalation dose is 2.13 rem and the cloud γ whole body dose is 9.3 x 10⁻³ rem. The cloud γ doses reported here are those calculated by the semi-infinite cloud model.

These results were obtained with use of RSAC-2^[A-7] a computer program capable of determining radiological hazards resulting from a reactor system accident. The program generates a fission product inventory from a given set of reactor operating conditions, and then computes the various gamma dosages and ingestion parameters specific to the facility location and environmental condition.

9. RISK RESULTS

Risk, the chance of injury, has been defined mathematically as follows:

Risk = (accident probability)(accident consequence)




Fig. A-10 CFA 250-foot level lapse wind roses, July 1951 through May 1962.




Fig. A-11 CFA 250-foot level inversion wind roses, July 1951 through May 1962.

ANC-A-5876

TABLE A-XV

DATA INPUT TO RSAC-2

```
RADIOLOGICAL SAFETY ANALYSIS COMPUTER PROGRAM (RSAC-2)
                                                                                                                  DATE 06/20/75
(RSAC-2/03/26/74/D.R.WENZEL)
ETR RISK ANALYSIS ( LAPSE WEATHER CONDITION )
                                                                                                                  PAGE
                                                                                                                          1
    CHAIN DATA INPUT IS FROM DATA SET
***CURIE CALCULATION
    THE REACTOR HAS OPERATED AT 1.750E 08 WATTS FOR 2.592E 06 SECONDS WATTS TO FISSIONS/SECOND CONVERSION FACTOR = 3.120E 10
    REACTOR HAS BEEN SHUT DOWN FOR 1.000E OO SECONDS
    FRACTIONATION BY ELEMENT GROUP -- PERCENT
                                      HALDGENS = 2.500E 01
                                                                    NOBLE GASES = 5.000E 01
                                                                                                      CESIUM =
          SOLICS = 0.0
                                                                                                                 0.0
    TOTAL FISSION PRODUCT RELEASE = 2.360E 18 D/SEC OR 6.380E 07 CURIES
***METEURULOGICAL DATA
     UBAR = 6.000E 00 (M/SEC)
                                       W1 = 1.500E 00
                                                              W2 = 1.500E 00
                                                                                     W3 = 1.500E 00
WASHOUT FACTUR = 0.0
     STACK HEIGHT = 7.600E 01 (M)
                                            INVERSION HEIGHT = 0.0
                                                                              (M)
    DOWNWIND DISTANCES -- METERS
                         1.120E 04
                                            2.740E 04
      THERE IS 1 SET OF EXPONENTIALS (K. P)
            . 2 . 7 78 E-04
                               0.0
    PASQUILL CLASS B METEGROLOGY, MARKEE SIGY(S), MARKEE SIGZ(S)
    BUILDING WIDTH = 1.000E CC (M)
SIGY AND SIGZ(S) -- METERS
                                            BUILDING HEIGHT = 1.000E 00 (M)
                                                                                    DILUTION FACTOR = 1.000E 00
       1.519E G3
                         2.651E 03
                                            3.362E 03
                                                              5.851E 03
          CY AND CZ(S)
       1.973E 00
                         3.443E 00
                                            2.232E 00
                                                              3.886E 00
***DECAY CALCULATION -- CURIES .
CHAIN 1 MASS NUMBER
       NUCLIDE 3
                       PERCENT FISSION YIELD
                                                     DECAY CONST (SEC-1)
1.791E-09
                                                                                  HALF LIFE
1.226E OI YRS
                                                                                                    GAMMA ENERGY (MEV/DIS)
                                 8.800E-03
                                                                                                              0.0
               TIME (SEC)
                                       H-
                                            3
                                      3.01E 01
                 1.867E C3
4.567E O3
                                      3.01E 01
3.01E 01
CHAIN 2
            MASS NUMBER 72
                       PERCENT FISSION YIELD
                                                     DECAY CONST (SEC-1)
4.140E-06
1.365E-05
                                                                                  HALF LIFE
4.650E 01 HRS
1.410E 01 HRS
       NUCLIDE
                                                                                                    GAMMA ENERGY (MEV/DIS)
           7N- 72
GA- 72
                                                                                                              9.100E-01
2.700E 00
                                 0.0
```

TABLE A-XVI

THYROID INHALATION DOSE WITH

LAPSE WEATHER CONDITIONS

```
RADIOLOGICAL SAFETY ANALYSIS COMPUTER PROGRAM (RSAC-2)
(RSAC-2/03/26/74/D.R.WENZEL)
                                                                                                                   DATE 06/20/75
ETR RISK ANALYSIS ( LAPSE WEATHER CONDITION )
NICLIDE PERCENT FISSICN YIELD
1 EU-159 1-05CE-C3
0.0
                                                                                                                   PAGE
                                                                                  HALF LIFE
                                                                                                     GAMMA ENERGY (MEV/DIS)
                                                     DECAY CONST (SEC-L)
                                                             6.417E-0
                                                                                   1.8COE OL HRS
                                                              1.0698-05
                                                                                                              4.600E-01
               TIME (SEC)
                                                          GD-159
                                      EU-159
                 0.0
                                      0.0
                                                          C. C
                 1.867E 03
4.567E 03
                                      0.0
                                                          0.0
    TCTAL FPI VS TIME (TIME, FPI)
C.C 6.38E 07 1.867E 03
                                                      2.94E 07
                                                                      4.557E C3
                                                                                       2.53E 07
    TOTAL FPI BY GROUP -- CURIES ILME (SEC) SOLIDS
                                              HALOGENS
                                                                                       CESTUM
                                                                 NOBLE: GASES
                                                                    4.44 07
1.69 07
8.00 06
        C. C
                             0.0
                                                1.94E 07
                                                                                        0.0
         1.87E C3
                             1.95E 06
                                                 9.51E 06
         1.04E C6
                             4.57E 03
                                                 2.04E 06
                             5.86E 05
         1.47E 07
    SUMMATION OF FPI BY ELEMENT
SUMMATION OF ISOTOPES C (TIME, FPI)
1.469E 07 1.87E G3
          1.469E 07
SUMMATION CF
                            ISCTCPES*** (TIME, FPI)
              7.805E 06
***INHALATION CALCULATION (ICRP II MODEL FOR SOLUBLE NUCLICES)
      BREATHING RATE = 3.470E-04 (CU M/SEC)
                                                        INHALATION TIME = 3.600E 03 (SEC)
                                                                                                     MULTIPLIER = 1.000E 00
                                                        TIME = 1.867E D3 (SEC)
      DOWNWIND DISTANCE = 1.120E 04 (M)
                                                                                              CHI/O = 1.317E-08 (SEC/CU M)
                                             THYROLD
                                                       DOSE FOR EACH I ISCTOPE (ATOMIC NO 53)
                                              ISDTOPE
                                                            CHAIN
                                                                          DOSE (REM)
                                               - 129
- 129
                                                             60
                                                                             3.88E-09
                                                                             2.89E-08
                                                              61
                                                  131

    iši

                                               _
                                                  132
                                                              66
                                               -
                                                  133
                                                              67
                                                  134
                                                              68
                                                              70
                   THYROID INFALATION COSE FOR ALL I ISOTOPES (ATOMIC NO 53) IS 1.0574E 01 (REM):
          TOTAL THYROID INHALATION DOSE = 1.0574E 01 (REM)
                                                       TIME = 4.567E 03 (SEC)
                                                                                              CHI/Q = 2.697E-09 (SEC/CU M)
      DCWNWIND DISTANCE = 2.740E 04 (M)
```

EXECUTION TIME = 1.717414E 02

TABLE A-XVI (contd.)

THYROID INHALATION DOSE WITH

LAPSE WEATHER CONDITIONS

	LAPSE WEATHER	COND IT IONS	
(RSAC-2/03/26/74/D.R.WENZEL)	RADIOLOGICAL SAFETY ANAL	YSIS CCMPUTER PROGRAM (RSAC-2)	DATE 06/20/75
ETR RISK ANALYSIS (LAPSE WEATHE	R CONDITION)		PAGE 22
	THYROID DOSE FOR EACH IN THE STORT IN THE ST	ACH I ISOTOPE (ATOMIC NO 53) DCSE (REM) 7.95E-10 5.92E-09 1.12E 00 1.95E-01 1.01E-02 4.40E-01 2.70E-01 1.60E-03 2.65E-02 7.15E-02	e
THYROID INHALA	FICN DOSE FOR ALL I ISOTOF	PES (ATOMIC NO 53) IS 2.1321E 00 (REM)
TOTAL THYROID INHALATI	ON DOSE = 2.1321E 00 (REM	· · · · · · · · · · · · · · · · · · ·	
***GAMMA DOSE CALCULATION WITH E	XPOSURE TIME = 3.6000E 03	(SEC)	
COWNWIND DISTANCE = 1.12CE	04 (M) DOSE = 9.1	1E-02 (REM)	An
DCHNWING CISTANCE = 2.740E	04 (M) DOSE = 3.	33E 01 (REM)	•
***GAMMA DOSE CALCULATION WITH E CALCULATIONS MADE USIN	XPCSURE TIME = 3.6000E 03 G ONLY THE SEMI-INFINITE MO	(SEC) DDEL	
DOWNWIND DISTANCE = 1.120E	04 (M) DOSE = 5.0	35E-02 (REM)	
CCWNWING CISTANCE = 2.740E	04 (M) DOSE = 9.	32E-03 (REM)	

TABLE A-XVII

INPUT DATA TO RSAC-2

```
DATE 06/19/75
(RSAC-2/03/26/74/D.R.WENZEL)
                                       RADIOLOGICAL SAFETY ANALYSIS COMPUTER PROGRAM (RSAC-2)
ETR RISK ANALYSIS (INVERSION WEATHER CONDITION)
                                                                                                               PAGE
    CHAIN DATA INPUT IS FRCM DATA SET
                                              55555
***CURIE CALCULATION
    THE REACTER HAS CPERATED AT 1.750E 08 WATTS FOR 2.592E 06 SECONDS WATTS TO FISSIONS/SECOND CONVERSION FACTOR = 3.120E 10
    REACTOR HAS BEEN SHUT DOWN FOR 1.COCE OO SECONDS
    FRACTICNATION BY ELEMENT GROUP -- PERCENT
          SOLIDS = C.C
                                     HALDGENS = 2.500E 01
                                                                  MOBLE GASES = 5.000E 01
                                                                                                   CESIUM = 0.0
    TOTAL FISSION PRODUCT RELEASE = 2.360E 18 D/SEC OR 6.380E 07 CURIES
***METECRCLCGICAL CATA
                                     W1 = 1.500E 00
    UBAR = 2.COCE CO (M/SEC)
STACK FEIGHT = 7.600E 01 (M)
                                                            W2 = 1.500E 00
                                                                                   W3 = 1.500E 00
                                          INVERSION HEIGHT = 3.000E 02 (M)
                                                                                     WASHOUT FACTOR = 0.0
    DCWNWIND DISTANCES -- METERS
                                           2.740E 04
     0.0
                        1.120E C4
     THERE IS 1 SET OF EXPONENTIALS (K, P)
    PASQUILL CLASS H METEOROLOGY, MARKEE SIGY(S), MARKEE SIGZIS)
    BUILDING WIDTH = 1.000E 00 (M)
SIGY AND SIGZ(S) -- METERS
                                           BUILDING HEIGHT = 1.000E 00 (MI
                                                                                  DILLTION FACTOR = 1.000E 00
       1.273E C3
CY AND CZ(S)
                        1.4C9E 01
                                           2.352E 03
                                                            1.850€ 01
       1.654E CC
                        1.8325-02
                                           1.562E 00
                                                            1.229 =-02
***CECAY CALCULATION -- CURIES
CHAIN
         MASS NUMBER
      NUCLIDE 3
                                                                                                  GAMMA ENERGY (MEV/DIS)
                    PERCENT FISSION YIELD
                                                    DECAY CONST (SEC-1)
                                                                                  HALF LIFE
                                                                                1.226E JI YRS
                                                            1.791E-03
                               8.800E-C3
                                                                                                           0.0
              TIME (SEC)
                                      H- 3 /
                                     3.01E 01
3.01E 01
3.01E 01
                5.600E 03
1.370E 04
            MASS NUMBER 72
CHAIN 2
                                                                                                  GAMMA ENERGY ( VEV/DIS )
       NUCLIDE
                      PERCENT FISSION YIELD
                                                    DECAY CONST (SEC-1)
                                                                                  HALF LIFE
          ZN- 72
GA- 72
                                                            4.140E-06
                                                                                4.650E 01 HRS
1.410E 01 HRS
                                                                                                           9.100E-01
2.700E 00
                               1.600E-05
                                                           1.365E-05
```

TABLE A-XVIII

THYROID INHALATION DOSE WITH INVERSION WEATHER CONDITIONS

```
(RSAC-2/03/26/74/D.R.WENZEL)
                                         RADIOLOGICAL SAFETY ANALYSIS COMPUTER PROGRAM (RSAC-2)
                                                                                                                      DATE 06/19/75
ETR RISK ANALYSIS (INVERSION WEATHER CONDITION)
NUCLIDE PERCENT FISSION YIELD C
                                                                                                                      PAGE
                                                                                     HALF LIFE
1.800E 01 MIN
1.800E C1 HRS
                                                       CECAY CONST (SEC-1)
                                                                                                        GAMMA ENERGY (MEV/DIS)
        1 EU-159
2 GD-159
                                                               6.417E-04
1.069E-05
                                 1.05CE-03
                                                                                                                 0.0
                                 0.0
                                                                                                                 4.600E-01
               TIME (SEC).
                                       EU-159
                                                            GD-159
                                                           6.0
                                       0.0
                 5.600E 03
1.37CE 04
                                       0.0
                                                            0.0
    TCTAL FPI VS TIME (TIME, FPI)
C.C 6.38E 07 5
                                      5.600E 03
                                                        2.41E 07
                                                                       1.370E 04
                                                                                          1.88E 07
     TOTAL FPI BY GROUP -- CURIES
          TIME (SEC)
                             SUL IDS
                                                HALDGENS
                                                                   NOBLE GASES
                                                                                          CESIUM
                                                  1.94E 07
7.58E 06
1.15E 06
                                                                      4.44E C7
1.42E 07
5.70E 06
                                                                                           0.0
                              1.95E C6
1.37E C4
         4.26E C5
         1.19E 07
                              2.52E 04
    SUMMATION OF FPI BY ELEMENT
SUMMATION OF ISOTOPES C (TIME, FPI)
1.469E 07 5.60E 03
           SUMMATION OF
                             ISCTOPES*** (TIME, FPI)
***INHALATION CALGULATION (ICRP. II MODEL FOR SOLUBLE NUCLICES)
      BREATHING RATE = 3.470E-04 (CU M/SEC)
                                                        .INHALATION TIME = 3.600E 03 (SEC)
                                                                                                        MULTIPLIER = 1.000E 00
      DOWNKIND DISTANCE = 1.120E 04 (M)
                                                         TIME = 5.600E 03 (SEC)
                                                                                                 CHI/Q = 4.372E-12 (SEC/CU M)
                                                                           I ISCTOPE (ATOMIC NO 53)
DCSE (REM)
1.29E-12
                                               THYROID
                                                        DOSE FOR EACH
                                                ISOTOPE
                                                              CHAIN
                                                               60
                                                 -
                                                               63
                                                   131
                                                               64
                                                 _
                                                               65
                                                 _
                                                    133
                                                               66
                                                   133
                                                 -
                                                   134
                    THYROID INHALATION DOJE FOR ALL I ISOTOPES (ATOMIC NO 53) IS 3.4370E-03 (REM)
          TCTAL THYROID INHALATION DOSE = 3.4370E-03 (REM)
      DEWNWIND CISTANCE = 2.740E 04 (M)
                                                         TIME = 1.370E 04 (SEC)
                                                                                                 CHI/Q = 7.974E-LO (SEG/CU M)
```

TABLE A-XVIII (contd.)

THYROID INHALATION DOSE WITH INVERVSION WEATHER CONDITIONS

(RSAC-2/03/26/74/C.R.WENZEL) RADIDLOGICAL SAFETY ANALYSIS COMPUTER PROGRAM (RSAC-2) DATE 06/19/75
ETR RISK ANALYSIS (INVERSION FEATHER CONDITION) PAGE 3

THYROID | DCSE FOR EACH | I ISCTOPE (ATOMIC NO 53) | DDSE (REM) | DDSE (REM) | I - 129 | 60 | 1.75E-09 | I - 131 | 63 | 3.28E-01 | I - 131 | 64 | 5.72E-02 | I - 132 | 65 | I - 133 | 66 | I - 133 | 66 | I - 133 | 67 | 7.73E-02 | I - 134 | 68 | 6.29E-05 | I - 135 | 69 | 6.62E-03 | I - 135 | 70 | I - 63E-02 | I - 63E-02 | I - 63E-02 | I - 63E-02 | I - 63E-02 | I - 135 | 70 | I - 63E-02 | I - 135 | 70 | I - 63E-02 | I - 135 | 70 | I - 63E-02 | I - 135 | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I - 135 | TO | I

THYRUID INHALATICN DOSE FOR ALL 1 ISOTOPES (AFOMIC NO 53) IS 6.0127E-01 (REM)

TOTAL THYROID INHALATION DOSE = 6.0127E-01 (REM!

***GAMMA DOSE CALCULATION WITH EXPOSURE TIME = 3.6000E 03 (SEC)

DCWNWIND DISTANCE = 1.12CE C4 (M) DOSE = 2.47E OD (REF)

DOWNWIND DISTANCE = 2.740E 04 (M) COSE = 8.79E-01 [REM]

DRINKING DISTANCE - 201-00 OF THE

EXECUTION TIME = 6.744191E 01

Risk is, therefore, the probability of the accident occurring, times the probability of the released material reaching a given population, times the doses in rems that will reach the given population.

The information needed for this calculation has been given earlier in the report and is collected here for an example risk calculation. The probability of the accident occurring for the three event sequences was presented in Section 6. The consequences are discussed in Section 8.

The event tree earlier shown in Figure A-4 is repeated in Figure A-12 with tabulated values for the risk calculation. The risk for Sequences 1 and 2 (S_1 and S_2) is 0 because a radioactivity release will not occur. A risk for S_3 has been calculated for the nearest population zone which is Arco, Idaho, at a distance of 2.74 x 10^4 meters from the ETR. The release for the lapse weather condition, 2.13 rems (from Table A-XVI), is used in the calculation. The hazard probability of 3.25×10^{-3} , tabulated in Section 8, denotes the probability of the released radioactivity reaching Arco.

The resultant probability of a radioactive exposure of 2.13 rem to the populace of Arco, Idaho, resulting from a loss of flow accident at the ETR during lapse weather conditions is 3.25×10^{-10} /operating cycle. When the exposure and the probability are multiplied together, the risk becomes 6.9×10^{-10} .

10. REFERENCES

- A-1. USAEC, Reactor Safety Study, An Assessment of Accident Risks in U.S. Commercial Nuclear Power Plant, WASH-1400, Draft (August 1974).
- A-2. Reliability Prediction of Electronic Equipment, MIL-HDBK-217B (September 1974).
- A-3. K. V. Moore and W. H. Rettig, RELAP4 A Computer Program for Transient Thermal-Hydraulic Analysis, ANCR-1127 (March 1975).
- A-4. D. H. Knoebel et al, Forced Convection Sub-Cooled Critical Heat Flux, D.P. 1306 (February 1973).
- A-5. R. S. Dougall and W. M. Rohsenow, Film Boiling on the Inside of Vertical Tubes with Upward Flow of the Fluid at Low Qualities, MIT-TR-9079-26 (1963).
- A-6. R. P. Morgan, A Review and Discussion of Literature Concerning Transient Heat Transfer and Steam Formation, IDO-17226 (March 1967).
- A-7. L. C. Richardson, User's Manual for the FORTRAN Version of RSAC (June 1968).

Loss of Primary Flow	Automatic Reactor Shutdown	Emergency Flow	Event Sequence	Frequency Probability Per Operation	Hazard Probability To Nearest Population Zone [a]	Corsequence (rem)	Risk
P ₁	1-P ₂	1-P ₃	s ₁ s ₂ s ₃	2 x 10 ⁻² 8 x 10 ⁻⁴ 1 x 10 ⁻⁷	0 0 3.25 x 10 ⁻³	0 2 2.13	0 0 6.9 x 10 ⁻¹⁰

[a] Arco, Idaho 2.74×10^4 meters (17 miles) ANC-A-5877

Fig. A-12 Risk summary for ETR loss of flow event.

APPENDIX B

DIFFERENCES BETWEEN TEST REACTORS AND COMMERCIAL NUCLEAR PLANTS

THIS PAGE WAS INTENTIONALLY LEFT BLANK

APPENDIX B

DIFFERENCES BETWEEN TEST REACTORS AND COMMERCIAL NUCLEAR PLANTS

During the course of this study a few differences were observed between test reactors and the large commercial nuclear power plants pertinent to risk assessment that are worthy of mention. These important differences are summarized as follows:

- (1) Because of the relatively long operating cycle (dictated by refueling requirements), the commercial power plant designs provide for on-line testing of most components associated with engineered safety features. Test reactors, for the most part, do not have provisions for on-line tests. Instead, most test and maintenance activities are performed for the test reactors before each experiment (while the reactor is shut down). Thus, test outages can influence system unavailabilities for the commercial power plant; they are not so significant with test reactors.
- (2) Test reactors are subject to more frequent startups and shutdowns; therefore, components characterized by cyclic failure rates are more likely to fail in a given time frame.
- (3) Test reactor operations are less routine due to the variety of experimental test programs encountered, thus more operational attention is required in the control and surveillance of the plant.

DISTRIBUTION RECORD FOR ANCR-1271

External

68 - UC-78, Light Water Reactor Technology - TID-4500, R64

Internal

- 1 Chicago Patent Group ERDA 9800 South Cass Avenue Argonne, Illinois 60439
- 3 A. T. Morphew, Classification and Technical Information Officer ERDA-ID
 Idaho Falls, Idaho 83401
- 11 INEL Technical Library
- 41 Special Internal Distribution

Total Copies Printed - 124